

INSTRUCTION MANUAL

**MODEL 146
MULTIFUNCTION
GENERATOR**

WAVETEK
SAN DIEGO

9045 BALBOA AVENUE, SAN DIEGO, CALIFORNIA



Serial No. _____

INSTRUCTION MANUAL

**MODEL 146
MULTIFUNCTION
GENERATOR**

THIS DOCUMENT CONTAINS INFORMATION PROPRIETARY TO WAVETEK. THE INFORMATION IN THIS DOCUMENT IS NOT TO BE USED OR DUPLICATED IN ANY MANNER WITHOUT THE PRIOR APPROVAL IN WRITING OF WAVETEK.

WAVETEK®

SAN DIEGO

9045 Balboa Ave., San Diego, Calif. 92123
P. O. Box 651, San Diego, California 92112
Tel 714/279-2200 TWX 910-335-2007

Manual Revision 4/80
Instrument Release P-6/79

WARRANTY

All Wavetek instruments are warranted against defects in material and workmanship for a period of one year after date of manufacture. Wavetek agrees to repair or replace any assembly or component (except batteries) found to be defective, under normal use, during this period. Wavetek's obligation under this warranty is limited solely to repairing any such instrument which in Wavetek's sole opinion proves to be defective within the scope of the warranty when returned to the factory or to an authorized service center. Transportation to the factory or service center is to be prepaid by purchaser. Shipment should not be made without prior authorization by Wavetek.

This warranty does not apply to any products repaired or altered by persons not authorized by Wavetek, or not in accordance with instructions furnished by Wavetek. If the instrument is defective as a result of misuse, improper repair, or abnormal conditions or operations, repairs will be billed at cost.

Wavetek assumes no responsibility for its product being used in a hazardous or dangerous manner either alone or in conjunction with other equipment. High voltage used in some instruments may be dangerous if misused. Special disclaimers apply to these instruments. Wavetek assumes no liability for secondary charges or consequential damages and, in any event, Wavetek's liability for breach of warranty under any contract or otherwise, shall not exceed the purchase price of the specific instrument shipped and against which a claim is made.

Any recommendations made by Wavetek for use of its products are based upon tests believed to be reliable, but Wavetek makes no warranty of the results to be obtained. This warranty is in lieu of all other warranties, expressed or implied, and no representative or person is authorized to represent or assume for Wavetek any liability in connection with the sale of our products other than set forth herein.

CONTENTS

Product Improvement Notice

SECTION 1 INTRODUCTION

1.1 Wavetek's Commitment

Wavetek maintains a continuing program to make improvements to their instruments that will take advantage of the latest electronic developments in circuitry and components.

SECTION 2

Due to the time required to document and print instruction manuals, it is not always possible to incorporate these changes in the manual.

Wavetek has manufactured your instrument, using metal film 1% tolerance resistors in place of 5% carbon resistors, wherever practical. This results in a substantial improvement in the overall performance of your instrument. Therefore, there may exist a discrepancy between the resistor used to manufacture your instrument and the resistor called out in the Parts List and Schematic Diagrams in this manual.

SECTION 3

If field replacement of an affected resistor does become necessary, replacement may be made in accordance with the manual call outs. Wavetek, however, recommends replacement with the same type of resistor used in the manufacture of your instrument, whenever possible.

SECTION 4 CALIBRATION AND MAINTENANCE

4.1 INTRODUCTION

4.2 INSTRUMENT TEST ALIGNMENT

4.3 POWER SUPPLY ADJUSTMENT

4.4 CALIBRATION INSTRUMENTS

4.5 CORRECTIVE MAINTENANCE

SECTION 5 DRAWING, ACCESSORIES AND PARTS LISTS

5.1 DRAWINGS

5.2 ACCESSORIES

5.3 PARTS LISTS

5.4 RECOMMENDED SPARE PARTS LIST

CONTENTS

SECTION 1 INTRODUCTION

1.1	GENERAL CAPABILITIES	1-1
1.2	PHYSICAL AND ELECTRICAL SPECIFICATIONS	1-1

SECTION 2 INSTALLATION AND OPERATION

2.1	MECHANICAL INSTALLATION	2-1
2.2	ELECTRICAL INSTALLATION	2-1
2.3	OPERATING CONTROLS	2-1
2.4	INSTALLATION CHECKS	2-5
2.5	OPERATING PROCEDURE	2-7

SECTION 3 CIRCUIT DESCRIPTION

3.1	GENERAL DESCRIPTION (Main Generator)	3-1
3.2	THEORY OF OPERATION	3-2
3.3	GENERAL DESCRIPTION (Auxiliary Generator)	3-5

SECTION 4 CALIBRATION AND MAINTENANCE

4.1	INTRODUCTION	4-1
4.2	RECOMMENDED TEST EQUIPMENT	4-1
4.3	ACCESS INSTRUCTION	4-1
4.4	CALIBRATION INSTRUCTIONS	4-1
4.5	CORRECTIVE MAINTENANCE	4-5

SECTION 5 DIAGRAMS, ADDENDUMS AND PARTS LISTS

5.1	DIAGRAMS	5-1
5.2	ADDENDUMS	5-2
5.3	PARTS LISTS	5-2
5.4	RECOMMENDED SPARE PARTS LIST	5-2




Figure i — Model 146 Multifunction Generator

SCOPE OF THIS MANUAL

This manual provides descriptive material and instructions for the installation, operation, maintenance, and repair of this instrument. Wavetek's product improvement program ensures that the latest electronic developments are incorporated in all Wavetek instruments by the addition of circuit and component changes as rapidly as development and testing permit. Due to the time required to document and print instruction manuals, it is not always possible to incorporate the more recent changes in the released manual. In this case, data will be found on addendum change page(s) at the back of the manual.

We continue to rely on careful readers to help us improve future revisions of this instruction manual. If you should spot an error, inconsistency, or ambiguity, send your corrections and comments to:

WAVETEK
Publications Department
P. O. Box 651
San Diego, Calif. 92112

1

SECTION

INTRODUCTION

1.1 GENERAL CAPABILITIES

The Model 146 Multifunction Generator consists of two independent signal sources in one integrated unit. Each generator can be used as an individual signal source, or both can be used together. Functions and operating modes of both generators are push button selectable. The signal of the main generator can be frequency or amplitude modulated by any of the auxiliary generator waveforms. Analog control of output frequency and amplitude is provided by VCG (Voltage Controlled Generator) and VCA (Voltage Control of Amplitude) circuitry. Amplitude is variable from maximum through null to maximum at inverted phase. A caliper dial establishes upper and lower limits for frequency and amplitude modulation. Continuous, triggered and gated waveforms can be produced by the main generator through the range of 0.0005 Hz to 10 MHz. The auxiliary generator is capable of producing sine, square, triangle, and special sawtooth outputs. These waveforms can be internally applied to the main generator to obtain frequency modulation and frequency sweep up to 1000:1 ratio; amplitude modulation through 100% to suppressed carrier modulation; and triggered, gated and tone burst outputs. Operating range of the auxiliary generator is 0.004 Hz to 100 kHz. Both generators can be externally triggered. VCG and VCA connectors are available for external inputs to the main generator. Auxiliary and main generator output impedances are 600Ω and 50Ω, respectively.

1.2 PHYSICAL AND ELECTRICAL SPECIFICATIONS

MAIN GENERATOR

1.2.1 Versatility

Waveforms

Selectable sine , square , and triangle  and dc outputs. Symmetry of all outputs continuously adjustable from 1:19 to 19:1, with rear panel control. Varying triangle symmetry provides a positive slope sawtooth , or negative slope sawtooth  output. Separate sync with variable symmetry (see below). Waveform can be continuous, triggered, or gated.

Frequency Range

0.0005 Hz to 10 MHz in 10 decade ranges.

Ranges

X 0.001	0.0005 Hz to 0.01 Hz
X 0.01	0.005 Hz to 0.1 Hz
X 0.1	0.05 Hz to 1 Hz
X 1	0.1 Hz to 10 Hz
X 10	1 Hz to 100 Hz
X 100	10 Hz to 1 kHz
X 1K	100 Hz to 10 kHz
X 10K	1 kHz to 100 kHz
X 100K	10 kHz to 1 MHz
X 1M	100 kHz to 10 MHz

NOTE

When symmetry control is used, indicated frequency is divided by a factor of approximately 10.

Main Output

Sine, square, and triangle selectable. Maximum output 20 V p-p open circuit and 10 V p-p into 50Ω. Precision front dial controls the amplitude with high resolution and provides phase reversal of output. Output impedance is 50Ω. Short circuit current is 150 mA. Precision output range multiplier with four decade steps.

Sync Output

Amplitude greater than 4 V p-p into open circuit; 2 V p-p into 50Ω. Rise and fall times are less than 50 nanoseconds. Square waveform for symmetrical outputs; rectangular waveform for non-symmetrical outputs.

DC Offset

Can be controlled manually using the front panel control. Range of ±10 Vdc into open circuit (±5 Vdc into 50Ω load), peak output limited to ±15 Vdc into open circuit (±7.5 Vdc into 50Ω load). DC offset and output waveform are attenuated proportionately by the amplitude range multiplier.

Operating Modes

Continuous, triggered, and gated modes of the main and auxiliary generator are push button selectable. Triggering or gating of the main generator by the auxiliary generator is internal. The auxiliary generator may be triggered or gated by the main generator through external connections on the rear panel. Both generators provide for external triggering and gating.

1.2.2 Accuracy

Horizontal Precision

Frequency Accuracy of Symmetrical Waveforms

0.001 Hz to 1 MHz . . . ±(1% of setting +1% of full scale)
1 MHz to 10 MHz . . . ±(2% of setting +2% of full scale)
Applies for symmetrical waveforms.

Vernier

Electronic vernier controls provided for precision frequency and amplitude adjustment.

Time Symmetry

10 Hz to 100 kHz ±0.5%
0.001 Hz to 500 kHz ±0.1%

Vertical Precision

Amplitude Dial Accuracy

0.001 Hz to 10 kHz ±(2% of setting +2% of full scale).
Accuracy stated is for X 1 amplitude multiplier. For X 0.1, X 0.01, X 0.001, add ±3% +1 mV.

Frequency Response (Sine Wave)

Amplitude change with frequency less than:
0.13 dB to 1 MHz
0.59 dB to 10 MHz

Stability

Short term ±0.05% for 10 minutes
Long term ±0.25% for 24 hours
Percentages apply to amplitude, frequency, and dc offset.

Amplitude Symmetry

All waveforms are symmetrical about ground within ±2% of maximum peak to peak amplitude.

1.2.3 Waveform Purity

Sine Wave Distortion

10 Hz to 100 kHz . . . less than 0.5% (typically 0.25%)
0.001 Hz to 1 MHz less than 1.0%
1 MHz to 10 MHz . . . all harmonics at least 26 dB down

Triangle Linearity

Greater than 99% 1 Hz to 100 kHz

Square Wave Rise and Fall Time (Terminated into 50Ω Load)

Less than 50 nanoseconds.

Total Aberrations

Less than 5%.

1.2.4 Analog Control Characteristics

Voltage Controlled Generator (VCG)

Up to 1000:1 frequency change with external voltage input. Required external signal for full control is 5 volts with input impedance of 5 kΩ. When the FM switch is depressed, the output of the auxiliary generator is connected to the VCG circuit and the FM LIMITS knob controls the amount of modulation.

VCG Control Range

Upper frequency is limited to maximum of selected range. Minimum and maximum frequencies are indicated by the caliper pointers and the center frequency is indicated by the frequency index when in internal sweep.

VCG Input Frequency

VCG Bandwidth 100 kHz
VCG Slew Rate 2% of range per microsecond

VCG Linearity

10 Hz to 100 kHz ±0.2%
0.001 Hz to 1 MHz ±0.5%

Voltage Control of Amplitude (VCA)

Full amplitude control with an external voltage input of ±5 volts. The control is bipolar, that is, the amplitude can be controlled from maximum through null to range maximum at inverted phase. VCA input impedance is 10 kΩ. When the AM switch is depressed, the output of the auxiliary generator is connected to the VCA input. The AM LIMITS control adjusts the amount of AM modulation. Minimum and maximum amplitudes are indicated by the caliper pointers and the mean amplitude is indicated by the amplitude index.

VCA Response

Bandwidth 100 kHz, slew rate 2% of range per microsecond.

VCA Linearity

1% of full scale.

AUXILIARY GENERATOR

1.2.5 Versatility

Waveforms

Selectable sine , square , triangle , positive slope sawtooth , and negative slope sawtooth  outputs. Output level fixed 5 V p-p into open circuit. Approximately 2.5 V p-p into 600Ω (600Ω output impedance). Short circuit current is approximately 4 mA peak. Rear panel AUX SYNC OUT connector provides approximately 5 V sync signal.

Dynamic Frequency Range

0.004 Hz to 100 kHz (250 seconds per cycle to 10 μ s per cycle) calibrated in frequency and time.

Operating Frequency Range

X 0.01 Hz	0.004 Hz to 0.1 Hz ($\swarrow$ $\searrow$ only)
X 0.1 Hz	0.04 Hz to 1 Hz
X 1 Hz	0.4 Hz to 10 Hz
X 10 Hz	4 Hz to 100 Hz
X 100 Hz	40 Hz to 1 kHz
X 1 kHz	400 Hz to 10 kHz
X 10 kHz	4 kHz to 100 kHz ($\sim$ $\sqcap$ $\sim$ only)

1.2.6 Environmental

Temperature

All specifications listed except for stability are for 25°C $\pm$ 5°C. For operation from 0°C to 55°C, derate all specifications by a factor of 2.

1.2.7 Mechanical

Dimensions

17¼ inches wide, 5¼ inches high, 17 inches deep.

Weight

14 lbs net, 23 lbs shipping.

Power

105 V to 125 V or 200 V to 250 V, 50 Hz to 400 Hz. Less than 45 watts.

NOTES

All specifications apply for frequencies obtained when dial is between 1.0 and 10 on the Main and Auxiliary Generators. Main Generator output specifications apply at 10 V p-p into a 50 Ω load.

It is possible to stop the generator from oscillating by applying a negative voltage when the dial is already set at a minimum frequency. Input up to 30 V will not permanently damage the instrument, however.

SECTION 2

INSTALLATION AND OPERATION

2.1 MECHANICAL INSTALLATION

After unpacking the instrument, visually inspect all external parts for possible damage to switches, connectors, surface areas, etc. If damage is discovered, file a claim with the carrier who transported the unit. The shipping container and packaging material should be retained in case reshipment is required.

A Wavetek Rack Adapter Kit will allow this unit to be mounted in a standard 19-inch equipment rack. No mechanical installation is required when the instrument is to be used as a portable bench unit.

2.2 ELECTRICAL INSTALLATION

2.2.1 Power Connection

NOTE

Unless otherwise specified at the time of purchase, all Wavetek Model 146 instruments are shipped from the factory with the power transformer connected for operation on a normal 115-volt ac line supply, and a 1/2 ampere 115-volt slow-blow line fuse.

CAUTION

To convert to 230 volts, set the slide switch at the rear of the instrument to 230, and replace the fuse with a slow-blow fuse rated at 1/4 ampere at 230 volts. Connect the ac line cord to the mating connector at the rear of the unit.

2.2.2 Signal Connections

Use 50 Ω shielded cables equipped with female BNC connectors to distribute all RF signals when connecting this instrument to associated equipment.

2.3 OPERATING CONTROLS

The operating controls and electrical connections for the Model 146 are shown in Figures 2-1 and 2-2. Each of the following paragraph numbers corresponds to a number appearing in Figure 2-1, front panel, and Figure 2-2, rear panel.

FRONT PANEL CONTROLS

1. **FREQ Hz** — Selects one of ten decade ranges from X 0.001 to X 1M to establish the frequency multiplier for main generator frequency.
2. **Frequency VERNIER** — Allows precision control of the output frequency. A complete turn of this control is approximately equal to 1% of full scale on the FREQUENCY dial. When turned to the full clockwise position (CAL), settings on the main dial will be calibrated.
3. **FREQUENCY Dial (Main)** — Controls the frequency of the main generator. The setting on this dial multiplied by the frequency range setting (1) equals the output frequency of the generator. The frequency VERNIER (2) and the SYMMETRY ADJUST (39) (rear panel) also affect the generator frequency.
4. **FREQUENCY Index (Main)** — The lower point of the triangle above the FREQUENCY dial indicates the dial setting.
5. **Caliper Pointers (FM)** — Indicate the limits for frequency sweep or modulation on the FREQUENCY dial (3).
6. **DC OFFSET Control** — Controls the amount of dc or baseline offset above (+) or below (–) signal ground. The larger knob controls the polarity of dc offset and the smaller knob adjusts the baseline offset ± 10 Vdc into an open circuit (± 5 Vdc into 50 Ω load), with peak output limited to ± 15 Vdc into an open circuit (± 7.5 Vdc into 50 Ω load).
7. **AMPLITUDE Dial** — Allows calibrated control of amplitude for the main generator output. This control is bipolar; that is, as the dial is rotated from the full cw to full ccw, the output waveform will be




Figure 2-1. Operating Controls and Electrical Connections, Front Panel


phase shifted 180° as the dial passes through zero. This setting multiplied by the VOLTS P-P (10) setting and VERNIER (11) adjustment equals the main generator output amplitude.

8. **AMPLITUDE Index** – The lower point of the triangle above the AMPLITUDE dial indicates the dial setting.
9. **Caliper Pointers (AM)** – Indicate the limits for amplitude modulation on the AMPLITUDE dial (7).
10. **VOLTS P-P** – Attenuates the main generator output signal in four calibrated steps, X 1, X 0.1, X 0.01 and X 0.001.
11. **VOLTS P-P VERNIER** – Allows precision control over the output amplitude. A complete turn of this vernier is equivalent to approximately 5% of the AMPLITUDE dial (7) setting multiplied by the VOLTS P-P (10) selector setting. When in the full cw position (CAL), the setting on the AMPLITUDE dial (7) will be calibrated.
12. **FREQ/PERIOD** – Selects one of seven decade ranges from X 10 mHz to X 10 kHz (black numerals and letters) for auxiliary generator frequency. However, the X 10 mHz setting can only be used when the positive or negative slope sawtooth waveform $\nearrow$ is selected. The X 10 kHz setting can only be used when the sine $\sim$, triangle ∇ , or square

$\square$ (15) waveform is selected. The selected frequency range and black AUX FREQUENCY dial setting (13) determine the output frequency of the auxiliary generator. The dial and range multiplier are also calibrated in period for convenience. This calibration is indicated in red.

13. **AUX FREQUENCY Dial** – Controls the frequency of the auxiliary generator. The outer scale setting (black on this dial) multiplied by the selected frequency range (12) equal the output frequency of the auxiliary generator. The inner scale setting (red on this dial) multiplied by the selected period setting (12) gives the auxiliary generator period.
14. **AUX FREQUENCY Index** – The lower point of the triangle above the AUX FREQUENCY dial indicates the dial setting.
15. **AUX FUNCTION Selector** – Allows push button selection of the waveform to appear at the AUX OUT (19) connector. The waveforms are sine $\sim$, triangle ∇ , square $\square$, sawtooth $\nearrow$, and negative slope sawtooth $\searrow$ for normal functions. These waveforms appear in black above the push buttons. When the AUX MODE – TRIG or GATE push button is in the depressed position and the TRIG push button is in the depressed position (INVERT) position, depressing one of the AUX FUNCTION push buttons will select the waveform appearing in red below the push button.

16. **TRIG** — Selects the state of the step source which controls the direction of integration when enabled by the TRIG IN signal (18). In the NORMAL (released) position, the auxiliary generator will start integrating positively and in the INVERT (depressed) position, it will start integrating negatively. This switch is only effective in the TRIG (17) or GATE (17) auxiliary mode. (Refer to the following illustration.)



17. AUX MODE Selector

CONT (Continuous Mode) — Allows continuous wave operation of the auxiliary generator at the selected frequency.

TRIG (Trigger Mode) — Allows the auxiliary generator to produce one complete cycle of output for each square wave pulse applied to the TRIG IN connector (18).

GATE (Gated Mode) — Operates the same as trigger mode, except that the auxiliary generator will continue to produce an output for the full time that the signal at the TRIG IN connector (18) exceeds the minimum gating level (approximately +2 volts). When the gating signal is removed, the generator will complete the last cycle.

18. **TRIG IN** — Provides a dc coupled input with 3 k Ω input impedance, when in the GATE mode (17). The minimum gating level (signal at TRIG IN connector) is +2 volts. When in the TRIG mode (17), the TRIG IN connector is ac coupled and requires a minimum

input square wave of 4 volts peak to peak and 1 micro-second in width. Maximum external input level is 30 volts peak for both modes.

19. **AUX OUT** — Provides approximately 600 Ω output impedance connection for all auxiliary generator output functions. The output amplitude is ± 2.5 volts into an open circuit.
20. **50 Ω OUT** — Provides 50 Ω output impedance connection for all main generator output signals.
21. **AM** — When depressed, this push button enables amplitude modulation of the main generator signal by the waveform selected in the auxiliary generator. The frequency of the modulation envelope is determined by the auxiliary generator.
22. **AM LIMITS** — Opens the AM caliper pointers when turned in the cw direction and closes the pointers when turned in the ccw direction to set the amplitude modulation limits. The AM push button must be depressed to enable the caliper pointers to set the calibrated limits.
23. **VCA IN** — Provides connections for an external input signal up to ± 5 volts for amplitude modulation of the main generator signal. Input impedance is 10 k Ω .
24. **MODE Selector**

CONT (Continuous Mode) — Provides continuous wave operation of the main generator at a fixed frequency.

TRIG (Trigger Mode) — Allows the main generator to produce one complete cycle of output for each pulse applied to the TRIG IN connector (25). Manual triggering can be accomplished by rotating the TRIG LEVEL control (26) from full ccw to full cw position with the TRIG LEVEL switch (26) in the positive (+) position. At higher generator frequencies, triggering with this manual control will be difficult. Use an external trigger.

GATE (Gated Mode) — Operates the same as trigger mode, except that the main generator will continue to produce an output for the full time that the signal at the TRIG IN connector (25) exceeds the minimum gating level (approximately +2 volts).

25. **TRIG IN** — Provides connection for an external trigger or gating signal to the main generator when the TRIG or GATE (24) push button is in the depressed position. The trigger signal should be at least ± 3 volts dependent upon the position of the TRIG LEVEL switch (26). Maximum external input level is ± 50 volts peak.

26. **TRIG LEVEL Selector and Control** — When the selector (larger knob) is set to the INT position, the main generator is triggered internally by the auxiliary generator. In the INT position, the TRIG LEVEL control adjusts the sensitivity of the trigger input circuitry, + (ccw) and - (cw). When an external trigger is used, the TRIG LEVEL selector must be set to the - or + position for selection of the respective negative or positive portion of the trigger signal. When the control is in the full cw position, approximately -15 volts is required for triggering. In the full ccw position, approximately +15 volts is required for triggering. At the midpoint, extremely low voltages will trigger the main generator.
 27. **FUNCTION Selector** — Allows push button selection of the waveform to appear at the 50 Ω OUT (20) connector. The waveforms are sine $\sim$, triangle ∇ , and square $\square$.
 28. **VCG IN (Voltage Controlled Generator Input)** — Allows external control of frequency. With 0 voltage in, the generator output frequency is determined by the frequency range selected and the FREQUENCY dial setting. A positive VCG voltage will increase the frequency, and a negative voltage will decrease the frequency within the limitations described in 2.5.2. Input impedance is 5 k Ω .
 29. **FM Switch** — Allows the main generator to be frequency modulated by the auxiliary generator when in the depressed position. The FM LIMITS (30) determines the amount of sweep or modulation.
 30. **FM LIMITS** — Opens the FM caliper pointers when turned in the cw direction and closes the pointers when turned in the ccw direction to set the frequency sweep or modulation limits. The FM push button must be depressed to enable the caliper pointers to set the calibrated limits.
 31. **PWR** — Applies power to the unit when push button is in the depressed position.
 32. **Power Indicator** — Illuminates when the unit has been switched on.
- ### REAR PANEL CONTROLS
33. **FUSE** — Protects the instrument from ac line transients as well as short circuits within the instrument. For 115 Vac operation, use a 1/2 ampere slow-blow fuse. For 230 Vac operation, use a 1/4 ampere slow-blow fuse.
 34. **Power Receptacle** — Accepts a female power connector for applying 115 or 230 volts ac.
 35. **115 — 230 Volt Switch** — Selects the power input voltage used. The instrument is normally shipped for 115 Vac and a 1/2 ampere fuse. To convert to 230 Vac, set slide switch to 230 and install a 1/4 ampere slow-blow fuse.
 36. **AUX SYNC OUT** — Provides a synchronizing waveform at the same frequency as the auxiliary generator. The maximum output amplitude is 5 volts peak to peak into an open circuit.




Figure 2-2. Operating Controls and Electrical Connections, Rear Panel

37. **GCV OUT** — Provides an analog voltage which is proportional to the output frequency of the main generator. This output is changed when the main generator FREQUENCY dial (3) is turned; a signal is applied to the VCG IN (28) connector; or the auxiliary generator is connected for frequency modulation of the main generator signal.
38. **SYNC OUT** — Provides a square or rectangular output at the same frequency as the main generator. The output amplitude is approximately 4 volts peak to peak into 50Ω impedance.
39. **SYMMETRY ADJUST** — Controls the time symmetry between the positive and negative portions of the output waveform. In the full ccw detented (OFF) position, the control is disabled and the output waveform has 1:1 symmetry (50% duty cycle). Rotating the control in a cw direction will release the calibrated detent and cause the frequency to divide by approximately 10. Continuing in a cw direction will vary the time symmetry from 1:19 through 19:1. This allows a minimum pulse width of approximately 50 nanoseconds with a repetition rate of 1 MHz.

2.4 INSTALLATION CHECKS

This paragraph outlines a quick checkout procedure to determine if the instrument is operating correctly. Field calibration and checkout instructions are given in Section 4 to determine compliance with electrical specifications. If electrical deficiencies exist, refer to the warranty on the back of the title page. Use an oscilloscope and counter-timer of the type stated in Table 4-1 when performing these installation checks.

- Set front and rear panel switches and controls as follows (refer to Section 2.3 for location of controls):

SWITCH/CONTROL	POSITION/ROTATION
MAIN GENERATOR	
FREQ Hz	X 10
Frequency VERNIER	cw
FREQUENCY Dial	10
FM	out
FUNCTION	
DC OFFSET Switch	OFF
DC OFFSET Control	ccw
TRIG LEVEL Switch	INT
TRIG LEVEL Control	ccw
MODE	CONT
AMPLITUDE Dial	ccw at 10
VOLTS P-P	X 1
VOLTS P-P VERNIER	cw
AM	out

AUXILIARY GENERATOR

FREQ/PERIOD	X 100 Hz/X 1 ms
FREQUENCY Dial	10
AUX MODE	CONT
TRIG	NORMAL (out)
AUX FUNCTION	

- Depress PWR push button and check to assure indicator is illuminated.
- Connect AUX OUT to oscilloscope. Check to assure waveform displayed is 5 V p-p open circuit (approximately 2.5 V p-p terminated into a 600Ω load) at 1 kHz.
- Connect a BNC cable between auxiliary generator TRIG IN connector and main generator SYNC OUT (rear panel). Depress AUX MODE — TRIG push button. Check oscilloscope display to assure one cycle of selected waveform appears and is identical to waveform *above* selected function push button.
- Depress TRIG (NORMAL/INVERT) push button. Check oscilloscope display to assure waveforms appear identical to waveform *below* selected function push button.
- Depress AUX MODE — GATE push button. Check oscilloscope display to assure several cycles of selected waveform appear.
- Depress AUX MODE — CONT push button.
- Rotate AUX FREQUENCY generator dial cw to the 1 setting, while observing oscilloscope display. Sine wave frequency should change from 1 kHz to 100 Hz. Check range-to-range tracking accuracy with dial setting at 10.

NOTE

, , and functions will not operate on lowest range, X 10 mHz.

- Depress AUX FUNCTION — push button.
- Check range-to-range tracking accuracy with dial setting at 10.

NOTE

and functions will not operate on highest range, X 10 kHz.

11. Check remaining AUX FUNCTION selections for correct waveforms.
12. Connect AUX SYNC OUT connector (rear panel) to oscilloscope. Waveform display should be a 5 V p-p square wave for $\wedge$, $\vee$, and $\sqcap$ functions and 5 V p-p rectangular wave for $\swarrow$ and $\searrow$ functions.
13. Set FREQ Hz switch to X 100 position.
14. Connect oscilloscope Trigger In Connector to instrument SYNC OUT connector (rear panel).
15. Connect 50 Ω OUT connector to oscilloscope with 50 ohm terminator. Waveform should be 1 kHz sine wave at 10 V p-p. Rotate AMPLITUDE dial cw. Amplitude should decrease to zero when dial setting reaches 0 and should increase to 10 V p-p, 180° out-of-phase, at full cw setting.
16. Turn AMPLITUDE dial to 0; depress AUX FUNCTION $\sqcap$ push button; and connect a BNC cable from AUX OUT connector to VCA IN connector. Check to assure amplitude of oscilloscope display is approximately 5 V p-p and symmetrical about ground.
17. Set DC OFFSET switch to – position. DC OFFSET control should vary waveform reference from 0 to at least –5 volts.
18. Set DC OFFSET switch to + position. DC OFFSET control should vary waveform reference from 0 to at least +5 volts.
19. Disconnect BNC cable from AUX OUT and VCA IN connector.
20. Set DC OFFSET switch to OFF position; depress AM push button; and turn AM LIMITS control until caliper pointers are on both 5s of AMPLITUDE dial. Check to assure amplitude of oscilloscope display is approximately 5 V p-p and symmetrical about ground.
21. Turn AMPLITUDE dial to either 10 (caliper pointers together); release AM switch; depress AUX MODE – CONT push button; depress MODE – TRIG push button; depress AUX FUNCTION – $\vee$ push button; set FREQ Hz to X 1K position; set FREQ/PERIOD switch to X 100 Hz position; and adjust Trigger Level Control until one cycle of selected waveform appears in oscilloscope display.
22. Depress MODE – GATE push button. Check oscilloscope display to assure multiple cycles of selected waveform appear when Trigger Level Control is rotated toward the cw extreme and disappear when the control is turned toward the ccw extreme.
23. Set TRIG LEVEL switch to negative (–) position. Connect BNC connector from AUX OUT connector to main generator TRIG IN connector. Check to assure multiple burst of cycles of selected waveform appears in oscilloscope display when the Trigger Level Control is rotated toward the cw extreme and disappears when the control is turned toward the ccw extreme.
24. Set TRIG LEVEL switch to positive (+) position. Check to assure multiple burst of cycles of selected waveform appears in oscilloscope display, when the Trigger Level Control is rotated toward the ccw extreme and that the generator free-runs when the control is turned toward the cw extreme.
25. Depress MODE – CONT push button; set TRIG LEVEL switch to INT position; turn Trigger Level Control fully ccw; and depress FUNCTION – $\sqcap$ push button. Check to assure oscilloscope display is $\sqcap$ waveform, 10 V p-p at 10 kHz.
26. Move VOLTS P-P switch to each position while checking oscilloscope display to assure correct attenuation at each position. Return VOLTS P-P switch to X 1 position.
27. Rotate VOLTS P-P VERNIER control to assure approximately 5% change of amplitude reading. Return control to CAL position.
28. Rotate FREQUENCY dial cw to the 1 setting, while observing oscilloscope display to assure square wave frequency changes from 10 kHz to 1 kHz. Check range-to-range tracking accuracy with dial setting at 10.
29. Rotate FREQ Hz VERNIER control to assure approximately 1% change in full scale frequency and return to CAL position.
30. Set FREQ Hz switch to X 10K position. Rotate SYMMETRY ADJUST control (rear panel) slightly cw until detent is disengaged. Check oscilloscope display to assure square waveform is unsymmetrical by a ratio of approximately 1:19 and the frequency is divided by approximately 10. Continue rotating the SYMMETRY ADJUST control through its entire range. Symmetry of the square waveform should vary from 1:19 through 1:1 to 19:1 at the full cw extreme.

31. Rotate SYMMETRY ADJUST control ccw to OFF position; set FREQUENCY dial to 0; set FREQ Hz to 1K position; depress AUX MODE — TRIG push button; depress AUX FUNCTION — $\square$ push button; depress TRIG push button to INVERT; and connect BNC cable between AUX OUT connector and VCG IN connector. Check to assure square waveform frequency in oscilloscope display is approximately 5 kHz.
32. Remove cable from AUX OUT and VCG IN connectors; turn FM LIMITS control cw; and depress FM push button. Check to assure square waveform frequency in oscilloscope display is approximately 10 kHz. Return FM push button to out position.
33. Connect oscilloscope to SYNC OUT connector. Check to assure square waveform in oscilloscope display is 4 V p-p (2 V p-p into 50 ohm load).
34. Connect oscilloscope to GCV OUT connector (rear panel). Rotate main generator FREQUENCY dial from fully cw to fully ccw. Check oscilloscope display to assure voltage level varies from 0 to +5 volts.

2.5 OPERATING PROCEDURE

No preparation for operation is required beyond completion of the initial installation checks given in Paragraph 2.4 of this manual. It is recommended that a one-half hour warm-up period be allowed for the associated equipment to reach a stabilized operating temperature and for the Model 146 to attain stated accuracies.

2.5.1 Operation as a Function Generator

MAIN GENERATOR

1. Terminate 50 Ω OUT connector with 50 ohm $\pm$ 1% termination.
2. Select desired waveform and mode of operation by depressing respective FUNCTION and MODE push buttons.
3. Set desired output frequency by setting the FREQUENCY dial and FREQ Hz range multiplier to the respective positions.
4. Select desired amplitude of output by setting the AMPLITUDE dial and VOLTS P-P multiplier to the respective positions.

5. Select the polarity of dc offset desired using the DC OFFSET switch, and set the amount of offset using the VERNIER control. If an excessive amount of dc offset is used, waveform clipping may be observed. The sum of peak waveform voltage and dc offset cannot exceed the maximum rated output of the main generator. Maximum output is 15 V peak to peak or 7.5 V peak above and below 0 volts. Offset plus peak voltage cannot exceed 7.5 V. (See Figure 2-3.)




Figure 2-3. DC Offset Control

6. Set SYMMETRY ADJUST control for desired symmetry or dissymmetry. The symmetry control can be used to develop ramp waveforms with variable rise-fall ratios and pulse trains with variable duty cycle. By using the sine wave with dissymmetry, controllable sine distortion can be developed. Figure 2-4 shows the effect of this control on output waveforms.

AUXILIARY GENERATOR

1. Connect oscilloscope to AUX OUT connector (600 ohm output impedance).




Figure 2-4. Waveform Phasing and Symmetry Control

2. Select desired waveform and mode of operation by depressing respective AUX FUNCTION and AUX MODE push buttons.
3. Set desired output frequency by setting FREQUENCY dial and FREQ/PERIOD range multiplier.
4. Output signal should be 5 volts p-p into an open circuit, or 2.5 volts p-p into 600 ohms.

2.5.2 Operation as a Frequency Modulated, Sweep or Voltage Controlled Generator

The frequency of the Model 146 may be modulated or changed in several ways as follows:

1. Modulated around a center frequency.
2. Swept from a low to a high frequency or a high to a low frequency.
3. Frequency Shift Keyed (FSK).

These and other types of frequency modulation may be performed internally or externally. The auxiliary generator provides the waveforms for the internal FM and the VCG IN connector allows an external signal to be used for FM.

Using the internal method of FM allows calibrating the limits of the modulation using the FM LIMITS control. This control spreads the caliper pointers to the desired calibrated limits.

The principle of operation is simple. An increasing voltage causes the frequency to increase and a decreasing voltage causes the frequency to decrease. Therefore, the type of frequency modulation depends only on the waveform used to FM. The following waveforms as selected from the auxiliary generator provide the indicated modulations:

A sine wave input will cause the main generator to FM around the center frequency (f_c) by an amount of Δf (f_m). The f_c is the frequency as read off the main dial under the top index. The f_m is the value as read adjacent to the caliper pointers on the main dial if internal modulation is used. If external modulation is applied to the VCG IN connector, the amount of deviation, Δf , may be approximated using the voltage-to-frequency nomograph shown in Figure 2-5, or may be measured using a counter.

~

⌐

A square wave, or other dc shift, will cause Frequency Shift Keying (FSK). The frequency will instantaneously change to the two values as set by the pointers if internal modulation is used or as determined using the nomograph in Figure 2-5, if an external signal is applied to the VCG IN connector.




A positive sloped ramp will cause the main generator frequency to be swept from a low to a high value. If the internal auxiliary generator is used, these low and high limits may be set by rotating the FM LIMITS control in conjunction with the main FREQUENCY dial to achieve the desired *calibrated* end points of the sweep. The sweep limits are read off the main FREQUENCY dial adjacent to the pointers.



A negative sloped ramp will sweep the generator from a high to a low frequency in the same manner as described above.

INTERNAL FM

Using the internal method of frequency modulating is straightforward since the limits are calibrated. Note the following diagram.



The following is a step-by-step procedure for internal FM:

1. Set the main FREQUENCY dial in conjunction with the FM LIMITS control to the limits required by the application. Up to 1000:1 frequency deviation is allowed. The mechanical stops disallow incorrect settings.
2. Select the waveform which is to be modulated by depressing the appropriate FUNCTION push button on the main generator.
3. Depress MODE — CONT push button on the main generator.
4. Set the AMPLITUDE dial to the desired output level.
5. Set the AUX FREQUENCY dial to the desired rate of modulation.
6. Select the desired modulating waveform by depressing one of the AUX FUNCTION push buttons.

7. Select the desired AUX MODE.
8. Depress the FM push button on the main generator.

EXTERNAL FM

The VCG IN connector can be used to externally control the frequency of the main generator.

NOTE

When using an external voltage to FM, the FM LIMITS control has no affect.

The nomograph in Figure 2-5 may be used to determine the FM limits. If a positive voltage is applied to the VCG IN connector, the frequency will increase from the FREQUENCY dial setting. A negative voltage will cause the frequency to decrease. The VCG range of the Model 146 is 1000:1 on and FREQ Hz selector setting. With external voltage control the frequency can be driven to 0 in any range, but below 1/1000th of full scale, stability is insufficient for practical control.

The nomograph in Figure 2-5 shows the characteristics of the VCG circuit. Column A gives the FREQUENCY dial setting, column B, the VCG voltage and column C, the resultant frequency.

In Example 1, the FREQUENCY dial setting is 5 and the potential at the VCG IN connector is 0 volts. Extend a straight line from 5 (FREQUENCY dial setting) through 0 volts (VCG voltage). The result is an output frequency of 5 (multiplied by the FREQ Hz selector setting).

In Example 2, the FREQUENCY dial setting is 5 and a varying voltage of -1 volt to $+1$ volt is applied to the VCG IN connector. Extend a straight line from 5 (FREQUENCY dial setting) through -1 volt and another through $+1$ volt (VCG voltage). The result is an output frequency that will vary from 3 to 7 (multiplied by the FREQ Hz selector setting).

To obtain a maximum frequency change of 1000:1, such as sweeping from 10 kHz to 10 MHz, proceed as follows:

1. Connect a counter, or oscilloscope, to the 50 Ω OUT connector.
2. Set the FREQ Hz selector to the X 1M position.
3. Turn the FREQUENCY dial cw to a frequency equal to 0.1 of full scale (100:1).
4. Rotate the frequency VERNIER control ccw to reduce the frequency another 10:1, thereby providing a fre-




Figure 2-5. VCG Voltage-to-Frequency Nomograph

quency equal to 0.01 of full scale, 10 kHz (0.01 X 1M = 10 kHz).

5. Connect a 0 to +5 volt ramp signal to the VCG IN connector.
6. Observe that when the VCG signal increases to +5 volts, the output will have increased to a frequency equal to full scale (10 MHz), or 1000 times.

As another example, sweep down from 1 kHz to 1 Hz. The VCG input must be a 0 to -5 volt ramp signal with the FREQUENCY dial turned to 10 and the FREQ Hz selector set at X 100, or 1 kHz (the high frequency). At a -4.995 volt input, the generator will be at the minimum frequency for the X 100 range (0.01 X 100 = 1 Hz).

2.5.3 Operation as a Triggered Generator

2.5.3.1 MAIN GENERATOR TRIGGERED INTERNALLY

The main generator may be triggered internally or externally. The procedure for this mode of operation is:

1. Depress AUX MODE – CONT push button.
2. Depress desired AUX FUNCTION.
3. Set auxiliary generator to the desired triggering frequency. This frequency must be less than the main generator frequency.
4. Set main generator to the desired frequency.
5. Select desired output waveform by depressing the corresponding FUNCTION push button on the main generator.
6. Set TRIG LEVEL switch to INT position.
7. Depress MODE – TRIG push button.
8. Adjust TRIG LEVEL control so that the triggered output is present.

2.5.3.2 MAIN GENERATOR TRIGGERED EXTERNALLY

When triggering the main generator externally, an external source of ± 1 volt minimum must be connected to the main generator TRIG IN connector. The procedure for this mode of operation is:

1. Connect an external trigger source (at least ± 1 V) to the main generator TRIG IN connector.
2. Set external signal source to the desired triggering frequency. This frequency must be less than the main generator frequency.

CAUTION

Input level should not exceed ± 50 volts peak.

3. Set main generator to desired frequency.
4. Select desired output waveform by depressing corresponding FUNCTION push button.
5. Set TRIG LEVEL switch to desired negative (-) or positive (+) position, as necessary.

6. Depress MODE — TRIG push button.
7. Adjust TRIG LEVEL control until triggering occurs.

2.5.3.3 AUXILIARY GENERATOR TRIGGERED OPERATION

When triggering the auxiliary generator, an external trigger source or the main generator may be used. The minimum voltage requirement from either trigger source is 4 volts peak. Minimum pulse width must be at least 1 micro-second, and the slew rate may not exceed 8 volts per micro-second. Inversion of the triggered output of the auxiliary generator is push button controlled from the front panel. Depressing the TRIG push button on the auxiliary generator (INVERT position) will cause the triggered cycle to be generated with a 180° phase reversal. The procedure for triggered operation is:

1. Connect main generator or external trigger signal source (square wave or pulse) to auxiliary generator TRIG IN connector.
2. Set main generator or external signal source to desired triggering frequency with at least 4 V peak amplitude.

CAUTION

Input level should not exceed ±30 volts peak.

3. Set auxiliary generator to desired frequency.
4. Select desired output waveform by depressing corresponding AUX FUNCTION push button.
5. Depress AUX MODE — TRIG push button.

2.5.4 Operation as a Gated or Tone Burst Generator

2.5.4.1 MAIN GENERATOR GATED INTERNALLY

The main generator may be gated internally or externally. Gating internally on a square wave will not allow changing the number of cycles, due to the rapid rise time of the waveform. Using a sloping waveform in conjunction with the TRIG LEVEL control will allow selection of any number of discrete cycles to be generated. The procedure for this operation is as follows:

1. Depress AUX MODE — CONT push button.
2. Select desired triggering waveform (sine, triangle or ramp) by depressing the corresponding AUX FUNCTION push button.

3. Set auxiliary generator to desired frequency. This frequency must be lower than the frequency of the main generator.
4. Set main generator to desired frequency.
5. Select desired output waveform by depressing the corresponding FUNCTION push button.
6. Set TRIG LEVEL switch to INT position.
7. Depress MODE — GATE push button.
8. Adjust TRIG LEVEL control until the desired number of cycles in the burst is obtained.

2.5.4.2 MAIN GENERATOR GATED EXTERNALLY

When gating the main generator externally, an external signal source of ±1 volt minimum must be connected to the main generator. This signal cannot be one with a rapid rise time. Since the TRIG LEVEL control must be used to select voltage levels, a triangle, sine or ramp waveform should be used. The procedure for this mode of operation is:

1. Connect external signal source (sine, triangle or ramp) to main generator TRIG IN connector.

CAUTION

Input level should not exceed ±50 volts peak.

2. Set external signal source to desired frequency. This frequency must be lower than the frequency of the main generator.
3. Set main generator to desired frequency.
4. Select desired output waveform by depressing corresponding FUNCTION push button.
5. Set TRIG LEVEL switch to desired negative (—) or positive (+) position.
6. Depress MODE — GATE push button.
7. Adjust TRIG LEVEL control until the desired number of cycles in the burst is achieved.

2.5.4.3 AUXILIARY GENERATOR GATED OPERATION

When gating the auxiliary generator, an external gating source or the main generator may be used. The minimum requirement for either gating source is +2 volts peak. A sine,

triangle or ramp waveform should be used. Inversion of the gated output of the auxiliary generator is push button controlled from the front panel. Depressing the TRIG push button on the auxiliary generator (INVERT position) will cause the gated burst to be generated with a 180° phase reversal. The procedure for this operation is:

1. Connect main generator or external gating source to auxiliary generator TRIG IN connector.
2. Set main generator or external signal source (sine, triangle or ramp) to desired frequency and amplitude (at least +2 volts peak).

CAUTION

Input level should not exceed 30 volts peak.

3. Set auxiliary generator to desired frequency.
4. Select desired output waveform by depressing corresponding AUX FUNCTION push button.
5. Depress AUX MODE — GATE push button.
6. Adjust main generator AMPLITUDE dial or external signal source level until the desired number of cycles in the burst is achieved.

2.5.5 Operation as a DC Voltage Source

The Model 146 Generator may be used as a variable dc voltage source not to exceed 100 mA of current. The AMPLITUDE dial is a calibrated control only when the instrument is connected to a 50 ohm load. The procedure is:

1. Depress the FUNCTION — $\square$ and MODE — TRIG push buttons.
2. Connect the 50 Ω OUT connector to the device requiring the dc voltage source.
3. Turn the Trigger Level Control fully ccw.
4. Rotate FREQUENCY dial so that "10" is under the index (oscillation may occur at the bottom of the dial). Maximum level of ± 15 V can be obtained into a 50 Ω load.
5. The dc level may be adjusted using the AMPLITUDE dial and/or the DC OFFSET controls.

2.5.6 Operation as an Amplitude Modulated Generator

The Model 146 may be internally or externally amplitude modulated. If the auxiliary generator has the desired waveform describing the envelope and the desired frequency range, then the main generator should be amplitude modulated internally using the auxiliary generator.

If the auxiliary generator is not sufficient as the modulating source, an external signal may be applied to the VCA input connector.

In order to better understand the AM operation of the Model 146, please note the following:

"VCA" means Voltage Controlled Amplitude. Voltage controlled amplitude implies amplitude modulation. The VCA signal originates either internally from the auxiliary generator or externally via the VCA IN connector. This VCA signal is summed with the dc level selected by the p-p AMPLITUDE dial. By rotating the AMPLITUDE dial, a different dc offset is applied to the VCA signal. Now the VCA signal with its offset is multiplied times the carrier signal which originates from the main generator. The product of these two signals gives the AM output. Figure 2-6 shows the block diagram describing the algebraic process.




Figure 2-6. X-Y Multiplier Block Diagram

The VCA signal is Y_1 , and the dc level from the p-p AMPLITUDE dial is Y_2 . Hence, $Y = Y_1 + Y_2$ describes the envelope of the AM output. X is the carrier waveform; therefore, $X \cdot Y = \text{AM output}$.

Figure 2-7 shows several amplitude modulated outputs corresponding to various VCA signals. Note that the percent of modulation may be determined by two factors: the amount of carrier amplitude provided by the AMPLITUDE dial as indicated by the fixed pointer and/or the amplitude of the




Figure 2-7. Amplitude Modulating Input and the Resultant Output


modulating waveform. When modulating internally, the percent of modulation is established using both the p-p AMPLITUDE dial and the AM LIMITS control. The p-p AMPLITUDE dial is providing carrier amplitude and the AM LIMITS control is varying the amplitude of the modulating waveform from the auxiliary generator. These pointers are calibrated, and the percent of modulation may be determined as follows (see Figure 2-7, Diagram A):

$$\frac{A - B}{A + B} \times 100 = \% \text{ of AM}$$

where A = the position of the left hand pointer

and B = the position of the right hand pointer

For example, the following AMPLITUDE dial and pointer positions provide the modulation shown in Figure 2-7.



When modulating with an external waveform, the AM LIMITS control does not control the gain of this signal and, therefore, the pointers may not be used to calibrate the amount of modulation. The gain must be adjusted externally. The p-p AMPLITUDE dial is the only control to set the amount of modulation.

Figure 2-8 provides a nomograph for several different externally applied modulating waveforms. It allows you to determine the peak limits of the amplitude modulated output. The following examples are provided for clarification:

Example 1 displays suppressed carrier modulation. The input must be symmetrical about ground of the Model 146. See Figure 2-7, Diagram C, for a display of the VCA input waveform and the resultant modulated output.

Example 2 shows 100% modulation. The envelope is 4 volts peak to peak. The input sine wave is 2 volts p-p with the negative peak equal to zero as referenced to signal ground of the Model 146. See Figure 2-7, Diagram B, for waveform display.

Example 3 illustrates the effect of using the AMPLITUDE dial together with a VCA input. The result is less than 100%




Figure 2-8. Amplitude Modulation Nomograph for an External Input

modulation, since the AMPLITUDE dial has offset the VCA input above signal ground. The effect is shown in Figure 2-7, Diagram A.

The following step-by-step procedures may be used to set up the generator for internal or external AM.

NOTE

The AM LIMITS control which spreads the caliper pointers around the AMPLITUDE dial is only used when modulating internally. Depressing the AM push button enables this control. An external input to the VCA is not affected by this control.

INTERNAL AM

1. Depress the desired FUNCTION push button to select the carrier waveform.
2. Depress the MODE – CONT push button. You may also operate in the TRIG or GATE mode for other applications.
3. Depress the AUX MODE – CONT push button.
4. Depress the desired AUX FUNCTION push button to select the modulating waveform.
5. Set the carrier frequency using the main generator.
6. Set the modulating frequency of the envelope using the auxiliary generator.
7. Depress AM push button.
8. Vary the AM LIMITS control and the p-p AMPLITUDE dial to set the desired amount of modulation.

EXTERNAL AM

1. Depress the desired FUNCTION push button on the main generator to select the carrier waveform.
2. Depress the MODE – CONT push button. You may also operate in the TRIG or GATE mode for other applications.
3. Set the carrier frequency using the main generator.
4. Be sure the AM push button is in the out position.
5. Connect the modulating waveform to the VCA input connector.
6. The percent of modulation may be varied using the AMPLITUDE dial on the main generator.

2.5.7 Operation as the Horizontal Driver of an Oscilloscope or X-Y Recorder

The Model 146 may be used to drive a display device to show many network response characteristics, such as frequency versus amplitude and frequency versus impedance. This is possible because the GCV OUT (No. 37, Paragraph 2.3) on the rear panel makes available an output voltage which is directly proportional to the instantaneous output frequency of the generator. As the main FREQUENCY dial is rotated, the GCV voltage changes proportionally with the change in frequency. This feature is used to calibrate the graticule of an oscilloscope or the X-axis of an X-Y recorder *directly in the frequency domain*. No time to frequency domain conversion is necessary.




Figure 2-9. Test Setup for an Oscilloscope

Figure 2-9 shows a typical test setup in which GCV is used. The following step-by-step procedure demonstrates how to use GCV with an oscilloscope. In this example, assume that a filter is to be swept and a frequency versus amplitude plot is required.

1. Select the frequency range in which the sweep is to occur.
2. Rotate the FM LIMITS control and spread the calipers to the desired start and stop frequencies. (FM push button should be in the out position.)
3. Select the waveform to be used by depressing the desired FUNCTION push button on the main generator.
4. Depress MODE — CONT push button.
5. DC OFFSET should be OFF.
6. AM push button should be in out position.
7. Set AMPLITUDE dial and multiplier for the desired output.

8. Depress the AUX MODE — CONT and AUX FUNCTION — $\wedge$.
9. Set AUX FREQUENCY to desired sweep rate.
10. Connect the instruments as shown in Figure 2-9. Be sure scope is in the external horizontal mode.
11. Rotate the main FREQUENCY dial so that frequency which was adjacent to the left hand pointer (low frequency sweep limit) is now under the center index.

Adjust the horizontal position of the scope so that the vertical component line is aligned with the left hand major vertical division.

12. Rotate the main FREQUENCY dial so that the frequency which was adjacent to the right hand pointer (high frequency sweep limit; see step 2) is now under the center index.

Adjust the scope horizontal gain so that the vertical component is on the right hand major vertical division.

13. Repeat steps 11 and 12 to eliminate scope gain and position interaction.
14. Return main FREQUENCY dial to the position established in step 2.
15. Depress the FM push button. The scope will now show a frequency response of the filter. The sweep rate should be fast for a good envelope display.




Figure 2-10. Test Setup for an X-Y Recorder

An X-Y recorder may also be driven with the GCV. See Figure 2-10. The procedure is similar to that for an oscilloscope, except that the auxiliary generator signal must be a triggered triangle ($\wedge$) waveform. The X-axis of the plotter may be calibrated in frequency by adjusting the horizontal gain in the same way as with the scope.

2.5.8 Operation as a Pulse Generator

The following pulse outputs are provided by the Model 146:



The pulses may be either positive or negative by rotating the AMPLITUDE dial to either polarity. They may be unipolar or bipolar. The pulses may be rectangular, sinusoidal, triangular or sawtooth in shape.

The duty cycle may be continuously varied over a range of 1:19 to 19:1 by using a symmetry control. Pulse widths as narrow as 50 nanoseconds may be achieved.

Pulses may be generated in two ways:

1. By triggering a single cycle or gating two or more cycles of square waveform from the main generator, the repetition rate is controlled by the trigger source frequency and the pulse width is set by the main generator frequency. Refer to Paragraph 2.5.3 for trigger operation or Paragraph 2.5.4 for gated operation.
2. By using the symmetry control on the rear panel, the pulse width may be varied. The main generator FREQUENCY control selects the repetition rate. The symmetry control in effect is varying the duty cycle of the selected waveform over a range of 1:19 to 19:1. This control divides the frequency by approximately 10 when out of the detent position.

3

SECTION

CIRCUIT DESCRIPTION

3.1 GENERAL DESCRIPTION (Main Generator)

3.1.1 VCG Generator

A simplified block diagram of the VCG generator is shown in Figure 3-1. Triangle and square signals are generated

simultaneously in the generator loop circuit. The triangle is then applied to a sine converter and amplified.

The frequency is controlled by the current from the VCG amplifier which, in turn, is controlled by the voltage from the VCG summing amplifier. Voltage from the VCG sum-




Figure 3-1. VCG Generator Simplified Block Diagram

ming amplifier is also fed into the GCV amplifier which gives a generator control voltage that is proportional to frequency.

One of the signals, square, triangle or sine, is fed into the X-Y multiplier and the amplitude is controlled by the VCA summing amplifier and AM limits buffer. The signal is then fed into the output amplifier. DC offset voltage can be varied positively, or negatively from the front panel dc offset control. The square wave from the triangle generator circuit is also fed into a sync amplifier to generate a sync output.

3.2 THEORY OF OPERATION

3.2.1 Generator Loop

When the voltage at point D is positive, the diodes CRA and CRD are reverse biased and CRB and CRC are forward biased. (See Figure 3-2.) Therefore, the current $I+$ is charging the capacitor C which causes the voltage at points A

and B to rise. As soon as the voltage at point B reaches +1.25 V, the output of the hysteresis switch will switch negative and thus reverse the current flow. The current $I-$ is drawn from capacitor C. Again, the hysteresis switch will switch positive when the voltage at B is below -1.25 V. Thus, triangle and square signals are generated simultaneously.

The output frequency depends on the size of the capacitor selected and the amount of currents, $I+$ and $I-$, charging the capacitor. Currents are controlled by the VCG amplifier which, in turn, is controlled by the voltage from the VCG summing amplifier.

3.2.2 VCG Amplifier and Current Sources

The voltage used to control the output frequency from the VCG amplifier is applied to point A of the VCG amplifier. (See Figure 3-3.) ICA and ICC are used to shift the control voltage ground reference to the power supply reference. ICB and ICD are the current source generators. The two current outputs are fed to the triangle generator.




Figure 3-2. Generator Loop Block Diagram




Figure 3-3.

Amplifier and Current Source Simplified Circuit

If the current of the negative current source is decreased by 19 times, the fall time of the triangle will be 19 times longer than the rise time of the triangle, resulting in an unsymmetrical waveform and a division of the frequency by a factor of 10. Symmetry of the output waveform can be continuously varied, while frequency is held constant. This can be obtained by gradually increasing the current from the negative current source and decreasing the current from the positive current source in such a way that the period for the triangle to complete one cycle remains constant. To accomplish this, the SYMMETRY ADJUST control on the rear panel must be utilized.

3.2.3 GCV Amplifier

The VCG amplifier output (0 to -5 volts) is fed to the generator control voltage (GCV) amplifier. This is a unity gain, inverting amplifier. From the GCV amplifier, the signal is applied to the GCV OUT connector. The GCV voltage (0 to +5 volts) is proportional to the output frequency.

3.2.4 Sine Converter and Amplifier

The sine wave is produced by feeding the triangle wave into a shaping network composed of resistors and diodes. As the triangle wave voltage passes through zero, loading of the triangle wave is minimal and thus the slope is maximum. As the triangle voltage increases, diodes with current limiting resistors conduct successively, causing the slope of the output to be reduced.

Since the diode break points are mathematically computed and fitted to the true sine shape, the resultant waveform resembles a pure sine wave. Using a complimentary pair of diodes on each break point, the circuitry is completely symmetrical about ground. The sine wave, produced by shaping, is considerably less in amplitude than the triangle wave input and is thus amplified to be equal to the triangle wave.

3.2.5 Capacitance Multiplier

Frequency ranging is achieved by selecting different capacitors. For frequency ranges at X 1 Hz or below, large capacitors are necessary and, therefore, impractical. Instead, a capacitance multiplier circuit is used, and ranging is achieved by changing the multiplication factor which is equivalent to the ranging resistors. The simplified circuit is shown in Figure 3-4.

Because of the nature of the feedback loop connection, A1 and A2, most of the current I+ and I- will be drawn by A2 through R1. Only a small percentage of current is charging and discharging capacitor C1. Therefore, the output frequency will appear much slower. The percentage of current




Figure 3-4. Capacitance Multiplier Simplified Circuit

drawn by A2 is precisely controlled by the loop gain and time constant of the capacitance multiplier circuit. Frequency ranging is achieved by changing R2.

3.2.6 X-Y Multiplier, Output Amplifier, and Attenuator

One of the signals is selected and fed into one of the Y inputs and a control voltage from the VCA summing amplifier and AM limits buffer are fed to the X inputs. (Refer to Figure 3-1.) The output from the X-Y multiplier is directly proportional to the product of the X and Y inputs.

The signal is then fed into the output amplifier. This is an inverting amplifier whose output is fed into a step attenuator and then to the output BNC connector (50Ω OUT).

3.2.7 Trigger Gated Modes

The triangle generator will oscillate continuously only if the voltage at G is negative which reverse biases CR48. (Refer to Figure 3-5.) This requires that the voltage at E or F be negative. If both voltages at E and F are positive, then so is the voltage at G. The current through CR48 will keep the voltage of C from falling below zero, because CR47 is clamped at zero. This stops the generator from oscillating.

The J-K flip-flop is used to control the timing, so that the triangle will always stop at the end of the cycle. If the trigger signal is reset between times t_1 and t_3 , the triangle will stop at time t_3 , as shown in the timing diagram.

If the signal at B is differentiated before it is applied to the J-K flip-flop, only one cycle of the triangle signal will be generated for each trigger input.

3.3 GENERAL DESCRIPTION (Auxiliary Generator)

A simplified block diagram of the auxiliary generator is shown in Figure 3-6. The dial pot picks off a $-dc$ voltage proportional to frequency from 0 to -15 V. This voltage is fed to a potentiometric buffer to guard against modification of this voltage by load current.

This buffered generator control voltage is fed through a switched resistive voltage divider to the reference or $+$ input of the operational amplifier used as the integrator. This voltage is the exact common mode voltage seen by the integrator. For time symmetrical waveforms (i.e., $\sim$ $\square$) this common mode voltage is just half of the output of the dial buffer. For the down ramp $\searrow$ it is nearly all of the dial buffer output and for the up ramp $\nearrow$ it is only a small part.

The amplifier and clamp is a circuit which multiplexes alternately between 0 Vdc and the output of the dial buffer on command from the logic generated at the hysteresis switch. The combination of this step function signal and the dc common mode voltage fed to the integrator causes a bipolar voltage to be developed across the integrating resistor which is appropriate for the waveform that is being generated.

A square wave is applied to the input of the integrator. The output of the integrator, a triangle wave, is fed into a hysteresis switch. The hysteresis switch functions like a Schmitt trigger with the limit points set at the waveform extremes, firing when the triangle wave reaches $+1.25$ volts and -1.25 volts. The firing set the hysteresis switch which reverses the square wave fed into the integrator, causing the triangle wave to reverse direction. The result is simultaneous generation of a square wave and




Figure 3-6. Auxiliary Generator Simplified Block Diagram

triangle wave of the same frequency with the positive half cycle of the square wave coincident with the negative slope of the triangle wave.

The frequency of oscillation is determined by the magnitude of capacitor C selected with the **FREQ/PERIOD** switch and by the amplitude of the square wave fed into the integrating resistor R. Setting the potentiometer for maximum voltage, and thus maximum integrating current, produces an output at maximum frequency. Frequency is directly proportional to the amplitude appearing on the arm of the frequency dial potentiometer.

The sine wave is produced by shaping the triangle wave. The triangle wave is fed into a shaping network composed of resistors and diodes. As the triangle wave voltage passes through zero, loading of the triangle wave is minimal and thus the slope is maximum. As the triangle wave voltage increases, diodes with current limiting resistors conduct, successively, causing the slope of the output to be less.

Since the diode break points are mathematically computed and fitted to the true sine shape, the resultant waveform is an almost pure sine wave. The circuitry is completely symmetrical about ground, using a complimentary pair of diodes on each break point. The sine wave produced by shaping is considerably less in amplitude than the triangle wave input and is thus amplified to be equal to the triangle wave.

Selection of a sync or an inverting sync signal for the trigger flip-flop will determine at which phase, positive or negative, the ground clamping feedback loop will be enabled. (See Figure 3-6.) If the **TRIG** push button is in the **NORMAL** (out) position, the integrator output will be integrating positively when clamped to ground at the zero crossing. At this point, the amplitude and clamp will be positive with respect to the integrator input common mode voltage. When a gating pulse is applied to the **TRIG IN** connector, the integrator will start integrating negatively, since the step source is positive. When the **TRIG** push button is in the **INVERT** (depressed) position, the integrator output will be integrating positively when clamped to ground at the zero crossing. At this point, amplifier and clamp will be negative with respect to the integrator input common mode voltage. When a gating pulse is applied to the **TRIG IN** connector, the integrator will start integrating negatively, since the amplifier and clamp are negative. (See illustration on page 2-3 under number 16.)

The generator trigger circuit is disconnected in the continuous-frequency operation just described. When a trigger or gated operation is selected, this circuit places a shunt path between the integrator input and output. Therefore, there is no output at the BNC until an external trigger/gate signal is applied to the trigger input connector. A trigger input enables the generator for one complete cycle of the selected waveform; then, the generator is disabled until another trigger arrives. A gate input allows the generator to function for the duration of the gate.

CALIBRATION AND MAINTENANCE

4.1 INTRODUCTION

This section provides instructions for testing, calibrating, trouble-shooting and repairing the Model 146 instrument. The instructions are concise and written for the experienced electronics technician or field engineer. Wavetek maintains a factory-repair department for those customers not possessing the necessary personnel or test equipment to maintain the instrument. A list of sales/service offices for repair of the instrument is also available on pages iii and iv of this manual. If an instrument is returned to the factory for calibration or repair, a detailed description of the specific problem should be attached to facilitate the turnaround time. The main board test point and adjustment locations are shown on the board itself and all points are illustrated in the data package.

4.2 RECOMMENDED TEST EQUIPMENT

Table 4-1 contains a list of recommended test equipment. Any test equipment having equivalent accuracies may be substituted for those listed.

Table 4-1. TEST EQUIPMENT

Type	Required Characteristics
Oscilloscope	To 250 MHz
Oscilloscope	To 30 MHz
Plug-in	Dual Channel
Plug-in	Peak mV measuring capability
Distortion Analyzer	To 600 kHz
Spectrum Analyzer Display	To 50 MHz
IF Section	
RF Section	
Differential Voltmeter	Microvolt dc measurement
Counter-Timer	To 10 MHz 0.1% of reading accuracy

4.3 ACCESS INSTRUCTION

Removal of the top and bottom dust covers affords quick access to all of the components within the unit.

4.3.1 Removing the Dust Cover

1. Unplug the power cord.
2. Unscrew three screws on top cover.
3. Remove top cover.
4. Follow same procedure for bottom cover removal.

4.4 CALIBRATION INSTRUCTIONS

The following paragraphs provide complete sequential calibration procedures for the Model 146 instrument.

NOTE

The entire calibration procedure must be read first to determine initial control settings and test equipment connections required before attempting recalibration. The steps of this procedure should be performed in the sequence given and the parts within each step should also be performed in the same sequence given. See fold-out on page 4-19 for test point location.

4.4.1 Preliminary Procedures

✓ Allow the unit to warm up for at least 30 minutes. Start the calibration by setting the switches and controls as follows:

FREQ Hz Switch		X 100
Frequency VERNIER		CAL
FREQUENCY Dial		10
DC OFFSET Switch		OFF
DC OFFSET Control		fully ccw
TRIG LEVEL Control		fully ccw
TRIG LEVEL Switch		INT
AMPLITUDE Dial		fully ccw
VOLTS P-P Switch		X 1
Amplitude VERNIER		CAL

FREQ/PERIOD Switch X 10 Hz
 AUX FREQUENCY Dial 10
 AUX FUNCTION Selector $\sim$
 AUX MODE Selector CONT
 AM Switch released (off)
 MODE Selector TRIG
 FUNCTION Selector $\sim$
 FM Switch released (off)
 SYMMETRY ADJUST . . . (rear panel) OFF
 PWR depressed (on)

4.1 Power Supply Regulation

1. Connect ac power to the instrument and connect the voltmeter leads to TP1 (common) and TP2 (+15 V) on the power supply board.
2. Adjust R21 for a reading of +15 Vdc $\pm$ 20 mV.
3. Check the voltage at TP3 for -15 Vdc $\pm$ 50 mV, at TP4 for +28 Vdc $\pm$ 400 mV, at TP5 for -28 Vdc $\pm$ 400 mV, and at TP6 for +5 Vdc $\pm$ 100 mV.

4.2 Auxiliary Triangle Amplitude

1. Connect the oscilloscope with a BNC cable to AUX OUT (unloaded). Use a peak mV measuring capability plug-in module in oscilloscope.
2. Adjust the triangle amplitude to $\pm$ 2.5 V $\pm$ 50 mV using R42 (+) and R58 (-). *Card 1 Block 4*

4.3 Auxiliary Square Wave Amplitude

1. Depress AUX FUNCTION $\square$ and adjust the square wave amplitude to $\pm$ 2.5 V $\pm$ 5 mV using R98 (+) and R110 (-). *Card 1 Block 2*

4.4 Auxiliary Frequency Dial Alignment

1. Set AUX FREQUENCY dial to 10.
2. Set FREQ/PERIOD switch to X 100 and adjust R10 to obtain 1 kHz $\pm$ 1 Hz. *Card 1 Block 3*
3. Adjust R10 for optimum frequency on X 100, X 10, X 1, and X 0.1 of FREQ/PERIOD switch.
4. Set FREQ/PERIOD switch to X 1K and adjust C10 for 10 kHz $\pm$ 10 Hz. *Card 4 Block 4*
5. Set FREQ/PERIOD switch to X 10K and adjust C12 for 100 kHz $\pm$ 100 Hz. *Card 1 Block 5*

6. Set FREQ/PERIOD switch to X 10, AUX FUNCTION selector to $\checkmark$, and adjust R26 to obtain 100 Hz $\pm$ 0.1 Hz. *Card 4 Block 6*

7. Set AUX FUNCTION selector to $\sim$ and adjust R30 to obtain 100 Hz $\pm$ 0.1 Hz. *Card 1 Block 7*

8. Set AUX FREQUENCY dial to 1 and adjust R1 to obtain 10 Hz $\pm$ 0.1 Hz. *Card 1 Block 8*

9. Set AUX FUNCTION selector to $\checkmark$ and adjust R35 to obtain 10 Hz $\pm$ 0.1 Hz. *Card 1 Block 9*

10. Repeat steps 6 through 10 until all frequencies are correct.

4.5 Auxiliary Sine Distortion, Amplitude, and Balance

1. Set AUX FUNCTION selector to $\sim$, FREQ/PERIOD to X 100, and FREQUENCY dial to 10.
2. Adjust R61 to balance output.
3. Adjust R67 to obtain 5 V p-p $\pm$ 10 mV output. *Card 1 Block 10*
4. Connect the test equipment as shown in Figure 4-1. Model 146 connects to the AUX OUT.





Figure 4-1. Distortion Analysis Test Set Up

5. Adjust R28, R53 and R55 for minimum sine distortion.

6. Repeat steps 2 and 3 to obtain $\pm 2.5 \text{ V} \pm 5 \text{ mV}$. *Card 4 Block 11*

4.6 Triangle Amplitude Adjustment

1. Set MODE selector to CONT and AUX MODE selector to TRIG.
2. Connect a X 1 oscilloscope probe to TP7 ($\sim$). Use a peak mV measuring capability plug-in module in oscilloscope.
3. Adjust the triangle amplitude to $\pm 1.25 \text{ V} \pm 5 \text{ mV}$, using R96 (+) and R99 (-). *Card 4 Block 12*

4.7 Frequency and Time Symmetry Calibration

1. Set FREQ Hz to X 10K, FREQUENCY dial to 10, and frequency VERNIER to CAL.
2. Adjust R5 to obtain $100 \text{ kHz} \pm 100 \text{ Hz}$. *Card 4 Block 13*
3. Turn FREQUENCY dial to 1/100 of full scale and verify accuracy with oscilloscope. While opening and shorting the VCG IN, adjust R35 for minimum frequency shift.
4. Adjust time symmetry within 0.1% with R18. *Card 4 Block 14*
5. Set FREQUENCY dial to 1 and adjust R34 to obtain $10 \text{ kHz} \pm 10 \text{ Hz}$. *Card 4 Block 15*

Check for 1000:1 FM operation. If necessary, readjust R34 to maintain 1000:1 operation and requirements in first paragraph of Step 5.

6. Repeat steps 1 and 4, as necessary, for accurate frequency at 10 and 1 on the dial.
7. Set FREQ Hz to X 1M, FREQUENCY dial to 10, and adjust C31 to obtain an output frequency of $10 \text{ MHz} \pm 10 \text{ kHz}$. Check frequency accuracy from 1 to 10 on the dial and readjust C31 to split the error, if necessary. *Card 4 Block 16*
8. Set FREQ Hz to X 100K, FREQUENCY dial to 10, frequency VERNIER to CAL and adjust C42 to obtain $1 \text{ MHz} \pm 1 \text{ kHz}$ at the output. Check frequency accuracy from 1 to 10 on the FREQUENCY dial and readjust C42 to split the error, if necessary. *Card 4 Block 17*
9. Set FREQUENCY dial to 10 and frequency VERNIER to CAL position.
10. Set FREQ Hz to X 1K and adjust R6 to obtain $10 \text{ kHz} \pm 10 \text{ Hz}$. *Card 4 Block 18*
11. Set FREQ Hz to X 100 and adjust R7 to obtain $1000 \text{ Hz} \pm 1 \text{ Hz}$. *Card 4 Block 19*

12. Set FREQ Hz to X 10 and adjust R8 to obtain $100 \text{ Hz} \pm 0.1 \text{ Hz}$. *Card 4 Block 20*

13. Set FREQ Hz to X 1 and adjust R23 to obtain $10 \text{ Hz} \pm 0.01 \text{ Hz}$. *Card 4 Block 21*

14. Adjust R23 for optimum frequency on X 1, X 0.1, X 0.01, X 0.001 of FREQ Hz selector.

15. Set FREQUENCY dial fully ccw, frequency VERNIER to CAL and FREQ Hz to X 1.

16. Adjust R73 for 0.1% time symmetry. *Card 4 Block 22*

4.8 Sine Distortion

1. Set FREQ Hz to X 100, frequency VERNIER to CAL, FUNCTION selector to $\sim$ and FREQUENCY dial to 10.
2. Connect X 1 oscilloscope probe to TP8 ($\sim$).
3. Adjust R141 so that the dc offset of the sine amplifier is zero.
4. Connect the test equipment as shown in Figure 4-1. Model 146 connects to the 50Ω OUT.
5. Adjust R134, R135 and R136 for minimum sine wave distortion.
6. Set FREQ Hz to X 1K and readjust R134, R135 and R136 for optimum sine distortion.
7. Alternately perform steps 5 and 6 until the least amount of sine wave distortion is obtained on both ranges (typically 0.14%). *Card 4 Block 23*

8. Connect oscilloscope probe to TP8 ($\sim$).

9. Adjust R159 for a $2.5 \text{ V p-p} \pm 5 \text{ mV}$ signal output from the sine amplifier. *Card 4 Block 24*

10. Readjust R141 so that the dc offset of the sine amplifier is $0 \text{ V} \pm 5 \text{ mV}$. *Card 4 Block 25*

4.9 X-Y Multiplier Adjustment

1. Set FREQ Hz to X 100, FREQUENCY dial to 10 and FUNCTION selector to $\sim$.

2. Turn AMPLITUDE dial to null waveform at 50Ω OUT (loaded with 50Ω).

3. Adjust R231 for $0 \text{ V} \pm 10 \text{ mV}$. *Card 4 Block 26*

- Set amplitude to 1 V p-p and decrease amplitude until the straight sides of the triangle wave become parabolic.

NOTE

Avoid decreasing the amplitude so far that the waveform folds over into a null.

- Adjust R201 for an unwarped triangle.

NOTE

It is not necessary to perform step 5 with great care at the initial higher amplitudes.

- Repeat steps 4 and 5 until the triangle is down to about 50 mV p-p.

NOTE

It is normal for the 50 mV triangle to be fuzzy and somewhat distorted, but the potentiometer should be set for optimum linearity. Increase oscilloscope sensitivity as necessary to observe the signal.

- Readjust R231 for 0 V $\pm$ 10 mV.
- Set AMPLITUDE dial to 0 and adjust R9 on switch board to null waveform at 50 Ω OUT.
- Turn AMPLITUDE dial to either 10 and adjust triangle from 50 Ω OUT (loaded with 50 Ω) for $\pm$ 5 V peak $\pm$ 25 mV with R228 (amplitude) and R205 (balance). *card 4 Block 27*
- Turn AMPLITUDE dial to other 10 and check to assure waveform is within $\pm$ 5 V peak $\pm$ 50 mV. If not, reset R228 and R205 for optimum amplitude and balance at both 10s. *card 4 Block 28*
- Set FUNCTION selector to $\sim$ and AMPLITUDE dial to either 10.
- Connect the test equipment as shown in Figure 4-1.
- Adjust R195 for minimum sine distortion at both 10s of the AMPLITUDE dial.
- Set FUNCTION selector to $\sim$ and repeat steps 10 through 13 for optimum amplitude and balance and minimum sine distortion.

4.10 Square Wave Amplitude Adjustment

- Set FUNCTION selector to $\square$ and set AMPLITUDE dial to either 10.
- Adjust the square wave amplitude from 50 Ω OUT (loaded with 50 Ω) for $\pm$ 5 V $\pm$ 25 mV using R167 and R169. *card 4 Block 28*
- Turn dial to other 10 and check that waveform is within $\pm$ 5 V $\pm$ 50 mV. If not, reset R167 and R169 for optimum amplitude at both 10s. *card 4 Block 30*

4.11 Sine Wave Amplitude and Balance Adjustment

- Set FUNCTION selector to $\sim$ and AMPLITUDE dial to either 10.
- Adjust the sine wave amplitude from 50 Ω OUT (loaded with 50 Ω) for $\pm$ 5 V $\pm$ 25 mV using R159 (amplitude) and R141 (balance). *card 4 Block 31*
- Turn AMPLITUDE dial to other 10 and check to assure the waveform is within $\pm$ 5 V $\pm$ 50 mV. If not, reset R159 and R141 for optimum amplitude at both 10s. *card 4 Block 32*

4.12 AM LIMITS Adjustment

- Set FUNCTION selector to $\square$, MODE selector to TRIG, AM LIMITS control fully cw, AUX MODE selector to CONT, AUX FUNCTION to $\square$, and depress AM push button.
- Adjust R5 on switch board for square wave amplitude at 50 Ω OUT (loaded with 50 Ω) for 10 V p-p $\pm$ 50 mV. *card 4 Block 33*

4.13 Trigger Base Line Adjustment

- Set AUX MODE selector to TRIG and FUNCTION selector to $\sim$; release AM push button and turn AM LIMITS control fully cw.
- Adjust R80 for 0 V $\pm$ 5 mV at 50 Ω OUT (loaded with 50 Ω). *card 4 Block 34*
- Turn AMPLITUDE dial to other 10 and split the error from 0 V by readjusting R80.
- Set FREQUENCY dial to 1/100 of full scale and adjust R257 to set base line to 0 V $\pm$ error accrued in step 3.

5. Check to assure base line remains within ± 100 mV at all FREQUENCY dial settings from full scale to 1/100 of full scale.

4.14 GCV OUT Adjustment

1. Set MODE selector to CONT and FREQUENCY dial to 10.
2. Adjust R52 to obtain +5 Vdc ± 10 mV at GCV OUT connector. *Cond 1 Block 35*

4.15 High Frequency Response Adjustment

1. Set FREQ Hz to X 0.1M, FREQUENCY dial to 10 and FUNCTION selector to $\square$.
2. Adjust C85 for optimum square wave, without peaking, from 5 V p-p to 10 V p-p output amplitude. *Cond 1 Block 36*
3. Set FUNCTION selector to $\sim$, FREQUENCY dial to 10 and FREQ Hz to X 1M.
4. Adjust C26 to obtain 10 V p-p output amplitude.

4.16 CORRECTIVE MAINTENANCE

This portion of the manual presents a systematic approach to trouble-shooting. It is composed of two parts. Part one (see 4.5.1) is a quick guide for locating the area of the problem. Part two (see 4.5.2) contains 10 tables which are given as detailed supplements to part one.

The following abbreviations are used:

Symbol	Meaning
B	Base (transistor)
C	Collector (transistor)
E	Emitter (transistor)
G	Gate (FET)
S	Source (FET)
D	Drain (FET)
CR	Diode
Qn	Transistor number (n)
V _{GS}	Voltage between gate and source (FET)
Q	Output terminal (flip-flop)
$\overline{Q}$	Inverting output terminal (flip-flop)

4.5.1 Quick Trouble-Shooting Guide

Symptom	Corrective Action
Blown Line Fuse	Replace fuse. If it blows again, check the following: 1. Solder bridge or wire connection shorted. 2. Q39 and/or Q40 shorted in output amplifier. 3. Bypass capacitors for power supply are shorted. 4. Follow Table 4-2 to locate the short in a particular power supply.
+15 V Power Supply Malfunctions	1. Voltage low: a. Transformer output low. b. Extra current loading. Check for overheated and defective component in the circuit. c. Q4 or Q3 is shorted. d. Q2 is open. e. CR10 is shorted. f. IC1 is defective. 2. Voltage high: a. Power transistor Q1 or Q2 is shorted. b. Q4 is open. c. IC1 is defective. 3. High frequency oscillation (MHz): a. C4 or C5 at IC1 is defective. b. One of the semiconductors in another part of the circuit is oscillating. Locate by using hand to touch the most sensitive area of the circuit boards. 4. Large 60 cycle noise: defective filter capacitor, C1 or C9.
Other Power Supply Malfunctions	1. Follow Table 4-2 to locate the problem to a particular power supply. 2. Use similar procedure for trouble-shooting as in the +15 V power supply malfunctions.

Quick Trouble-Shooting Guide (Continued)

Symptom	Corrective Action
MAIN GENERATOR	
No Output Signals	1. If no Δ signal is present at output of Δ amplifier (G of Q6), follow Table 4-3 for trouble-shooting. 2. Check for faulty wiring to and from FUNCTION selector (switch board). 3. If no signal is present at R238 and R241 with the Δ FUNCTION selected, follow Table 4-10 to check out the X-Y multiplier and Table 4-5 to check out the output amplifier.
No Δ , $\square$ or SYNC Output	Follow Table 4-10 to check out the corresponding circuit.
$\square$ Rise/Fall Time Abnormally Slow	1. Malfunctioning $\square$ amplifier. 2. One of the capacitors in the output amplifier is open. 3. C85 (output amplifier) is not calibrated.
Frequency Accuracy Out of Specification	1. Check frequency calibration. 2. Check for defective C34, C45 to C52, CR14 and/or CR16 on main board, if problem is in X 10K to X 1 MHz ranges. 3. Check capacitance multiplier, if problem appears in X 0.001 to X 1 ranges only, using Table 4-6. 4. Check VCG for frequency linearity problem in all ranges, using Table 4-4.
High Frequency Output Has Abnormal Ringing	Defective capacitor in output amplifier.
High Sine Distortion at Low Frequency	1. Δ amplitude and time symmetry calibration is off. 2. Defective sine converter. 3. Sine converter or X-Y multiplier calibration is off.
High Sine Distortion at High Frequency	1. $\square$ also looks bad, if problem is in the output amplifier. 2. Defective capacitors C34 and C45 to C52 in Δ amplifier. 3. Defective C29 to C36 in sine amplifier. 4. Defective sine converter.
Unsymmetrical Δ	Follow Table 4-4 to check out VCG circuit.
Amplitude Accuracy Out of Specification	1. Check calibration. 2. Check X-Y multiplier, using Table 4-10.
TRIG and GATE MODE Inoperative	1. Check trigger and gated control switches. 2. Check for correct signals in the trigger circuit, using Table 4-9.
AUXILIARY GENERATOR	
No Aux Output Signal	1. If no Δ is present at junction of R33 and R34, use Table 4-7. 2. If Δ signal is present at junction of R33 and R34, check FUNCTION switch and wiring.
No Aux Δ Output	1. If no Δ signal is present at pin 4 of IC5 (± 125 mV), check for defective sine converter (A1).

Quick Trouble-Shooting Guide (Continued)

Symptom	Corrective Action
No Aux $\sim$ Output (Cont)	- If no $\sim$ signal is present at pin 12 of IC5 (± 2.5 V peak), check for defective IC5 and associated circuitry. - If $\sim$ signal is present at pin 12 of IC5, check FUNCTION switch and wiring.
No Aux $\square$ Output	- If no $\square$ signal is present at the emitter of Q22, check for defective IC7, Q20 – Q22 and associated circuitry. - If $\square$ signal is present at the emitter of Q22, check FUNCTION switch and wiring.
TRIG and GATE MODE Inoperative	- Check trigger and gated control switches. - Use Table 4-7.

4.5.2 Trouble-Shooting Guide Tables

4.5.2.1 POWER SUPPLIES

Use Table 4-2 to localize the problem to a particular power supply and associated loading circuitry. In some cases, it is necessary to turn on the power of the unit no more than one

or two seconds at a time to prevent it from blowing fuses and further damage circuit components.

NOTE

Be sure to use the correct ground in the following voltage checks.

Table 4-2. POWER SUPPLIES




Table 4-3. TRIANGLE AMPLIFIER, COMPARATOR, AND HYSTERESIS SWITCH




Table 4-3. TRIANGLE AMPLIFIER, COMPARATOR, AND HYSTERESIS SWITCH (Continued)




Table 4-4. VCG, CURRENT SOURCE, AND TRIG BASE LINE CORRECTOR




Table 4-5. OUTPUT AMPLIFIER



Table 4-6. CAPACITANCE MULTIPLIER




Table 4-7. AUXILIARY GENERATOR





Table 4-8. AM LIMITS AND FM LIMITS CONTROLS



4.5.2.2 TRIGGER AND GATED LOGIC TIMING

For trouble-shooting the trigger, set the generator to the GATE MODE. (Refer to Table 4-9.) Draw a vertical line on the timing diagram along t_1 or t_2 , depending on whether

the TRIG IN signal is low or high, and check for correct voltage levels according to the timing diagram.

After the GATE MODE has been checked, the TRIG MODE can be checked in the same way, but concentrated in the Q55, Q56 area.

Table 4-9. TRIGGER AND GATED LOGIC TIMING DIAGRAM




Table 4-10. KEY SIGNAL AND VOLTAGE

AMPLIFIER, COMPARATOR AND HYSTERESIS SWITCH

Test Point	Typical Voltage
G of Q6	2.5 V p-p Δ , 0 Vdc offset
G of Q7	2.5 V p-p Δ , 0 Vdc offset
E of Q10	2.5 V p-p Δ , $\approx$ +7 Vdc offset
Pins 1 and 4 of IC10	See Table 4-11.
Pins 2 and 8	-3 V
Pins 3 and 9	-3.7 V
E of Q16	+6.8 Vdc
B of Q16 and Q20	See Table 4-11.
E of Q15 and Q21	See Table 4-11.
E of Q17	+10 V
R118 and R125 junction	-3 V
S of Q13	+10 V to +15 V, dependent on frequency setting
S of Q14	-10 V to -15 V, dependent on frequency setting

X-Y MULTIPLIER

Test Point	Typical Voltage
R196	Selected signal (Δ , Δ , $\square$)
Pin 6 of IC11	+11 volts to -11 volts, dependent upon AMPLITUDE dial setting
Pin 6 of IC12	+2.5 volts to -2.5 volts, dependent upon AMPLITUDE dial setting
Pins 3 and 13 of IC13	-10.5 V
Pin 1 of IC13	Selected signal output +4 Vdc offset
E of Q32 and E of Q33	Selected signal output +13 Vdc offset
Pin 14 of IC13	$\approx$ 7 Vdc

CONVERTER AND AMPLIFIER

Test Point	Typical Voltage
Pin 2 of A1	See Table 4-11.
Pin 4 of A1	+14 V
Pin 1 of A1	-14 V
Pin 5 of A1	250 mV p-p Δ , 0 Vdc offset
R155 and R156 junction	2.5 V p-p Δ , 0 Vdc offset
B of Q24 and Q25	+8 V

SYNC AND SQUARE AMPLIFIER

Test Point	Typical Voltage
R165 and R166 junction	$\pm$ 2 V $\square$
CR23 cathode	$\pm$ 1.25 V $\square$
R175 and R176 junction	$\pm$ 1.25 V $\square$

OUTPUT AMPLIFIER

Test Point	Typical Voltage
B of Q35	+19 Vdc
E of Q37	+19 Vdc
B of Q36	-19 Vdc
E of Q38	-19 Vdc
R238 and R241 junction	Main output, $\pm$ 10 V maximum

VCG AMPLIFIER AND TRIGGER BASELINE COMPENSATION

Test Point	Typical Voltage
Pin 6 of IC1	0 V to +5 V*
R46 and R49 junction	0 V to -5 V*
S of Q1	0 V
Pins 2 and 3 of IC3	+10 V to +15 V*
S of Q2	0 V to -5 V*
Pins 2 and 3 of IC7	-10 V to -15 V*
V _{GS} of Q46	V _{G1,S1} = V _{G2,S2}
R258 and R260	Voltage across both are equal
E of Q48	+2.2 V
R262	Voltage across R262 and R64 are equal

*Voltage is dependent on a FREQUENCY dial setting.

CAPACITANCE MULTIPLIER*

Test Point	Typical Voltage
G1 and G2 of Q3	$\pm$ 1.25 V Δ
Pin 6 of IC9	$\square$, amplitude dependent on frequency setting
Pins 2 and 3 of IC4	$\pm$ 1.25 V Δ
Pin 6 of IC4	$\pm$ 7.5 V Δ

*The information applies if the frequency range is at X 1 Hz.

**AUXILIARY GENERATOR
(CONT MODE)**

KEY SIGNALS AND VOLTAGES

Test Point	Typical Voltage
Pin 6 of IC2	0 V to +5 Vdc dependent on FREQUENCY dial setting
Pin 6 of IC1	0 Vdc
E of Q3	0 V to +5 Vdc step source dependent on FREQUENCY dial setting (see Figure 3-7 for correct step source).
Pin 13 of IC4	+1.25 Vdc
Pin 9 of IC4	-1.25 Vdc
C of Q6, pin 11 of IC4, pin 3 of IC1 and pin 3 of IC7	1 V p-p logic level, ≈ -3 Vdc offset 180° out-of-phase with logic level of C of Q7
C of Q7, pin 3 of IC4, pin 11 of IC1 and pin 11 of IC7	1 V p-p logic level, ≈ -3 Vdc offset 180° out-of-phase with logic level of C of Q6
Pin 3 of IC6	-7.5 Vdc
Pin 11 of IC6	-6.5 Vdc
R96 and AMP pin 7 junction	+15 Vdc
Pin 2 of IC7	+2.5 Vdc
Pin 6 of IC7	-2.5 Vdc
Pin 4 of IC5	± 125 mV $\sim$
Pin 12 of IC5	± 2.5 V $\sim$

$\sim$ $\sim$ $\sqcap$ **FUNCTIONS ONLY**

Test Point	Typical Voltage
Pin 2 of IC3, R20 and AMP pin 27 junction, and pin 6 of IC6	$\approx +2.5$ V
R33 and R34 junction	± 2.5 V $\sim$
E of Q22 and AUX OUT connector	± 2.5 V $\sqcap$


$\checkmark$ **FUNCTION ONLY**

Test Point	Typical Voltage
Pin 2 of IC3, R20 and AMP pin 27 junction, and pin 6 of IC6	$\approx +0.1$ V
R33 and R34 junction	± 2.5 V $\checkmark$
E of Q22 and AUX OUT connector	± 2.5 V $\sqcap$

$\sim$ **FUNCTION ONLY**

Test Point	Typical Voltage
Pin 2 of IC3, R20 and AMP pin 27 junction, and pin 6 of IC6	+4.9 V
R33 and R34 junction	± 2.5 V $\sim$
E of Q22 and AUX OUT connector	± 2.5 V $\sqcap$

Table 4-11. KEY WAVEFORMS





5

SECTION

DIAGRAMS ADDENDUMS AND PARTS LISTS

5.1 DRAWINGS

The following assembly drawings (with parts lists) and schematics are in the arrangement shown below.

5.2 ORDERING PARTS

When ordering spare parts, please specify part number, circuit reference, board, serial number of unit and, if applicable, the function performed.

5.3 ADDENDA

Under Wavetek's product improvement program, the latest electronic designs and circuits are incorporated into each Wavetek instrument as quickly as development and testing permit. Because of the time needed to compose and print instruction manuals, it is not always possible to include the most recent changes in the initial printing. Whenever this occurs, addendum pages are prepared to summarize the changes made and are inserted immediately inside the rear cover. If no such pages exist, the manual is correct as printed.

CROSS REFERENCE FOR DRAWING NUMBERS

Drawings	Old Number	New Number	Drawings	Old Number	New Number
Chassis Assy	146-020	0102-00-0296	Rear Panel Assy	146-014	0102-00-0330
Chassis Schematic	146-220	0004-00-0037	Rear Panel Parts List	*	1101-00-0071
Chassis Parts List	*	1101-00-0037			
Main Board Assy	146-030	0101-00-0056	Trigger Switch Assy	146-005	1202-00-0015
Main Board Schematic	146-230	0103-00-0056	Trigger Switch Parts List	*	*
Main Board Parts List	*	1100-00-0056	Freq Hz Switch Assy	146-006	1202-00-0016
Power Supply Assy	146-011	0101-00-0057	Freq Hz Switch Parts List	*	*
Power Supply Schematic	146-211	0103-00-0057	Attenuator Switch Assy	146-007	1202-00-0017
Power Supply Parts List	*	1100-00-0057	Attenuator Switch Parts List	*	*
Movement Assy	146-002	0102-00-0329			
Left Movement Parts List	*	1101-00-0070	D/C Offset Switch Assy	146-008	1202-00-0018
Right Movement Parts List	*	1101-00-0091	D/C Offset Switch Parts List	*	*
Switch Board Assy	146-032	0101-00-0058			
Switch Board Schematic	146-232	0103-00-0058	Freq/Period Switch Assy	146-009	1202-00-0019
Switch Board Parts List	*	1100-00-0058	Freq/Period Switch Parts List	*	*
Auxiliary Board Assy	146-033	0101-00-0059			
Auxiliary Board Schematic	146-233	0103-00-0059	Patch Block Assy	154-024	1205-00-0489
Auxiliary Board Parts List	*	1100-00-0059	Patch Block Parts List	*	*


*Same as assembly number

5.4 RECOMMENDED SPARE PARTS LIST

Information is provided to maintain the instrument on a board or component level. Price and delivery information should be obtained from the Wavetek representative in your area or directly from the factory.

DESCRIPTION	MFG	PART NO.	QTY
BOARD LEVEL			
MAIN BOARD	WAVETEK	146-030	1
POWER SUPPLY BOARD	WAVETEK	146-011	1
SWITCH BOARD	WAVETEK	146-032	1
AUXILIARY GENERATOR BOARD	WAVETEK	146-033	1
COMPONENT LEVEL			
DIODE	SEMTECH	SCE-1	2
DIODE	FAIRCHILD	FD777	1
DIODE	FAIRCHILD	F06866	2
DIODE TUNNEL	GE	1N3716	1
DIODE ZENER	WAVETEK	1N4581	2
FUSE 1/4A 230 V	LITTELFUSE	313-250	1
FUSE 1/4A 115 V	LITTELFUSE	313-500	1
★ INTEGRATED CKT — 13	FAIRCHILD	μA709C	2
★ INTEGRATED CKT — 14	CA3054	CA3054	1
★ INTEGRATED CKT — 15	RCA	CA3030	1
INTEGRATED CKT	RCA	CA3028A	1
INTEGRATED CKT	RCA	CA3049	1
INTEGRATED CKT	FAIRCHILD	μA795	1
INTEGRATED CKT	NATIONAL	LM-301AN	1
INTEGRATED CKT	MOTOROLA	MC3050P	1
LAMP	MURA	L 28/40	1
SINE MODULE	WAVETEK	B142-011	1
TRANSISTOR	MOTOROLA	2N2905A	1
TRANSISTOR	FAIRCHILD	2N3638	2
TRANSISTOR	FAIRCHILD	2N3640	1
TRANSISTOR	FAIRCHILD	2N3642	2
TRANSISTOR	FAIRCHILD	2N3646	2
TRANSISTOR	MOTOROLA	2N3903	1
TRANSISTOR	MOTOROLA	2N3905	1
TRANSISTOR	FAIRCHILD	2N4047	1
TRANSISTOR	FAIRCHILD	2N4248	1
TRANSISTOR	FAIRCHILD	2N5139	1
TRANSISTOR	MOTOROLA	2N5160	1
★ TRANSISTOR — 52	MOTOROLA	2N3563	2
★ TRANSISTOR — 53	MOTOROLA	2N5485	2
★ TRANSISTOR — 54	MOTOROLA	2N5485	1
★ TRANSISTOR — 55	MOTOROLA	2N5462	1
★ TRANSISTOR — 56	MOTOROLA	2N2219A	1
TRANSISTOR	MOTOROLA	MPS L08	1
TRANSISTOR	TEXAS INST	TIP 29	1
TRANSISTOR	TEXAS INST	TIP 30	1
TRANSISTOR	TECH PROD	TP 308	1

★ Denotes special selected parts and should be ordered from Wavetek.




A SEN 935 A 1 1 1			
REV	ECN	BY	DATE
XXX	1	010	
XX	1	030	
ANDLER	1	030	
SCALE 1/1 A	9	SCHEMATIC	DATE
MATERIAL	N/A	TITLE	INSTRUMENT SCHEMATIC
FINISH	146	DRG NO	0004-00-0037
THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION AND DESIGN RIGHTS BELONGING TO WAVETEK AND MAY NOT BE REPRODUCED FOR ANY REASON EXCEPT CALIBRATION OPERATION AND MAINTENANCE WITHOUT WRITTEN AUTHORIZATION			

REFERENCE DESIGNATORS	PART DESCRIPTION	ORIG=MPGN+PART=NO	MPGN	WAVETEK NO.	WTF/P1
NONE	ABST DRWG, CHASSIS	0102-00-0296	NVTR	0102-00-0296	1
26	DIAL ABST	130-333-7	NVTR	1301-00-0011	1
27	DIAL ABST	130-333-8	NVTR	1301-00-0012	1
25	DIAL ABST	130-333-9	NVTR	1301-00-0013	1
NONE	COVER ABST	140-305H ABST	NVTR	1201-00-0044	1
14	DAN, SUPP	140-305	NVTR	1400-00-2513	1
27	SHIELD, RELATIGN	140-337	NVTR	1400-00-2555	1
26	DIAL, BR	140-349	NVTR	1400-00-2563	1
21	PANEL, DUB	140-363	NVTR	1400-00-2653	1
15	PLATE, DUB	140-364	NVTR	1400-00-2653	1
23	PANEL, FT	140-386	NVTR	1400-00-2680	1
17	DAN, SUPP	140-371	NVTR	1400-00-2693	1
24	BLUCK, SPACER	140-372	NVTR	1400-00-2703	1
31	LENS, INDICATOR	150-311	NVTR	1400-00-2690	1
41	SPACE	157-304	NVTR	1400-00-3003	1
23-24	MODULE, MFA	167-304	NVTR	1400-00-2564	1
23	LLAMP	167-310	NVTR	1400-00-3590	1
WAVETEK PARTS LIST		TITLE STD CHASSIS	ASSEMBLY NO. 1101-00-0037		REV 1
		PAGE 1			


REFERENCE DESIGNATORS	PART DESCRIPTION	ORIG=MPGN+PART=NO	MPGN	WAVETEK NO.	WTF/P
W1	SWITCH ABST PS	157-422	NVTR	1503-00-0011	1
93	BUTTON	157-503-HSD	NVTR	1503-00-0044	1
NONE	PAW LURE	0-7788-CUR-6T	WALSH	1803-00-0005	1

REFERENCE DESIGNATORS	PART DESCRIPTION	ORIG=MPGN+PART=NO	MPGN	WAVETEK NO.	WTF/P1
40	TRIM, PANEL	167-303	NVTR	1400-00-3614	1
41	TRIM, PANEL	167-304	NVTR	1400-00-3614	1
73	ENCL LURE	167-304	NVTR	1400-00-3614	1
71	BULDER LUG	167-304	NVTR	1400-00-3614	1
51	STU ANUB	167-304	NVTR	1400-00-3614	1
44	CURA KNUB BBT	167-304	NVTR	1400-00-3614	1
45	BUR-INW HT LINE	167-304	NVTR	1400-00-3614	1
46	SPACER	167-304	NVTR	1400-00-3614	1
47	STANDOFF	167-304	NVTR	1400-00-3614	1
48	STANDOFF	167-304	NVTR	1400-00-3614	1
49	STANDOFF	167-304	NVTR	1400-00-3614	1
50	STANDOFF	167-304	NVTR	1400-00-3614	1
51	STANDOFF	167-304	NVTR	1400-00-3614	1
52	STANDOFF	167-304	NVTR	1400-00-3614	1
53	STANDOFF	167-304	NVTR	1400-00-3614	1
54	STANDOFF	167-304	NVTR	1400-00-3614	1
55	STANDOFF	167-304	NVTR	1400-00-3614	1
56	STANDOFF	167-304	NVTR	1400-00-3614	1
57	STANDOFF	167-304	NVTR	1400-00-3614	1
58	STANDOFF	167-304	NVTR	1400-00-3614	1
59	STANDOFF	167-304	NVTR	1400-00-3614	1
60	STANDOFF	167-304	NVTR	1400-00-3614	1
61	STANDOFF	167-304	NVTR	1400-00-3614	1
62	STANDOFF	167-304	NVTR	1400-00-3614	1
63	STANDOFF	167-304	NVTR	1400-00-3614	1
64	STANDOFF	167-304	NVTR	1400-00-3614	1
65	STANDOFF	167-304	NVTR	1400-00-3614	1
66	STANDOFF	167-304	NVTR	1400-00-3614	1
67	STANDOFF	167-304	NVTR	1400-00-3614	1
68	STANDOFF	167-304	NVTR	1400-00-3614	1
69	STANDOFF	167-304	NVTR	1400-00-3614	1
70	STANDOFF	167-304	NVTR	1400-00-3614	1
71	STANDOFF	167-304	NVTR	1400-00-3614	1
72	STANDOFF	167-304	NVTR	1400-00-3614	1
73	STANDOFF	167-304	NVTR	1400-00-3614	1
74	STANDOFF	167-304	NVTR	1400-00-3614	1
75	STANDOFF	167-304	NVTR	1400-00-3614	1
76	STANDOFF	167-304	NVTR	1400-00-3614	1
77	STANDOFF	167-304	NVTR	1400-00-3614	1
78	STANDOFF	167-304	NVTR	1400-00-3614	1
79	STANDOFF	167-304	NVTR	1400-00-3614	1
80	STANDOFF	167-304	NVTR	1400-00-3614	1
81	STANDOFF	167-304	NVTR	1400-00-3614	1
82	STANDOFF	167-304	NVTR	1400-00-3614	1
83	STANDOFF	167-304	NVTR	1400-00-3614	1
84	STANDOFF	167-304	NVTR	1400-00-3614	1
85	STANDOFF	167-304	NVTR	1400-00-3614	1
86	STANDOFF	167-304	NVTR	1400-00-3614	1
87	STANDOFF	167-304	NVTR	1400-00-3614	1
88	STANDOFF	167-304	NVTR	1400-00-3614	1
89	STANDOFF	167-304	NVTR	1400-00-3614	1
90	STANDOFF	167-304	NVTR	1400-00-3614	1
91	STANDOFF	167-304	NVTR	1400-00-3614	1
92	STANDOFF	167-304	NVTR	1400-00-3614	1
93	STANDOFF	167-304	NVTR	1400-00-3614	1
94	STANDOFF	167-304	NVTR	1400-00-3614	1
95	STANDOFF	167-304	NVTR	1400-00-3614	1
96	STANDOFF	167-304	NVTR	1400-00-3614	1
97	STANDOFF	167-304	NVTR	1400-00-3614	1
98	STANDOFF	167-304	NVTR	1400-00-3614	1
99	STANDOFF	167-304	NVTR	1400-00-3614	1
100	STANDOFF	167-304	NVTR	1400-00-3614	1
WAVETEK PARTS LIST		TITLE STD CHASSIS	ASSEMBLY NO. 1101-00-0037		REV 1
			PAGE 2		





REMOVE ALL BURRS AND BREAK SHARP EDGES		DATE	WAVETEK SAN DIEGO, CALIFORNIA	
MATERIAL	PROVIDE	TITLE	STD CHASSIS	
	RELEASE APPROV	TO: FRANK ON-LEE OTHER: FRANK ON-LEE XXX-XXX-XXXX DATE: 11/01/00		
FABRI WAVETEK PROCESS	DO NOT SCALE DIMS	MODEL NO	0000 146-000	REV 1
	SCALE	SCALE	1101-00-0037	1/1
CUST 23328		SHEET	OF	



+5V POWER SUPPLY



BASELINE CORRECTOR



DESIGNATORS NOT USED
R26B C105, C107

BROOKMAN 3/14/75
SCHEMATIC,
MAIN BOARD
146 0103-00-00506 G

THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION AND DESIGN RIGHTS BELONGING TO WAVETEK AND MAY NOT BE REPRODUCED FOR ANY REASON EXCEPT CALIBRATION, OPERATION AND MAINTENANCE WITHOUT WRITTEN AUTHORIZATION

REV ECH BP DATE APP

REFERENCE DESIGNATORS	PART DESCRIPTION	DRG=MFCH=PART=ND	WAVE	WAVETEK NO.	QTY/PT
NONE	ASSY DRNG MAIN	0101-00-0056	NVIA	0101-00-0056	1
NONE	SCHEMATIC MAIN	0101-00-0056	NVIA	0101-00-0056	1
A1	SWH MOD	142-111	NVIA	1200-00-0002	1
SW1	FWH SW ASSY	144-006	NVIA	1202-00-0016	1
SW2	D/C OFFSET SW ASSY	148-008	NVIA	1202-00-0018	1
IC17	PATCH BLOCK	150-028	NVIA	1205-00-0040	1
NONE	SPACE	REAR	NVIA	1400-00-0065	1
CRV	CAP,CEM,50PF,1KV	00-600	CHL	1500-00-5011	1
CR1 CR2	CAP,CEM,100PF,1KV	00-100	CHL	1500-01-0011	2
CR4 CR7 CR8	CAP,CEM,300PF,1KV	00-100	CHL	1500-01-0211	3
CR9 CR10 CR11 CR12 CR13 CR14 CR15 CR16 CR17 CR18 CR19 CR20 CR21 CR22 CR23 CR24 CR25 CR26 CR27 CR28 CR29 CR30 CR31 CR32 CR33 CR34 CR35 CR36 CR37 CR38 CR39 CR40 CR41 CR42 CR43 CR44 CR45 CR46 CR47 CR48 CR49 CR50 CR51 CR52 CR53 CR54 CR55 CR56 CR57 CR58 CR59 CR60 CR61 CR62 CR63 CR64 CR65 CR66 CR67 CR68 CR69 CR70 CR71 CR72 CR73 CR74 CR75 CR76 CR77 CR78 CR79 CR80 CR81 CR82 CR83 CR84 CR85 CR86 CR87 CR88 CR89 CR90 CR91 CR92 CR93 CR94 CR95 CR96 CR97 CR98 CR99 CR100	CAP,CEM,100PF,5KV	CR-175	CHL	1500-01-0310	20
CR4 CR7	CAP,CEM,100PF,5KV	CR-175	CHL	1500-01-0310	2
CR10 CR11 CR12 CR13 CR14 CR15 CR16 CR17 CR18 CR19 CR20 CR21 CR22 CR23 CR24 CR25 CR26 CR27 CR28 CR29 CR30 CR31 CR32 CR33 CR34 CR35 CR36 CR37 CR38 CR39 CR40 CR41 CR42 CR43 CR44 CR45 CR46 CR47 CR48 CR49 CR50 CR51 CR52 CR53 CR54 CR55 CR56 CR57 CR58 CR59 CR60 CR61 CR62 CR63 CR64 CR65 CR66 CR67 CR68 CR69 CR70 CR71 CR72 CR73 CR74 CR75 CR76 CR77 CR78 CR79 CR80 CR81 CR82 CR83 CR84 CR85 CR86 CR87 CR88 CR89 CR90 CR91 CR92 CR93 CR94 CR95 CR96 CR97 CR98 CR99 CR100	CAP,CEM,100PF,5KV	CR-175	CHL	1500-01-0310	20

REFERENCE DESIGNATORS	PART DESCRIPTION	DRG=MFCH=PART=ND	WAVE	WAVETEK NO.	QTY/PT
C99	CAP,SELECT,100PF,1KV	500010701007	SPHAG	1500-31-0101	1
C113	CAP,SELECT,250PF,1KV	500025701007	SPHAG	1500-32-0101	1
C81	CAP,POLY,01MF,100V	PA20-100	ELCUM	1500-41-0104	1
C40	CAP,POLY,1MF,100V	PA20-100	ELCUM	1500-41-0104	1
C94	CAP,POLY,1MF,100V	21-01C-100F	1M	1500-41-0104	1
C10 C11 C17 C18	CAP,POLY,5MF,100V	C1A0N	PLAC	1500-44-0104	4
C26 C31 C42 C45	VARI,7-50PF,250V	75-7140-A2 7/15 PF	1P10	1500-53-0100	4
C101 C73	CAP,TANT,22MF,15V	14002204001007	SPRAG	1500-72-2401	2
C74 C87 C92 C96	CAP,TANT,5,6MF,15V	1400451001007	SPHAG	1500-75-0102	4
NONE	MAIN	140-130	NVIA	1700-00-0056	1
NONE	SKT,IC,10PIN	14-01M	ELNCH	2100-01-0111	1
NONE	TERM	2400-1	1-5FCH	2100-05-0104	6
NONE	TERM	2400-1	1-5FCH	2100-05-0104	6
NONE	CUNN	60500-A	AMP	2100-25-0017	0
NONE	PH,PALE	611P-2	AMP	2100-05-0020	4
NONE	HEAT SINK	HP-107	LAPE	2600-11-0001	2
NONE	TRANSPAD	1012R	HP105	2800-11-0001	2

REFERENCE DESIGNATORS	PART DESCRIPTION	DRG=MFCH=PART=ND	WAVE	WAVETEK NO.	QTY/PT
R265	RES,C,1/4W,100,10K	HC12CF-103	NVIA	4700-05-1002	1
R110 R111 R113 R124 R212 R221 R223 R272 R274 R55 R81 R82	RES,M,1/4W,10,100	NVIA-1000F	1M	4701-05-1000	12
R170 R19 R191 R194 R58 R70 R8	RES,M,1/4W,18,10	NVIA00-1001F	1M	4701-05-1001	2
R189 R222 R256 R260 R267 R280 R281 R284 R286 R288 R290 R50 R90	RES,M,1/4W,18,10K	NVIA00-1002F	1M	4701-05-1002	13
R155 R156 R157 R160 R176 R180 R228 R237 R240 R76	RES,M,1/4W,18,10	NVIA00-1003F	1M	4701-05-1003	1
R117 R124 R77	RES,M,1/4W,18,1,1K	NVIA00-1101F	1M	4701-05-1101	3
R102 R100 R126	RES,M,1/4W,18,1,21K	NVIA00-1211F	1M	4701-05-1211	1
R700 R760	RES,M,1/4W,18,12,1K	NVIA00-1221F	1M	4701-05-1212	2
R185	RES,M,1/4W,18,12K	NVIA00-1240F	1M	4701-05-1240	1
R133	RES,M,1/4W,18,15K	NVIA00-1500F	1M	4701-05-1500	1
R10 R11 R15 R16 R170 R177 R182 R181 R207 R214 R215 R22 R261 R274 R280 R281 R5 R53 R55 R56 R60 R60 R67	RES,M,1/4W,18,1,5K	NVIA00-1511F	1M	4701-05-1501	24

WAVETEK PARTS LIST TITLE MAIN ASSEMBLY NO 1100-00-0056 REV G PAGE 1

WAVETEK PARTS LIST TITLE MAIN ASSEMBLY NO 1100-00-0056 REV G PAGE 3

WAVETEK PARTS LIST TITLE MAIN ASSEMBLY NO 1100-00-0056 REV G PAGE 5

REFERENCE DESIGNATORS	PART DESCRIPTION	DRG=MFCH=PART=ND	WAVE	WAVETEK NO.	QTY/PT
C60 C61 C68 C69	CAP,CEM,150PF,1KV	00-100	CHL	1500-01-0111	2
C54 C75	CAP,CEM,100PF,1KV	00-200	CHL	1500-02-0011	4
C100 C111 C112 C60 C105 C113 C114 C115 C116 C117 C118 C119 C120 C121 C122 C123 C124 C125 C126 C127 C128 C129 C130 C131 C132 C133 C134 C135 C136 C137 C138 C139 C140 C141 C142 C143 C144 C145 C146 C147 C148 C149 C150 C151 C152 C153 C154 C155 C156 C157 C158 C159 C160 C161 C162 C163 C164 C165 C166 C167 C168 C169 C170 C171 C172 C173 C174 C175 C176 C177 C178 C179 C180 C181 C182 C183 C184 C185 C186 C187 C188 C189 C190 C191 C192 C193 C194 C195 C196 C197 C198 C199 C200 C201 C202 C203 C204 C205 C206 C207 C208 C209 C210 C211 C212 C213 C214 C215 C216 C217 C218 C219 C220 C221 C222 C223 C224 C225 C226 C227 C228 C229 C230 C231 C232 C233 C234 C235 C236 C237 C238 C239 C240 C241 C242 C243 C244 C245 C246 C247 C248 C249 C250 C251 C252 C253 C254 C255 C256 C257 C258 C259 C260 C261 C262 C263 C264 C265 C266 C267 C268 C269 C270 C271 C272 C273 C274 C275 C276 C277 C278 C279 C280 C281 C282 C283 C284 C285 C286 C287 C288 C289 C290 C291 C292 C293 C294 C295 C296 C297 C298 C299 C300 C301 C302 C303 C304 C305 C306 C307 C308 C309 C310 C311 C312 C313 C314 C315 C316 C317 C318 C319 C320 C321 C322 C323 C324 C325 C326 C327 C328 C329 C330 C331 C332 C333 C334 C335 C336 C337 C338 C339 C340 C341 C342 C343 C344 C345 C346 C347 C348 C349 C350 C351 C352 C353 C354 C355 C356 C357 C358 C359 C360 C361 C362 C363 C364 C365 C366 C367 C368 C369 C370 C371 C372 C373 C374 C375 C376 C377 C378 C379 C380 C381 C382 C383 C384 C385 C386 C387 C388 C389 C390 C391 C392 C393 C394 C395 C396 C397 C398 C399 C400 C401 C402 C403 C404 C405 C406 C407 C408 C409 C410 C411 C412 C413 C414 C415 C416 C417 C418 C419 C420 C421 C422 C423 C424 C425 C426 C427 C428 C429 C430 C431 C432 C433 C434 C435 C436 C437 C438 C439 C440 C441 C442 C443 C444 C445 C446 C447 C448 C449 C450 C451 C452 C453 C454 C455 C456 C457 C458 C459 C460 C461 C462 C463 C464 C465 C466 C467 C468 C469 C470 C471 C472 C473 C474 C475 C476 C477 C478 C479 C480 C481 C482 C483 C484 C485 C486 C487 C488 C489 C490 C491 C492 C493 C494 C495 C496 C497 C498 C499 C500 C501 C502 C503 C504 C505 C506 C507 C508 C509 C510 C511 C512 C513 C514 C515 C516 C517 C518 C519 C520 C521 C522 C523 C524 C525 C526 C527 C528 C529 C530 C531 C532 C533 C534 C535 C536 C537 C538 C539 C540 C541 C542 C543 C544 C545 C546 C547 C548 C549 C550 C551 C552 C553 C554 C555 C556 C557 C558 C559 C560 C561 C562 C563 C564 C565 C566 C567 C568 C569 C570 C571 C572 C573 C574 C575 C576 C577 C578 C579 C580 C581 C582 C583 C584 C585 C586 C587 C588 C589 C590 C591 C592 C593 C594 C595 C596 C597 C598 C599 C600 C601 C602 C603 C604 C605 C606 C607 C608 C609 C610 C611 C612 C613 C614 C615 C616 C617 C618 C619 C620 C621 C622 C623 C624 C625 C626 C627 C628 C629 C630 C631 C632 C633 C634 C635 C636 C637 C638 C639 C640 C641 C642 C643 C644 C645 C646 C647 C648 C649 C650 C651 C652 C653 C654 C655 C656 C657 C658 C659 C660 C661 C662 C663 C664 C665 C666 C667 C668 C669 C670 C671 C672 C673 C674 C675 C676 C677 C678 C679 C680 C681 C682 C683 C684 C685 C686 C687 C688 C689 C690 C691 C692 C693 C694 C695 C696 C697 C698 C699 C700 C701 C702 C703 C704 C705 C706 C707 C708 C709 C710 C711 C712 C713 C714 C715 C716 C717 C718 C719 C720 C721 C722 C723 C724 C725 C726 C727 C728 C729 C730 C731 C732 C733 C734 C735 C736 C737 C738 C739 C740 C741 C742 C743 C744 C745 C746 C747 C748 C749 C750 C751 C752 C753 C754 C755 C756 C757 C758 C759 C760 C761 C762 C763 C764 C765 C766 C767 C768 C769 C770 C771 C772 C773 C774 C775 C776 C777 C778 C779 C780 C781 C782 C783 C784 C785 C786 C787 C788 C789 C790 C791 C792 C793 C794 C795 C796 C797 C798 C799 C800 C801 C802 C803 C804 C805 C806 C807 C808 C809 C810 C811 C812 C813 C814 C815 C816 C817 C818 C819 C820 C821 C822 C823 C824 C825 C826 C827 C828 C829 C830 C831 C832 C833 C834 C835 C836 C837 C838 C839 C840 C841 C842 C843 C844 C845 C846 C847 C848 C849 C850 C851 C852 C853 C854 C855 C856 C857 C858 C859 C860 C861 C862 C863 C864 C865 C866 C867 C868 C869 C870 C871 C872 C873 C874 C875 C876 C877 C878 C879 C880 C881 C882 C883 C884 C885 C886 C887 C888 C889 C890 C891 C892 C893 C894 C895 C896 C897 C898 C899 C900 C901 C902 C903 C904 C905 C906 C907 C908 C909 C910 C911 C912 C913 C914 C915 C916 C917 C918 C919 C920 C921 C922 C923 C924 C925 C926 C927 C928 C929 C930 C931 C932 C933 C934 C935 C936 C937 C938 C939 C940 C941 C942 C943 C944 C945 C946 C947 C948 C949 C950 C951 C952 C953 C954 C955 C956 C957 C958 C959 C960 C961 C962 C963 C964 C965 C966 C967 C968 C969 C970 C971 C972 C973 C974 C975 C976 C977 C978 C979 C980 C981 C982 C983 C984 C985 C986 C987 C988 C989 C990 C991 C992 C993 C994 C995 C996 C997 C998 C999 C1000	CAP,CEM,220PF,1KV	00-200	CHL	1500-02-0111	12
C17	CAP,CEM,822P,1KV	00-222 1045 140H	CHL	1500-02-2201	1
C60 C70	CAP,CEM,100PF,1KV	00-200	CHL	1500-02-0111	2
C130	CAP,CEM,82PF,1KV	00-675	CHL	1500-04-7011	1
C27 C62 C70	CAP,CEM,470PF,1KV	00-675	CHL	1500-04-7111	3
C1 C10 C12 C14 C16 C21 C23 C25 C7 C71	CAP,CEM,100MF,5KV	CR-412	CHL	1500-05-0210	15
C57 C58	CAP,CEM,80PF,1KV	00-600	CHL	1500-06-0001	2
CR8 CR9 C59	CAP,CEM,100PF,500V	00-1512	CHL	1500-11-0110	3
C10	CAP,CEM,20PF,500V	00-1520	CHL	1500-12-0000	1
C32	CAP,CEM,100PF,500V	00-1502	CHL	1500-13-0000	1
C40	CAP,CEM,80PF,500V	00-1502	CHL	1500-14-0000	1
C43	CAP,CEM,820PF,500V	00-1502	CHL	1500-16-0101	1
C60 C51	CAP,CEM,81PF,500V	00-1502	CHL	1500-19-0000	2

REFERENCE DESIGNATORS	PART DESCRIPTION	DRG=MFCH=PART=ND	WAVE	WAVETEK NO.	QTY/PT
NONE	TRANSPAD	1012R	HP105	2800-11-0004	2
NONE	HEATSINK NUT	1101R	1M100	2800-11-0005	2
NONE	HEATSINK BODY	1101R	1M100	2800-11-0006	2
NONE	FRAGITE HEAD	50-440-04/34	FLNCH	3100-00-0001	1
R101 R159	POT,10K,100	01A100	HP100	4000-01-0103	2
R5 R6 R7 R8	POT,10K,1K	01A100	HP100	4000-01-0204	4
R130 R195 R201 R205	POT,10K,10K	01A100	HP100	4000-01-0315	4
R18 R207 R54 R55 R73	POT,10K,100K	01A100	HP100	4000-01-0402	4
R80	POT,10K,200	01A100	HP100	4000-02-0101	1
R175 R169	POT,10K,2K	01A100	HP100	4000-02-0201	2
R220	POT,10K,20K	01A100	HP100	4000-02-0301	1
R130 R135 R23 R231 R52 R56 R59	POT,10K,500	01A100	HP100	4000-02-0401	1
R224 R233	RES,C,1/2W,5K,1K	HC200-100	NVIA	4700-25-0100	2
R257	RES,C,1/2W,51K,0.2	HC200-100	NVIA	4700-25-0100	1
R175 R176 R84 R87	RES,C,1/2W,51K,0.2	HC200-100	NVIA	4700-25-0100	1
R17	RES,C,1/2W,51K,0.2	HC200-100	NVIA	4700-25-0100	1
R14 R85	RES,C,1/2W,51K,0.2	HC200-100	NVIA	4700-25-0100	2

REFERENCE DESIGNATORS	PART DESCRIPTION	DRG=MFCH=PART=ND	WAVE	WAVETEK NO.	QTY/PT
R72	RES,M,1/4W,18,15K	RN500-1502F	1M	4701-03-1502	1
R187 R288 R290 R295 R49 R70	RES,M,1/4W,18,1,2K	NVIA00-1502F	1M	4701-03-1502	2
R230 R241	RES,M,1/4W,18,1,2K	NVIA00-1502F	1M	4701-03-1502	2
R100 R105	RES,M,1/4W,18,1,2K	NVIA00-1502F	1M	4701-03-1502	2
R200 R226 R244	RES,M,1/4W,18,1,2K	NVIA00-1502F	1M	4701-03-1502	1
R250 R265	RES,M,1/4W,18,1,2K	NVIA00-1502F	1M	4701-03-1502	1
R114	RES,M,1/4W,18,1,2K	NVIA00-1502F	1M	4701-03-1502	1
R251	RES,M,1/4W,18,1,2K	NVIA00-1502F	1M	4701-03-1502	1
R105 R106 R107 R227 R88 R95	RES,M,1/4W,18,1,2K	NVIA00-1502F	1M	4701-03-1502	1
R108 R170 R218 R219 R270 R271 R272 R273	RES,M,1/4W,18,1,2K	NVIA00-1502F	1M	4701-03-1502	1
R250 R265 R71	RES,M,1/4W,18,1,2K	NVIA00-1502F	1M	4701-03-1502	1
R121 R140 R153 R215 R216 R217 R218 R219 R220 R221 R222 R223 R224 R225 R226 R227 R228 R229 R230 R231 R232 R233 R234 R235 R236 R237 R238 R239 R240 R241 R242 R243 R244 R245 R246 R247 R248 R249 R250 R251 R252 R253 R254 R255 R256 R257 R258 R259 R260 R261 R262 R263 R264 R265 R266 R267 R268 R269 R270 R271 R272 R273 R274 R275 R276 R277 R278 R279 R280 R281 R282 R283 R284 R285 R286 R287 R288 R289 R290 R291 R292 R293 R294 R295 R296 R297 R298 R299 R300 R301 R302 R303 R304 R305 R306 R307 R308 R309 R310 R311 R312 R313 R314 R315 R316 R317 R318 R319 R320 R321 R322 R323 R324 R325 R326 R327 R328 R329 R330 R331 R332 R333 R334 R335 R336 R337 R338 R339 R340 R341 R342 R343 R344 R345 R346 R347 R348 R349 R350 R351 R352 R353 R354 R355 R356 R357 R358 R359 R360 R361 R362 R363 R364 R365 R366 R367 R368 R369 R370 R371 R372 R373 R374 R375 R376 R377 R378 R379 R380 R381 R382 R383 R384 R385 R386 R387 R388 R389 R390 R391 R392 R393 R394 R395 R396 R397 R398 R399 R400 R401 R402 R403 R404 R405 R406 R407 R408 R409 R410 R411 R412 R413 R414 R415 R416 R417 R418 R419 R420 R421 R422 R423 R424 R425 R426 R427 R428 R429 R430 R431 R432 R433 R434 R435 R436 R437 R438 R439 R440 R441 R442 R443 R444 R445 R446 R447 R448 R449 R450 R451 R452 R453 R454 R455 R456 R457 R458 R459 R460 R461 R462 R463 R464 R465 R466 R467 R468 R469 R470 R471 R472 R473 R474 R475 R476 R477 R478 R479 R480 R481 R482 R483 R484 R485 R486 R487 R488 R489 R490 R491 R492 R493 R494 R495 R496 R497 R498 R499 R500 R501 R502 R503 R504 R505 R506 R507 R508 R509 R510 R511 R512 R513 R514 R515 R516 R517 R518 R519 R520 R521 R522 R523 R524 R525 R526 R527 R528 R529 R530 R531 R532 R533 R534 R535 R536 R537 R538 R539 R540 R541 R542 R543 R544 R545 R546 R547 R548 R549 R550 R551 R552 R553 R554 R555 R556 R557 R558 R559 R560 R561 R562 R563 R564 R565 R566 R567 R568 R569 R570 R571 R572 R573 R574 R575 R576 R577 R578 R579 R580 R581 R582 R583 R584 R585 R586 R587 R588 R589 R590 R591 R592 R593 R594 R595 R596 R597 R598 R599 R600 R601 R602 R603 R604 R605 R606 R607 R608 R609 R610 R611 R612 R613 R614 R615 R616 R617 R618 R619 R620 R621 R622 R623 R624 R625 R626 R627 R628 R629 R630 R631 R632 R633 R634 R635 R636 R637 R638 R639 R640 R641 R642 R643 R644 R645 R646 R647 R648 R649 R650 R651 R652 R653 R654 R655 R656 R657 R658 R659 R660 R661 R662 R663 R664 R665 R666 R667 R668 R669 R670 R671 R672 R673 R674 R675 R676 R677 R678 R679 R680 R681 R682 R683 R684 R685 R686 R687 R688 R689 R690 R691 R692 R693 R694 R695 R696 R697 R698 R699 R700 R701 R702 R703 R704 R705 R706 R707 R708 R709 R710 R711 R712 R713 R714 R715 R716 R717 R718 R719 R720 R721 R722 R723 R724 R725 R726 R727 R728 R729 R730 R731 R732 R733 R734 R735 R736 R737 R738 R739 R740 R741 R742 R743 R744 R745 R746 R747 R748 R749 R750 R751 R752 R753 R754 R755 R756 R757 R758 R759 R760 R761 R762 R763 R764 R765 R766 R767 R768 R769 R770 R771 R772 R773 R774 R775 R776 R777 R778 R779 R780 R781 R782 R783 R784 R785 R786 R787 R788 R789 R790 R791 R792 R793 R794 R795 R796 R797 R798 R799 R800 R801 R802 R803 R804 R805 R806 R807 R808 R809 R810 R811 R812 R813 R814 R815 R816 R817 R818 R819 R820 R821 R822 R823 R824 R825 R826 R827 R828 R829 R830 R831 R832 R833 R834 R835 R836 R837 R838 R839 R840 R841 R842 R843 R844 R845 R846 R847 R848 R849 R850 R851 R852 R853 R854 R855 R856 R857 R858 R859 R860 R861 R862 R863 R864 R865 R866 R867 R868 R869 R870 R871 R872 R873 R874 R875 R876 R877 R878 R879 R880 R881 R882 R883 R884 R885 R886 R887 R888 R889 R890 R891 R892 R893 R894 R895 R896 R897 R898 R899 R900 R901 R902 R903 R904 R905 R906 R907 R908 R909 R910 R911 R912 R913 R914 R915 R916 R917 R918 R919 R920 R921 R922 R923 R924 R925 R926 R927 R928 R929 R930 R931 R932 R933 R934 R935 R936 R937 R938 R939 R940 R941 R942 R943 R944 R945 R946 R947 R948 R949 R950 R951 R952 R953 R954 R955 R956 R957 R958 R959 R960 R961 R962 R963 R964 R965 R966 R967 R968 R969 R970 R971 R972 R973 R974 R975 R976 R977 R978 R979 R980 R981 R982 R983 R984 R985 R986 R987 R988 R989 R990 R991 R992 R993 R994 R995 R996 R997 R998 R999 R1000 R1001 R1002 R1003 R1004 R1005 R1006 R1007 R1008 R1009 R1010 R1011 R1012 R1013 R1014 R1015 R1016 R1017 R1018 R1019 R1020 R1021 R1022 R1023 R1024 R1025 R1026 R1027 R1028 R1029 R1030 R1031 R1032 R1033 R1034 R1035 R1036 R1037 R1038 R1039 R1040 R1041 R1042 R1043 R1044 R1045 R1046 R1047 R1048 R1049 R1050 R1051 R1052 R1053 R1054 R1055 R1056 R1057 R1058 R1059 R1060 R1061 R1062 R1063 R1064 R1065 R1066 R1067 R1068 R1069 R1070 R1071 R1072 R1073 R1074 R1075 R1076 R1077 R1078 R1079 R1080 R1081 R1082 R1083 R1084 R1085 R1086 R1087 R1088 R1089 R1090 R1091 R1092 R1093 R1094 R1095 R1096 R1097 R1098 R1099 R1100 R1101 R1102 R1103 R1104 R1105 R1106 R1107 R1108 R1109 R1110 R1111 R1112 R1113 R1114 R1115 R1116 R1117 R1118 R1119 R1120 R1121 R1122 R1123 R1124 R1125 R1126 R1127 R1128 R1129 R1130 R1131 R1132 R1133 R1134 R1135 R1136 R1137 R1138 R1139 R1140 R1141 R1142 R1143 R1144 R1145 R1146 R1147 R1148 R1149 R1150 R1151 R1152 R1153 R1154 R1155 R1156 R1157 R1158 R1159 R1160 R1161 R1162 R1163 R1164 R1165 R1166 R1167 R1168 R1169 R1170 R1171 R1172 R1173 R1174 R1175 R1176 R1177 R1178 R1179 R1180 R1181 R1182 R1183 R1184 R1185 R1186 R1187 R1188 R1189 R1190 R1191 R1192 R1193 R1194 R1195 R1196 R1197 R1198 R1199 R1200 R1201 R1202 R1203 R1204 R1205 R1206 R1207 R1208 R1209 R1210 R1211 R1212 R1213 R1214 R1215 R1216 R1217 R1218 R1219 R1220 R1221 R1222 R1223 R1224 R1225 R1226 R1227 R1228 R1229 R1230 R1231 R1232 R1233 R1234 R1235 R1236 R1237 R1238 R1239 R1240 R1241 R1242 R1243 R1244 R1245 R1246 R1247 R1248 R1249 R1250 R1251 R1252 R1253 R1254 R1255 R1256 R1257 R1258 R1259 R1260 R1261 R1262 R1263 R1264 R1265 R1266 R1267 R1268 R1269 R1270 R1271 R1272 R1273 R1274 R1275 R1276 R1277 R1278 R1279 R1280 R1281 R1282 R1283 R1284 R1285 R1286 R1287 R1288 R1289 R1290 R1291 R1292 R1293 R1294 R1295 R1296 R1297 R1298 R1299 R1300 R1301 R1302 R1303 R1304 R1305 R1306 R1307 R1308 R1309 R1310 R1311 R1312 R1313 R1314 R1315 R1316 R1317 R1318 R1319 R1320 R1321 R1322 R1323 R1324 R1325 R1326 R1327 R1328 R1329 R1330 R1331 R1332 R1333 R1334 R1335 R1336 R1337 R1338 R1339 R1340 R1341 R1342 R1343 R1344 R1345 R1346 R1347 R1348 R1349 R1350 R1351 R1352 R1353 R1354 R1355 R1356 R1357 R1358 R1359 R1360 R1361 R1362 R1363 R1364 R1365 R1366 R1367 R1368 R1369 R1370 R1371 R1372 R1373 R1374 R1375 R1376 R1377 R1378 R1379 R1380 R1381 R1382 R1383 R1384 R1385 R1386 R1387 R1388 R1389 R1390 R1391 R1392 R1393 R1394 R1395 R1396 R1397 R1398 R1399 R1400 R1401 R1402 R1403 R1404 R1405 R1406 R1407 R1408 R1409 R1410 R1411 R1412 R1413 R1414 R1415 R1416 R1417 R1418 R1419 R1420 R1421 R1422 R1423 R1424 R1425 R1426 R1427 R1428 R1429 R1430 R1431 R1432 R1433 R1434 R1435 R1436 R1437 R1438 R1439 R1440 R1441 R1442 R1443 R1444 R1445 R1446 R1447 R1448 R1449 R1450 R1451 R1452 R1453 R1454 R1455 R1456 R1457 R1458 R1459 R1460 R1461 R1462 R1463 R1464 R1465 R1466 R1467 R1468 R1469 R1470 R1471 R1472 R1473 R1474 R1475 R1476 R1477 R1478 R1479 R1480 R1481 R1482 R1483 R1484 R1485 R1486 R1487 R1488 R1489 R1490 R1491 R1492 R1493 R1494 R1495 R1496 R1497 R1498 R1499 R1500 R1501 R1502 R1503 R1504 R1505 R1506 R1507 R1508 R1509 R1510 R1511 R1512 R1513 R1514 R1515 R1516 R1517 R1518 R1519 R1520 R1521 R1522 R1523 R1524 R1525 R1526 R1527 R1528 R1529 R1530 R1531 R1532 R1533 R1534 R1535 R1536 R1537 R1538 R1539 R1540 R1541 R1542 R1543 R1544 R1545 R1546 R1547 R1548 R1549 R1550 R1551 R1552 R1553 R1554 R1555 R1556 R1557 R1558 R1559 R1560 R1561 R1562 R1563 R1564 R1565 R1566 R1567 R1568 R1569 R1570 R1571 R1572 R1573 R1574 R1575 R1576 R1577 R1578 R1579 R1580 R1581 R1582 R1583 R1584 R1585 R1586 R1587 R1588 R1589 R1590 R1591 R1592 R1593 R1594 R1595 R1596 R1597 R1598 R1599 R1600 R1601 R1602 R1603 R1604 R1605 R1606 R1607 R1608 R1609 R1610 R1611 R1612 R1613 R1614 R1615 R1616 R1617 R1618 R1619 R1620 R1621 R1622 R1623 R1624 R1625 R1626 R1627 R1628 R1629 R1630 R1631 R1632 R1633 R1634 R1635 R1636 R1637 R1638 R1639 R1640 R1641 R1642 R1643 R1644 R1645 R1646 R1647 R1648 R1649 R1650 R1651 R1652 R1653 R1654 R1655 R1656 R1657 R1658 R1659 R1660 R1661 R1662 R1663 R1664 R1665 R1666 R1667 R1668 R1669 R1670 R1671 R1672 R1673 R1674 R1675 R1676 R1677 R1678 R1679 R1680 R1681 R1682 R1683 R1684 R1685 R1686 R1687 R1688 R1689 R1690 R1691 R1692 R1693 R1694 R1695 R1696 R1697 R1698 R1699 R1700 R1701 R1702 R1703 R1704 R1705 R1706 R1707 R1708 R1709 R1710 R1711 R1712 R1713 R1714 R1715 R1716 R1717 R1718 R1719 R1720 R1721 R1722 R1723 R1724 R1725 R1726 R1727 R1728 R1729 R1730 R1731 R1732 R1733 R1734 R1735 R1736 R1737 R1738 R1739 R1740 R1741 R1742 R1743 R1744 R1745 R1746 R1747 R1748 R1749 R1750 R1751 R1752 R1753 R1754 R1755 R1756 R1757 R1758 R1759 R1760 R1761 R1762 R1763 R1764 R1765 R1766 R1767 R1768 R1769 R1770 R1771 R1772 R1773 R1774 R1775 R1776 R1777 R1778 R1779 R1780 R1781 R1782 R1783 R1784 R1785 R1786 R1787 R1788 R1789 R1790 R1791 R1792 R1793 R1794 R1795 R1796 R1797 R1798 R1799 R1800 R1801 R1802 R1803 R1804 R1805 R1806 R1807 R1808 R1809 R1810 R1811 R1812 R1813 R1814 R1815 R1816 R1817 R1818 R1819 R1820 R1821 R1822 R1823 R1824 R1825 R1826 R1827 R1828 R1829 R1830 R1831 R1832 R1833 R1834 R1835 R1836 R1837 R1838 R1839 R1840 R1841 R1842 R1843 R1844 R1845 R1846 R1847 R1848 R1849 R1850 R1851 R1852 R1853 R1854 R1855 R1856 R1857 R1858 R1859 R1860 R1861 R1862 R1863 R1864 R1865 R1866 R1867 R1868 R1869 R1870 R1871 R1872 R1873 R1874 R1875 R1876 R1877 R1878 R1879 R1880 R1881 R1882 R1883 R1884 R1885 R1886 R1887 R1888 R1889 R1890 R1891 R1892 R1893 R1894 R1895 R1896 R1897 R1898 R1899 R1900 R1901 R1902 R1903 R1904 R1905 R1906 R1907 R1908 R1909 R1910 R1911 R1912 R1913 R1914 R1915 R1916 R1917 R1918 R1919 R1920 R1921 R1922 R1923 R1924 R1925 R1926 R1927 R1928 R1929 R1930 R1931 R1932 R1933 R1934 R1935 R1936 R1937 R1938 R1939 R1940 R1941 R1942 R1943 R1944 R1945 R1946 R1947 R1948 R1949 R1950 R1951 R1952 R1953 R1954 R1955 R1956 R1957 R1958 R1959 R1960 R1961 R1962 R1963 R1964 R1965 R1966 R1967 R1968 R1969 R1970 R1971 R1972 R1973 R1974 R1975 R1976 R1977 R1978 R1979 R1980 R1981 R1982 R1983 R1984 R1985 R1986 R1987 R1988 R1989 R1990 R1991 R1992 R1993 R1994 R1995 R1996 R1997 R1998 R1999 R2000 R2001 R2002 R2003 R2004 R2005 R2006 R2007 R2008 R2009 R2010 R2011 R2012 R2013 R2014 R2015 R2016 R2017 R2018 R2019 R2020 R2021 R2022 R2023 R2024 R2025 R2026 R2027 R2028 R2029 R2030 R2031 R2032 R2033 R2034 R2035 R2036 R2037 R2038 R2039 R2040 R2041 R2042 R2043 R2044 R2045 R2046 R2047 R2048 R2049 R2050 R2051 R2052 R2053 R2054 R2055 R2056 R2057 R2058 R2059 R2060 R2061 R2062 R2063 R2064 R2065 R2066 R2067 R2068 R2069 R2070 R2071 R2072 R2073 R2074 R2075 R2076 R2077 R2078 R2079 R2080 R2081 R2082 R2083 R2084 R2085 R2086 R2087 R2088 R2089 R2090 R2091 R2092 R2093 R2094 R2095 R2096 R2097 R2098 R2099 R2100 R2101 R2102 R2103 R2104 R2105 R2106 R2107 R2108 R2109 R2110 R2111 R2112 R2113 R2114 R2115 R2116 R2117 R2118 R2119 R2120 R2121 R2122 R2123 R2124 R2125 R2126 R2127 R2128 R2129 R2130 R2131 R2132 R2133 R2134 R2135 R2136 R2137 R2138 R2139 R2140 R2141 R2142 R2143 R2144 R2145 R2146 R2147 R2148 R2149 R2150 R2151 R2152 R2153 R2154 R2155 R2156 R2157 R2158 R2159 R2160 R2161 R2162 R2163 R2164 R2165 R2166 R2167 R2168 R2169 R2170 R2171 R2172 R2173 R2174 R2175 R2176 R2177 R2178 R2179 R2180 R2181 R2182 R2183 R2184 R2185 R2186 R2187 R2188 R2189 R2190 R2191 R2192 R2193 R2194 R2195 R2196 R2197 R2198 R2199 R2200 R2201 R2202 R2203 R2204 R2205 R2206 R2207 R2208 R2209 R2210 R2211 R2212 R2213 R2214 R2215 R2216 R2217 R2218 R2219 R2220 R2221 R2222 R2223 R2224 R2225 R2226 R2227 R2228 R2229 R2230 R2231 R2232 R2233 R2234 R2235 R2236 R2237 R2238 R2239 R2240 R2241 R2242 R2243 R2244 R2245 R2246 R2247 R2248 R2249 R2250 R2251 R2252 R2253 R2254 R2255 R2256 R2257 R2258 R2259 R2260 R2261 R2262 R2263 R2264 R2265 R2266 R2267 R2268 R2269 R2270 R2271 R2272 R2273 R2274 R2275 R2276 R2277 R2278 R2279 R2280 R2281 R2282 R2283 R2284 R2285 R2286 R2287 R2288 R2289 R2290 R2291 R2292 R2293 R2294 R2295 R2296 R2297 R2298 R2299 R2300 R2301 R2302 R2303 R2304 R2305 R2306 R2307 R2308 R2309 R2310 R2311 R2312 R2313 R2314 R2315 R2316 R2317 R2318 R2319 R2320 R2321 R2322 R2323 R2324 R2325 R2326 R2327 R2328 R2329 R2330 R2331 R2332 R2333 R2334 R2335 R2336 R2337 R2338 R2339 R2340 R2341 R2342 R2343 R2344 R2345 R2346 R2347 R2348 R2349 R2350 R2351 R2352 R2353 R2354 R2355 R2356 R2357 R2358 R2359 R2360 R2361 R2362 R2363 R2364 R2365 R2366 R2367 R2368 R2369 R2370 R2371 R2372 R2373 R2374 R2375 R2376 R2377 R2378 R2379 R2380 R2381 R2382 R2383 R2384 R2385 R2386 R2387 R2388 R2389 R2390 R2391 R2392 R2393 R2394 R2395 R2396 R2397 R2398 R2399 R2400 R2401 R2402 R2403 R2404 R2405 R2406 R2407 R2408 R2409 R2410 R2411 R2412 R2413 R2414 R2415 R2416 R2417 R2418 R2419 R2420 R2421 R2422 R2423 R2424 R2425 R2426 R2427 R2428 R2429 R2430 R2431 R2432 R2433 R2434 R2435 R2436 R2437 R2438 R2439 R2440 R2441 R2442 R2443 R2444 R2445 R2446 R2447 R2448 R2449 R2450 R2451 R2452 R2453 R2454 R2455 R2456 R2457 R2458 R2459 R2460 R2461 R2462 R2463 R2464 R2465 R2466 R2467 R2468 R2469 R2470 R2471 R2472 R2473 R2474 R2475 R2476 R2477 R2478 R2479 R2480 R2481 R2482 R2483 R2484 R2485 R2486 R2487 R2488 R2489 R2490 R2491 R2492 R2493 R2494 R2495 R2496 R2497 R2498 R2499 R2500 R2501 R2502 R2503 R2504 R2505 R2506 R2507 R2508 R2509 R2510 R2511 R2512 R2513 R2514 R2515 R2516 R2517 R2518 R2519 R2520 R2521 R2522 R2523 R2524 R2525 R2526 R2527 R2528 R2529 R2530 R2531 R2532 R2533 R2534 R2535 R2536 R2537 R2538 R2539 R2540 R2541 R2542 R2543 R2544 R2545 R2546 R2547 R2548 R2549 R2550 R2551 R2552 R2553 R2554 R2555 R2556 R2557 R2558 R2559 R2560 R2561 R2562 R2563 R2564 R2565 R2566 R2567 R2568 R2569 R2570 R2571 R2572 R2573 R2574 R2575 R2576 R2577 R2578 R2579 R2580 R2581 R2582 R2583 R2584 R2585 R2586 R2587 R2588 R2589 R2590 R2591 R2592 R2593 R2594 R2595 R2596 R2597 R2598 R2599 R2600 R2601 R2602 R2603 R2604 R2605 R2606 R2607 R2608 R2609 R2610 R2611 R2612 R2613 R2614 R2615 R2616 R2617 R2618 R2619 R2620 R2621 R2622 R2623 R2624 R2625 R2626 R2627 R2628 R2629 R2630 R2631 R2632 R2633 R2634 R2635 R2636 R2637 R2638 R2639 R2640 R2641 R2642 R2643 R2644 R2645 R2					

REFERENCE DESIGNATIONS	PART DESCRIPTION	ORGANIZATION	QTY	WAFER NO.	WAFER
W25A	W25 MF, 1.00u, 13, 5, 51	WASST-10110	1	0701-05-1011	1
W20	W20 MF, 1.00u, 13, 5, 51	WASST-10121	1	0701-05-1012	1
W100 W101 W171 W225 W232 W50 W57 W51 W52	W5, MF, 1.00u, 13, 5, 51	WASST-10070	1	0701-05-1100	1
W21	W25 MF, 1.00u, 13, 5, 52	WASST-10110	1	0701-05-1101	1
W157 W100 W107 W155 W157	W5, MF, 1.00u, 13, 5, 52	WASST-10020	1	0701-05-1100	1
W07 W08	W07 MF, 1.00u, 13, 5, 52	WASST-10051	1	0701-05-1005	1
W255 W252 W07	W25 MF, 1.00u, 13, 5, 51	WASST-10110	1	0701-13-1011	1
W05	W25 MF, 1.00u, 13, 5, 52	WASST-10070	1	0701-13-1001	1
W003	W25 MF, 1.00u, 13, 5, 52	WASST-10070	1	1301-05-1000	1
W25b	W25 MF, 1.00u, 13, 5, 52b	WASST-10021	1	0701-05-1001	1
W21 W25b	W25 MF, 1.00u, 13, 5, 52	WASST-10070	1	0701-05-1001	1
W151 W100 W100 W02 W01 W03	W25 MF, 1.00u, 13, 5, 52	WASST-10070	1	1301-05-1001	1
R100	W25 MF, 1.00u, 13, 5, 52	WASST-00001	1	0701-05-0001	1
W100 W25 W0 W70	W25 MF, 1.00u, 13, 5, 52	WASST-00001	1	0701-05-0000	1
R130 W20 W250 W271 W00 W03	W25 MF, 1.00u, 13, 5, 75	WASST-00151	1	0701-05-0751	1

[illegible]

REFERENCE DESIGNATION	PART DESCRIPTION	QUANTITY REQUIRED	WFO	AVAIL. IN STOCK	STOCK
228 04 007	10465	200000	1	0001-05+00020	5
011 026 054 041 000 054 041 054 051 000	10465	200000	1	0001-05+00020	10
054	10465	200000	1	0001-05+00020	7
054	10465	200000	1	0001-05+00020	1
012 015 012 021 000 025 027 031 000	10465	200000	1	0001-05+00020	4
258	10465	200000	1	0001-05+00020	1
01 016	10465	200000	1	0001-05+00020	2
016 016 016 021 000 031 030	10465	200000	1	0001-05+00020	2
085	10465	100000	1	0001-05+00020	1
01 006	10465	200000	1	0001-05+00020	2
022 023	10465, 10465, 200000 010121-0001-000000	100000000	1	0001-05+00020	1
011 02	10465, 201, 200000 010121-0001-000000	100000000	1	0001-05+00020	2
06 07	10465, 10465, 200000 010121-0001-000000	100000000	1	0001-05+00020	1
044 050	10465, 10465, 200000	100000000	1	0001-05+00020	1

WAVETEK
PARTS LIST

TITLE
PAGE 1

ASSEMBLY NO.
100000000

PAGE 1

REV
6


REFERENCE DESIGNATORS	PART DESCRIPTION	QUANTITY	ASSEMBLY NO.	REV
H276	W5, W, 1/200, 13, 1, 25	00000000000000	701-03-0372	1
H119 H180 H262	W5, W, 1/20, 13, 000	00000000000000	701-03-04000	1
H211 W50 H42 W40 H45 W40	W5, W, 1/200, 13, 000	00000000000000	701-03-04000	1
H118 H125 H134 H135	W5, W, 1/200, 13, 011	00000000000000	701-03-05110	1
H180 H150 H152	W5, W, 1/200, 13, 000	00000000000000	701-03-04020	1
H287	W5, W, 1/200, 13, 5, 766	00000000000000	701-03-05766	1
H103 H13	W5, W, 1/200, 13, 000	00000000000000	701-03-04010	1
H76	W5, W, 1/200, 13, 001	00000000000000	701-03-04001	1
H214 H23	W5, W, 1/200, 13, 000	00000000000000	701-03-04001	1
H40 W40	W5, W, 1/200, 13, 750	00000000000000	701-03-04750	1
H270 H40 H41	W5, W, 1/200, 13, 750	00000000000000	701-03-04750	1
H16	W5, W, 1/200, 13, 750	00000000000000	701-03-04750	1
H182 H21 H480 H210 H275 H277	W5, W, 1/200, 13, 275	00000000000000	701-03-04275	1
H182 H188 H172 H175	W5, W, 1/200, 13, 000	00000000000000	701-03-04000	1
H132 H75	W5, W, 1/200, 13, 000	00000000000000	701-03-04000	1
H15 H127	W5, W, 1/200, 13, 000	00000000000000	701-03-04000	1

[illegible]

DESIGNATION	PART DESCRIPTION	QTY REQ	REV	ASSEMB NO	QTY REQ
	47820100000000000000	130-501-11		890A-00-0014	1
Q41 W42	TP403, W404, 2P 300A 47820100000000000000				
IC12	IC	1W 3012A		7000-03-0100	1
IC13	IC	MC10451		7000-10-0450	1
IC16	IC	C4-100A8		7000-10-2000	1
IC10	IC	C4-100P		7000-10-0400	1
IC14	IC, CLASS 1, C4-1050 47811700000000000000	130-501-14		7200-00-0001	1
IC1 IC11 IC14 IC2 IC3 IC4 IC5 IC6 IC7 IC8 IC9	IC, CLASS 1, M4-700 M7C11700000000000000	130-501-11		7200-00-0005	11


NOTE: UNLESS OTHERWISE SPECIFIED

REMOVE ALL BURRS AND BREAK SHARP EDGES	DRAWN	DATE	 SAN DIEGO • CALIFORNIA	
MATERIAL	PROFINGER		TITLE	
	RELEASE APPROV		MAIN BOARD	
	TOLERANCE UNLESS OTHERWISE SPECIFIED		MODEL NO	DWG NO
FINISH	XXX .010 ANGLES - I		14C	100-00-0056
WAVETER PROCESS	XX - .020			REV
	DO NOT SCALE DWG		23338	G
	SCALE		CAGE IDENT	SHEET
				Z OF Z



NOTES: UNLESS OTHERWISE SPECIFIED
1. NUMBERS INDICATE WIRE TERMINATION POINTS.

Tolerance unless otherwise specified RES ± 0.05 CAP ± 0.05	rev	ecm	by	date	app.
WAVETEK san diego, calif.					
part no. N/A	title ASSEMBLY POWER SUPPLY				
drawn by N/A	checked by date 				
This document contains proprietary information and design rights pertaining to WAVE TEK and may not be used or reproduced for any reason except calibration operation and maintenance without written authorization.					



[illegible]

REFERENCE DESIGNATORS	PART DESCRIPTION	UNIT WEIGHT-Grams	QTY	ASSEMBLY NO.	REV.
D18 UM IC1 IC2 IC3 IC4	IC3CA EL	11.00-13.00 1.00-1.10	1 1	WAP2-15-010A P055-07-0101	1 1



VAVETEK
PARTS LIST

TITLE
PARTS



ASSEMBLY NO.
1107-05-000A-2

PAGE 1 3

REV.
-

REFERENCE DESIGNATORS	PART DESCRIPTION	QTY	UNIT	MANUFACTURER	PRICE	AVAIL. NO.	STATUS
M1A	MS-001, 1/8in, 1/4in, 3/8in	100000	100000	100000	100000	100000	100000
M2 A5	MS-001, 1/8in, 1/4in, 3/8in	100000	100000	100000	100000	100000	100000
M1 M1 M2 M3 M4 M5	MS-001, 1/8in, 1/4in, 3/8in	100000	100000	100000	100000	100000	100000
M27	MS-001, 1/8in, 1/4in, 3/8in	100000	100000	100000	100000	100000	100000
M2A M35	MS-001, 1/8in, 1/4in, 3/8in	100000	100000	100000	100000	100000	100000
M11 M16	MS-001, 1/8in, 1/4in, 3/8in	100000	100000	100000	100000	100000	100000
M2A M1 M2A	MS-001, 1/8in, 1/4in, 3/8in	100000	100000	100000	100000	100000	100000
M4 M5	MS-001, 1/8in, 1/4in, 3/8in	100000	100000	100000	100000	100000	100000
M2 M1 M2	MS-001, 1/8in, 1/4in, 3/8in	100000	100000	100000	100000	100000	100000
M1A M19	MS-001, 1/8in, 1/4in, 3/8in	100000	100000	100000	100000	100000	100000
C1010	01000	100000	100000	100000	100000	100000	100000
C101 C102 C103 C104 C105	01000	100000	100000	100000	100000	100000	100000
C106 C107 C108	01000	100000	100000	100000	100000	100000	100000
C109 C110	01000	100000	100000	100000	100000	100000	100000
C111 C112 C113 C114 C115	01000	100000	100000	100000	100000	100000	100000
C116 C117 C118	01000	100000	100000	100000	100000	100000	100000
C119 C120	01000	100000	100000	100000	100000	100000	100000

REMOVE ALL BURRS AND SHARP EDGES	DRAWN	DATE	 WAVELENGTH TECHNOLOGIES, INC.	
MATERIAL	PROFINDER			1.0
	RELEASE APPROP.	TOLERANCE UNLESS OTHERWISE SPECIFIED AXI - .010 ANGLES - 1° EX - .020		
FINISH WAVETEK PROCESS	DO NOT SCALE DWG		MODE NO 14C	QTY NO 1100-00-0057
	SCALE	CUST PO 23330	SHEET 1 OF H	



D	ECN 1764	5/2/80
C	ECN 1376	6-3-72
REV	ECN	DATE

B		ECN 145		7/1/77	
A	ECN 462	RE	Wavy		
REV	ECN	BY	DATE	APP	
TOLERANCE UNLESS OTHERWISE SPEC					
XX - .010					
XX - .030					
ANGLES - 0.30					
SCALE	BY	DATE	APPROVED		
MATERIAL	TITLE				
ASSEMBLY MOVEMENT					
MODEL NO	ORD NO	REV			
42	100-00-0323	D			
THIS DOCUMENT IS A PROPRIETARY INFORMATION. IT IS THE PROPERTY OF WAVE TEK, INC. AND IS NOT TO BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, WITHOUT WRITTEN AUTHORIZATION.					

THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION AND DESIGN RIGHTS BELONGING TO WAVETEK AND MAY NOT BE REPRODUCED FOR ANY REASON EXCEPT CALIBRATION, OPERATION, AND MAINTENANCE WITHOUT WRITTEN AUTHORIZATION.

REV	ECN	BY	DATE	APP
-----	-----	----	------	-----

REFERENCE DESIGNATORS	PART DESCRIPTION	ORIG+FIG+PART-NO	FIG#	WAVETEK NO.	QTY
NONE	ASST. DRAG, LEFT MOVE	U102-CU-0329	WVTK	0102-00-0329	1
11	PULLEY, LUMER	140-315	WVTK	1400-00-2520	1
8	PLATE, BEARING	140-317	WVTK	1400-00-2533	1
13	POINTER, PHUNT	140-335	WVTK	1400-00-2609	1
12	POINTER, REAR	140-330	WVTK	1400-00-2619	1
10	PULLEY, FT	140-353	WVTK	1400-00-2620	1
9	PULLEY, REAR	140-350	WVTK	1400-00-2630	1
10	RASPER, SPRING	140-350	WVTK	1400-00-2644	1
14	DRIVE SPRING	140-335	WVTK	1400-00-2650	1
21	BULDER LUG	1407	DMTH	2100-00-0014	1
ALAC	INSECT # 8	74-11-104-13	DUICO	2800-04-0010	1
22	RASPER, SPRING	2800	DMTH	2800-00-0001	0
20	SPRING	E1-0100-4	LEE	2800-01-0001	1
1	POT, LIAL, SR	140-501	WVTK	0400-05-0203	1
2	POT, LIAL, SR	140-502	WVTK	0400-05-0204	1

WAVETEK PARTS LIST	TITLE LEFT MOVEMENT	ASSEMBLY NO. 1101-00-0070 PAGE: 1	REV C
------------------------------	------------------------	---	----------

NOTE: UNLESS OTHERWISE SPECIFIED

REMOVE ALL BURRS AND BREAK SHARP EDGES	ORIGIN	DATE	WAVETEK SAN DIEGO - CALIFORNIA	
MATERIAL	PROCESSOR	TITLE LEFT MOVEMENT		
FINISH WAVETEK PROCESS	RELEASE APPROV	TOLERANCE UNLESS OTHERWISE SPECIFIED BY: STD ANGLES: 1° XX - 250		
	DO NOT SCALE DWG	MODEL NO. 140	QTY NO. 1101-00-0070	REV. E
	SCALE	SHEET 1 OF 1		
	SCALE	23338		

REFERENCE DESIGNATION	PART DESCRIPTION	QNTY=HIGH+PART-NU	WGR	REVISION NO.	DATE
2	POT, 0.1AL, 5K	145-562	WETA	8000-05-0004	1



WAVETEK
PARTS LIST


TITLE
RIGHT MOVEMENT

ASSEMBLY NO.
1101-00-0001

PAGE 2

REV
F

REMOVE ALL BURRS AND BREAK SHARP EDGES	NAME	DATE	 SAN DIEGO - CALIFORNIA	
MATERIAL	PRODUCER	TITLE	RIGHT MOVEMENT	
RELEASE APPROV				
TOLFRANCE UNLESS OTHER SPECIFIC X.XX - 010 ANGLES - 1 - 220				
DO NOT SCALE DWG		MODEL NO	DWG NO	REV
SCALE		146	1101-00-0091	1 OF
		CODE	SHEET	OF
		23338		



1.5" P.F.
 1.5" P.F.
 1.5" P.F.
 1.5" P.F.

1. NUMBERS ARE FOR INTERCONNECTION PURPOSES ONLY, SEE 0004-00-0037



NOTES: UNLESS OTHERWISE SPECIFIED

REV	DESCRIPTION	DATE	APPROVED
1	1/15/64	1/15/64	1/15/64
2	2/1/64	2/1/64	2/1/64
3	3/1/64	3/1/64	3/1/64
4	4/1/64	4/1/64	4/1/64
5	5/1/64	5/1/64	5/1/64
6	6/1/64	6/1/64	6/1/64
7	7/1/64	7/1/64	7/1/64
8	8/1/64	8/1/64	8/1/64
9	9/1/64	9/1/64	9/1/64
10	10/1/64	10/1/64	10/1/64
11	11/1/64	11/1/64	11/1/64
12	12/1/64	12/1/64	12/1/64
13	1/1/65	1/1/65	1/1/65
14	2/1/65	2/1/65	2/1/65
15	3/1/65	3/1/65	3/1/65
16	4/1/65	4/1/65	4/1/65
17	5/1/65	5/1/65	5/1/65
18	6/1/65	6/1/65	6/1/65
19	7/1/65	7/1/65	7/1/65
20	8/1/65	8/1/65	8/1/65
21	9/1/65	9/1/65	9/1/65
22	10/1/65	10/1/65	10/1/65
23	11/1/65	11/1/65	11/1/65
24	12/1/65	12/1/65	12/1/65
25	1/1/66	1/1/66	1/1/66
26	2/1/66	2/1/66	2/1/66
27	3/1/66	3/1/66	3/1/66
28	4/1/66	4/1/66	4/1/66
29	5/1/66	5/1/66	5/1/66
30	6/1/66	6/1/66	6/1/66
31	7/1/66	7/1/66	7/1/66
32	8/1/66	8/1/66	8/1/66
33	9/1/66	9/1/66	9/1/66
34	10/1/66	10/1/66	10/1/66
35	11/1/66	11/1/66	11/1/66
36	12/1/66	12/1/66	12/1/66
37	1/1/67	1/1/67	1/1/67
38	2/1/67	2/1/67	2/1/67
39	3/1/67	3/1/67	3/1/67
40	4/1/67	4/1/67	4/1/67
41	5/1/67	5/1/67	5/1/67
42	6/1/67	6/1/67	6/1/67
43	7/1/67	7/1/67	7/1/67
44	8/1/67	8/1/67	8/1/67
45	9/1/67	9/1/67	9/1/67
46	10/1/67	10/1/67	10/1/67
47	11/1/67	11/1/67	11/1/67
48	12/1/67	12/1/67	12/1/67
49	1/1/68	1/1/68	1/1/68
50	2/1/68	2/1/68	2/1/68
51	3/1/68	3/1/68	3/1/68
52	4/1/68	4/1/68	4/1/68
53	5/1/68	5/1/68	5/1/68
54	6/1/68	6/1/68	6/1/68
55	7/1/68	7/1/68	7/1/68
56	8/1/68	8/1/68	8/1/68
57	9/1/68	9/1/68	9/1/68
58	10/1/68	10/1/68	10/1/68
59	11/1/68	11/1/68	11/1/68
60	12/1/68	12/1/68	12/1/68
61	1/1/69	1/1/69	1/1/69
62	2/1/69	2/1/69	2/1/69
63	3/1/69	3/1/69	3/1/69
64	4/1/69	4/1/69	4/1/69
65	5/1/69	5/1/69	5/1/69
66	6/1/69	6/1/69	6/1/69
67	7/1/69	7/1/69	7/1/69
68	8/1/69	8/1/69	8/1/69
69	9/1/69	9/1/69	9/1/69
70	10/1/69	10/1/69	10/1/69
71	11/1/69	11/1/69	11/1/69
72	12/1/69	12/1/69	12/1/69
73	1/1/70	1/1/70	1/1/70
74	2/1/70	2/1/70	2/1/70
75	3/1/70	3/1/70	3/1/70
76	4/1/70	4/1/70	4/1/70
77	5/1/70	5/1/70	5/1/70
78	6/1/70	6/1/70	6/1/70
79	7/1/70	7/1/70	7/1/70
80	8/1/70	8/1/70	8/1/70
81	9/1/70	9/1/70	9/1/70
82	10/1/70	10/1/70	10/1/70
83	11/1/70	11/1/70	11/1/70
84	12/1/70	12/1/70	12/1/70
85	1/1/71	1/1/71	1/1/71
86	2/1/71	2/1/71	2/1/71
87	3/1/71	3/1/71	3/1/71
88	4/1/71	4/1/71	4/1/71
89	5/1/71	5/1/71	5/1/71
90	6/1/71	6/1/71	6/1/71
91	7/1/71	7/1/71	7/1/71
92	8/1/71	8/1/71	8/1/71
93	9/1/71	9/1/71	9/1/71
94	10/1/71	10/1/71	10/1/71
95	11/1/71	11/1/71	11/1/71
96	12/1/71	12/1/71	12/1/71
97	1/1/72	1/1/72	1/1/72
98	2/1/72	2/1/72	2/1/72
99	3/1/72	3/1/72	3/1/72
100	4/1/72	4/1/72	4/1/72

REV	EN	BY	DATE	AP
-----	----	----	------	----

NOTE: UNLESS OTHERWISE SPECIFIED

REVISIONS				
REV	DESCRIPTION	DATE	APPROVED	
A	ECN 876	2/2/68		
B	ECN 945	8/1/74		
C	DDC ECN 1335 ADDED SHEETS	8/2/74		



SW1
REF
FRONT VIEWS

1 A* INDICATES AMP PINS MOUNTED ON COMPONENT SIDE
NOTES: UNLESS OTHERWISE SPECIFIED:

TOLERANCE UNLESS OTHERWISE SPEC		REV	DATE	BY	DATE	BY
XAX .010		WAVETEK				
XAX .010		SANDIEGO, CALIFORNIA				
ANGLES .030						
SCALE -		BY	DATE	BY	DATE	BY
MATERIAL		TITLE				
		A55Y				
		AUXILIARY BOARD				
FINISH		MODEL NO	SHEET NO	REV	DATE	BY
		146	0101-00-0059	C	9/1/73	J. B. L.

THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION AND DESIGN RIGHTS BELONGING TO WAVETEK AND MAY NOT BE REPRODUCED FOR ANY REASON, EXCEPT CALIBRATION, OPERATION, AND MAINTENANCE WITHOUT WRITTEN AUTHORIZATION

THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION AND DESIGN RIGHTS BELONGING TO WAVETEK AND MAY NOT BE REPRODUCED FOR ANY REASON EXCEPT CALIBRATION, OPERATION AND MAINTENANCE WITHOUT WRITTEN AUTHORIZATION

REFERENCE DESIGNATORS	PART DESCRIPTION	UNIT NUMBER	QTY	WAVETEK NO.	QTY	REFERENCE DESIGNATORS	PART DESCRIPTION	UNIT NUMBER	QTY	WAVETEK NO.	QTY	REFERENCE DESIGNATORS	PART DESCRIPTION	UNIT NUMBER	QTY	WAVETEK NO.	QTY
None	ASST. JMW. AUXILIARY	U01=00+0000	1	0101=00+0000	1	W71 W72 W73 W74	RES, MF, 1/8W, 13, 10K	W71=00+0000	1	W71=00+0000	1	W71	RES, MF, 1/8W, 13, 7.5K	W71=00+0000	1	W71=00+0000	1
None	SCHEMATIC, AUXILIARY	U02=00+0000	1	0102=00+0000	1	W75 W76	RES, MF, 1/8W, 13, 10K	W75=00+0000	1	W75=00+0000	1	W75	RES, MF, 1/8W, 13, 7.5K	W75=00+0000	1	W75=00+0000	1
W1	DIAG. HW	130+001	1	0103=00+0001	1	W77 W78	RES, MF, 1/8W, 13, 10K	W77=00+0001	1	W77=00+0001	1	W77	RES, MF, 1/8W, 13, 7.5K	W77=00+0001	1	W77=00+0001	1
W2	ATTEN. ON ASST.	140+007	1	0104=00+0007	1	W79 W80	RES, MF, 1/8W, 13, 10K	W79=00+0007	1	W79=00+0007	1	W79	RES, MF, 1/8W, 13, 7.5K	W79=00+0007	1	W79=00+0007	1
W3	POWER/ENVELOPE ON ASST.	140+009	1	0105=00+0009	1	W81 W82	RES, MF, 1/8W, 13, 10K	W81=00+0009	1	W81=00+0009	1	W81	RES, MF, 1/8W, 13, 7.5K	W81=00+0009	1	W81=00+0009	1
U1 CE L37	CAP, CER, 100PF, 14V	U06=000	1	1500=00+0011	1	W83 W84 W85 W86 W87	RES, MF, 1/8W, 13, 10K	W83=00+0011	1	W83=00+0011	1	W83	RES, MF, 1/8W, 13, 7.5K	W83=00+0011	1	W83=00+0011	1
U2 L31 L34 L35	CAP, CER, 100PF, 14V	U07=001	1	1500=00+0011	1	W89 W90	RES, MF, 1/8W, 13, 10K	W89=00+0011	1	W89=00+0011	1	W89	RES, MF, 1/8W, 13, 7.5K	W89=00+0011	1	W89=00+0011	1
U3 L41 L42 L43 L44	CAP, CER, 100PF, 14V	U08=003	1	1500=00+0011	1	W91 W92	RES, MF, 1/8W, 13, 10K	W91=00+0011	1	W91=00+0011	1	W91	RES, MF, 1/8W, 13, 7.5K	W91=00+0011	1	W91=00+0011	1
U4 L14 L15 L16 L17 L18	CAP, CER, 100PF, 14V	U09=004	1	1500=00+0011	1	W93 W94	RES, MF, 1/8W, 13, 10K	W93=00+0011	1	W93=00+0011	1	W93	RES, MF, 1/8W, 13, 7.5K	W93=00+0011	1	W93=00+0011	1
U5 L19 L20 L21 L22 L23	CAP, CER, 100PF, 14V	U10=005	1	1500=00+0011	1	W95 W96	RES, MF, 1/8W, 13, 10K	W95=00+0011	1	W95=00+0011	1	W95	RES, MF, 1/8W, 13, 7.5K	W95=00+0011	1	W95=00+0011	1
U6 L24 L25 L26 L27 L28	CAP, CER, 100PF, 14V	U11=006	1	1500=00+0011	1	W97 W98	RES, MF, 1/8W, 13, 10K	W97=00+0011	1	W97=00+0011	1	W97	RES, MF, 1/8W, 13, 7.5K	W97=00+0011	1	W97=00+0011	1
U7 L29 L30 L31 L32 L33	CAP, CER, 100PF, 14V	U12=007	1	1500=00+0011	1	W99 W100	RES, MF, 1/8W, 13, 10K	W99=00+0011	1	W99=00+0011	1	W99	RES, MF, 1/8W, 13, 7.5K	W99=00+0011	1	W99=00+0011	1
U8 L34 L35 L36 L37 L38	CAP, CER, 100PF, 14V	U13=008	1	1500=00+0011	1	W101 W102 W103 W104	RES, MF, 1/8W, 13, 10K	W101=00+0011	1	W101=00+0011	1	W101	RES, MF, 1/8W, 13, 7.5K	W101=00+0011	1	W101=00+0011	1
U9 L39 L40 L41 L42 L43	CAP, CER, 100PF, 14V	U14=009	1	1500=00+0011	1	W105 W106	RES, MF, 1/8W, 13, 10K	W105=00+0011	1	W105=00+0011	1	W105	RES, MF, 1/8W, 13, 7.5K	W105=00+0011	1	W105=00+0011	1
U10 L44 L45 L46 L47 L48	CAP, CER, 100PF, 14V	U15=010	1	1500=00+0011	1	W107 W108	RES, MF, 1/8W, 13, 10K	W107=00+0011	1	W107=00+0011	1	W107	RES, MF, 1/8W, 13, 7.5K	W107=00+0011	1	W107=00+0011	1
U11 L49 L50 L51 L52 L53	CAP, CER, 100PF, 14V	U16=011	1	1500=00+0011	1	W109 W110	RES, MF, 1/8W, 13, 10K	W109=00+0011	1	W109=00+0011	1	W109	RES, MF, 1/8W, 13, 7.5K	W109=00+0011	1	W109=00+0011	1
U12 L54 L55 L56 L57 L58	CAP, CER, 100PF, 14V	U17=012	1	1500=00+0011	1	W111 W112	RES, MF, 1/8W, 13, 10K	W111=00+0011	1	W111=00+0011	1	W111	RES, MF, 1/8W, 13, 7.5K	W111=00+0011	1	W111=00+0011	1
U13 L59 L60 L61 L62 L63	CAP, CER, 100PF, 14V	U18=013	1	1500=00+0011	1	W113 W114	RES, MF, 1/8W, 13, 10K	W113=00+0011	1	W113=00+0011	1	W113	RES, MF, 1/8W, 13, 7.5K	W113=00+0011	1	W113=00+0011	1
U14 L64 L65 L66 L67 L68	CAP, CER, 100PF, 14V	U19=014	1	1500=00+0011	1	W115 W116	RES, MF, 1/8W, 13, 10K	W115=00+0011	1	W115=00+0011	1	W115	RES, MF, 1/8W, 13, 7.5K	W115=00+0011	1	W115=00+0011	1
U15 L69 L70 L71 L72 L73	CAP, CER, 100PF, 14V	U20=015	1	1500=00+0011	1	W117 W118	RES, MF, 1/8W, 13, 10K	W117=00+0011	1	W117=00+0011	1	W117	RES, MF, 1/8W, 13, 7.5K	W117=00+0011	1	W117=00+0011	1
U16 L74 L75 L76 L77 L78	CAP, CER, 100PF, 14V	U21=016	1	1500=00+0011	1	W119 W120	RES, MF, 1/8W, 13, 10K	W119=00+0011	1	W119=00+0011	1	W119	RES, MF, 1/8W, 13, 7.5K	W119=00+0011	1	W119=00+0011	1
U17 L79 L80 L81 L82 L83	CAP, CER, 100PF, 14V	U22=017	1	1500=00+0011	1	W121 W122	RES, MF, 1/8W, 13, 10K	W121=00+0011	1	W121=00+0011	1	W121	RES, MF, 1/8W, 13, 7.5K	W121=00+0011	1	W121=00+0011	1
U18 L84 L85 L86 L87 L88	CAP, CER, 100PF, 14V	U23=018	1	1500=00+0011	1	W123 W124	RES, MF, 1/8W, 13, 10K	W123=00+0011	1	W123=00+0011	1	W123	RES, MF, 1/8W, 13, 7.5K	W123=00+0011	1	W123=00+0011	1
U19 L89 L90 L91 L92 L93	CAP, CER, 100PF, 14V	U24=019	1	1500=00+0011	1	W125 W126	RES, MF, 1/8W, 13, 10K	W125=00+0011	1	W125=00+0011	1	W125	RES, MF, 1/8W, 13, 7.5K	W125=00+0011	1	W125=00+0011	1
U20 L94 L95 L96 L97 L98	CAP, CER, 100PF, 14V	U25=020	1	1500=00+0011	1	W127 W128	RES, MF, 1/8W, 13, 10K	W127=00+0011	1	W127=00+0011	1	W127	RES, MF, 1/8W, 13, 7.5K	W127=00+0011	1	W127=00+0011	1
U21 L99 L100 L101 L102 L103	CAP, CER, 100PF, 14V	U26=021	1	1500=00+0011	1	W129 W130	RES, MF, 1/8W, 13, 10K	W129=00+0011	1	W129=00+0011	1	W129	RES, MF, 1/8W, 13, 7.5K	W129=00+0011	1	W129=00+0011	1
U22 L104 L105 L106 L107 L108	CAP, CER, 100PF, 14V	U27=022	1	1500=00+0011	1	W131 W132	RES, MF, 1/8W, 13, 10K	W131=00+0011	1	W131=00+0011	1	W131	RES, MF, 1/8W, 13, 7.5K	W131=00+0011	1	W131=00+0011	1
U23 L109 L110 L111 L112 L113	CAP, CER, 100PF, 14V	U28=023	1	1500=00+0011	1	W133 W134	RES, MF, 1/8W, 13, 10K	W133=00+0011	1	W133=00+0011	1	W133	RES, MF, 1/8W, 13, 7.5K	W133=00+0011	1	W133=00+0011	1
U24 L114 L115 L116 L117 L118	CAP, CER, 100PF, 14V	U29=024	1	1500=00+0011	1	W135 W136	RES, MF, 1/8W, 13, 10K	W135=00+0011	1	W135=00+0011	1	W135	RES, MF, 1/8W, 13, 7.5K	W135=00+0011	1	W135=00+0011	1
U25 L119 L120 L121 L122 L123	CAP, CER, 100PF, 14V	U30=025	1	1500=00+0011	1	W137 W138	RES, MF, 1/8W, 13, 10K	W137=00+0011	1	W137=00+0011	1	W137	RES, MF, 1/8W, 13, 7.5K	W137=00+0011	1	W137=00+0011	1
U26 L124 L125 L126 L127 L128	CAP, CER, 100PF, 14V	U31=026	1	1500=00+0011	1	W139 W140	RES, MF, 1/8W, 13, 10K	W139=00+0011	1	W139=00+0011	1	W139	RES, MF, 1/8W, 13, 7.5K	W139=00+0011	1	W139=00+0011	1
U27 L129 L130 L131 L132 L133	CAP, CER, 100PF, 14V	U32=027	1	1500=00+0011	1	W141 W142	RES, MF, 1/8W, 13, 10K	W141=00+0011	1	W141=00+0011	1	W141	RES, MF, 1/8W, 13, 7.5K	W141=00+0011	1	W141=00+0011	1
U28 L134 L135 L136 L137 L138	CAP, CER, 100PF, 14V	U33=028	1	1500=00+0011	1	W143 W144	RES, MF, 1/8W, 13, 10K	W143=00+0011	1	W143=00+0011	1	W143	RES, MF, 1/8W, 13, 7.5K	W143=00+0011	1	W143=00+0011	1
U29 L139 L140 L141 L142 L143	CAP, CER, 100PF, 14V	U34=029	1	1500=00+0011	1	W145 W146	RES, MF, 1/8W, 13, 10K	W145=00+0011	1	W145=00+0011	1	W145	RES, MF, 1/8W, 13, 7.5K	W145=00+0011	1	W145=00+0011	1
U30 L144 L145 L146 L147 L148	CAP, CER, 100PF, 14V	U35=030	1	1500=00+0011	1	W147 W148	RES, MF, 1/8W, 13, 10K	W147=00+0011	1	W147=00+0011	1	W147	RES, MF, 1/8W, 13, 7.5K	W147=00+0011	1	W147=00+0011	1
U31 L149 L150 L151 L152 L153	CAP, CER, 100PF, 14V	U36=031	1	1500=00+0011	1	W149 W150	RES, MF, 1/8W, 13, 10K	W149=00+0011	1	W149=00+0011	1	W149	RES, MF, 1/8W, 13, 7.5K	W149=00+0011	1	W149=00+0011	1
U32 L154 L155 L156 L157 L158	CAP, CER, 100PF, 14V	U37=032	1	1500=00+0011	1	W151 W152	RES, MF, 1/8W, 13, 10K	W151=00+0011	1	W151=00+0011	1	W151	RES, MF, 1/8W, 13, 7.5K	W151=00+0011	1	W151=00+0011	1
U33 L159 L160 L161 L162 L163	CAP, CER, 100PF, 14V	U38=033	1	1500=00+0011	1	W153 W154	RES, MF, 1/8W, 13, 10K	W153=00+0011	1	W153=00+0011	1	W153	RES, MF, 1/8W, 13, 7.5K	W153=00+0011	1	W153=00+0011	1
U34 L164 L165 L166 L167 L168	CAP, CER, 100PF, 14V	U39=034	1	1500=00+0011	1	W155 W156	RES, MF, 1/8W, 13, 10K	W155=00+0011	1	W155=00+0011	1	W155	RES, MF, 1/8W, 13, 7.5K	W155=00+0011	1	W155=00+0011	1
U35 L169 L170 L171 L172 L173	CAP, CER, 100PF, 14V	U40=035	1	1500=00+0011	1	W157 W158	RES, MF, 1/8W, 13, 10K	W157=00+0011	1	W157=00+0011	1	W157	RES, MF, 1/8W, 13, 7.5K	W157=00+0011	1	W157=00+0011	1
U36 L174 L175 L176 L177 L178	CAP, CER, 100PF, 14V	U41=036	1	1500=00+0011	1	W159 W160	RES, MF, 1/8W, 13, 10K	W159=00+0011	1	W159=00+0011	1	W159	RES, MF, 1/8W, 13, 7.5K	W159=00+0011	1	W159=00+0011	1
U37 L179 L180 L181 L182 L183	CAP, CER, 100PF, 14V	U42=037	1	1500=00+0011	1	W161 W162	RES, MF, 1/8W, 13, 10K	W161=00+0011	1	W161=00+0011	1	W161	RES, MF, 1/8W, 13, 7.5K	W161=00+0011	1	W161=00+0011	1
U38 L184 L185 L186 L187 L188	CAP, CER, 100PF, 14V	U43=038	1	1500=00+0011	1	W163 W164	RES, MF, 1/8W, 13, 10K	W163=00+0011	1	W163=00+0011	1	W163	RES, MF, 1/8W, 13, 7.5K	W163=00+0011	1	W163=00+0011	1
U39 L189 L190 L191 L192 L193	CAP, CER, 100PF, 14V	U44=039	1	1500=00+0011	1	W165 W166	RES, MF, 1/8W, 13, 10K	W165=00+0011	1	W165=00+0011	1	W165	RES, MF, 1/8W, 13, 7.5K	W165=00+0011	1	W165=00+0011	1
U40 L194 L195 L196 L197 L198	CAP, CER, 100PF, 14V	U45=040	1	1500=00+0011	1	W167 W168	RES, MF, 1/8W, 13, 10K	W167=00+0011	1	W167=00+0011	1	W167	RES, MF, 1/8W, 13, 7.5K	W167=00+0011	1	W167=00+0011	1
U41 L199 L200 L201 L202 L203	CAP, CER, 100PF, 14V	U46=041	1	1500=00+0011	1	W169 W170	RES, MF, 1/8W, 13, 10K	W169=00+0011	1	W169=00+0011	1	W169	RES, MF, 1/8W, 13, 7.5K	W169=00+0011	1	W169=00+0011	1
U42 L204 L205 L206 L207 L208	CAP, CER, 100PF, 14V	U47=042	1	1500=00+0011	1	W171 W172	RES, MF, 1/8W, 13, 10K	W171=00+0011	1	W171=00+0011	1	W171	RES, MF, 1/8W, 13, 7.5K	W171=00+0011	1	W171=00+0011	1
U43 L209 L210 L211 L212 L213	CAP, CER, 100PF, 14V	U48=043	1	1500=00+0011	1	W173 W174	RES, MF, 1/8W, 13, 10K	W173=00+0011	1	W173=00+0011	1	W173	RES, MF, 1/8W, 13, 7.5K	W173=00+0011	1	W173=00+0011	1
U44 L214 L215 L216 L217 L218	CAP, CER, 100PF, 14V	U49=044	1	1500=00+0011	1	W175 W176	RES, MF, 1/8W, 13, 10K	W175=00+0011	1	W175=00+0011	1	W					





REFERENCE DESIGNATORS	PART DESCRIPTION	ORIG-MFGN-PART-NO	MFGN	WAVETEK NO.	UTY/PY
NONE	ASST UHWR, REAR PNL	0102-00-0330	NVTA	0102-00-0330	1
4	TRANSFORMER	140-500	NVTA	1200-00-0000	1
15	DRHT-3W	140-320	NVTA	1800-00-2503	1
NONE	END BELL	157-500-00	NVTA	1400-00-3220	1
14	PANEL, REAR	1000-00-0710	NVTA	1000-00-0710	1
NONE	LABEL, ID#	1000-00-0070	NVTA	1000-00-0070	1
12	SW, VNA	AC-7000	KING	2100-01-0002	1
10	RECEPT, POWER	LAC-301	SHCFT	2100-03-0005	1
20	TERM, LUG, LUG	1014-0	SMITH	2100-00-0000	1
25	TERM, LUG, LUG	1014-0	SMITH	2100-00-0010	1
18	SOLDER LUG	1007	SMITH	2100-00-0012	3
NONE	SOLDER LUG	1005-0	SMITH	2100-00-0025	1
15	KNOB	020-352	ELMA	2000-01-0003	1
16	KNOB CAP	000-302	ELMA	2000-01-0004	1
6	FUSE, 250V, 1/2A, 500	313-500	LITTE	2000-00-0010	1
5	FUSE HOLD	305001	LITTE	2000-00-0012	1
21	FUSE, CHASSIS	1501-C11	USECU	2000-00-0002	2
17	WASHER, SHUULDER	2000	SMITH	2000-27-0000	3
WAVETEK PARTS LIST		TITLE REAR PANEL ASSY		ASSEMBLY NO. 1101-UU-0071	REV 0
				PAGE: 1	

REFERENCE DESIGNATORS	PART DESCRIPTION	ORIG-MFGN-PART-NO	MFGN	WAVETEK NO.	UTY/PY
19	RYLLN PLAT WASHER	2000-00-305	ANTON	2000-20-0005	3
3	POT, SWITCH MOD	4000-00-0000	NVTA	4000-00-0000	1
11	SWITCH ASST SLIDE	40250-LF	SHCFT	5100-00-0002	1
7	SOLDER GUARD	40250-LF-00	SHCFT	5100-00-0001	1
WAVETEK PARTS LIST		TITLE REAR PANEL ASSY		ASSEMBLY NO. 1101-UU-0071	REV 0
				PAGE: 2	

REMOVE ALL DIMS AND BREAK SHARP EDGES	DRAWN	DATE	WAVETEK SAN DIEGO - CALIFORNIA	
MATERIAL	PROTECTOR			
	RELEASE APPROV			
	TOLERANCE UNLESS OTHERWISE SPECIFIED XXX - 000 ANGLES 1 AS - 000			
	DO NOT SCALE DIMS			
FINISH WAVETEK PROCESS	DATE	4/6	DWG NO. 110-00-0071	REV. 0
		23JJB	110-00-0071	G

REAR PANEL ASSY

REVISIONS			
REV	DESCRIPTION	DATE	APPROVED



2 SWITCH SHOWN IN FULL CCW POSITION
 1. SWITCH VIEWED FROM KNOB END OF BOARD
 NOTES:

1	1957	BA	5-11-79
B	945	BA	6-20-79
A	EW 462	BA	7-26-79

REV	DATE	BY	DATE	APP
1	5-11-79	BA		
2	6-20-79	BA		
3	7-26-79	BA		
4	8-1-79	BA		
5	8-1-79	BA		
6	8-1-79	BA		
7	8-1-79	BA		
8	8-1-79	BA		
9	8-1-79	BA		
10	8-1-79	BA		
11	8-1-79	BA		
12	8-1-79	BA		
13	8-1-79	BA		
14	8-1-79	BA		
15	8-1-79	BA		
16	8-1-79	BA		
17	8-1-79	BA		
18	8-1-79	BA		
19	8-1-79	BA		
20	8-1-79	BA		
21	8-1-79	BA		
22	8-1-79	BA		
23	8-1-79	BA		
24	8-1-79	BA		
25	8-1-79	BA		
26	8-1-79	BA		
27	8-1-79	BA		
28	8-1-79	BA		
29	8-1-79	BA		
30	8-1-79	BA		
31	8-1-79	BA		
32	8-1-79	BA		
33	8-1-79	BA		
34	8-1-79	BA		
35	8-1-79	BA		
36	8-1-79	BA		
37	8-1-79	BA		
38	8-1-79	BA		
39	8-1-79	BA		
40	8-1-79	BA		
41	8-1-79	BA		
42	8-1-79	BA		
43	8-1-79	BA		
44	8-1-79	BA		
45	8-1-79	BA		
46	8-1-79	BA		
47	8-1-79	BA		
48	8-1-79	BA		
49	8-1-79	BA		
50	8-1-79	BA		
51	8-1-79	BA		
52	8-1-79	BA		
53	8-1-79	BA		
54	8-1-79	BA		
55	8-1-79	BA		
56	8-1-79	BA		
57	8-1-79	BA		
58	8-1-79	BA		
59	8-1-79	BA		
60	8-1-79	BA		
61	8-1-79	BA		
62	8-1-79	BA		
63	8-1-79	BA		
64	8-1-79	BA		
65	8-1-79	BA		
66	8-1-79	BA		
67	8-1-79	BA		
68	8-1-79	BA		
69	8-1-79	BA		
70	8-1-79	BA		
71	8-1-79	BA		
72	8-1-79	BA		
73	8-1-79	BA		
74	8-1-79	BA		
75	8-1-79	BA		
76	8-1-79	BA		
77	8-1-79	BA		
78	8-1-79	BA		
79	8-1-79	BA		
80	8-1-79	BA		
81	8-1-79	BA		
82	8-1-79	BA		
83	8-1-79	BA		
84	8-1-79	BA		
85	8-1-79	BA		
86	8-1-79	BA		
87	8-1-79	BA		
88	8-1-79	BA		
89	8-1-79	BA		
90	8-1-79	BA		
91	8-1-79	BA		
92	8-1-79	BA		
93	8-1-79	BA		
94	8-1-79	BA		
95	8-1-79	BA		
96	8-1-79	BA		
97	8-1-79	BA		
98	8-1-79	BA		
99	8-1-79	BA		
100	8-1-79	BA		

THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION AND DESIGN RIGHTS BELONGING TO WAVETEK AND MAY NOT BE REPRODUCED FOR ANY REASON, EXCEPT CALIBRATION, OPERATION, AND MAINTENANCE WITHOUT WRITTEN AUTHORIZATION


REV LTN BY DATE APP

REFERENCE OR SIGNATURE	PART DESCRIPTION	UNIT NUMBER	REV	DATE NO.	DATE
4	BLDC + 1/2" HIGHT	1000-00-1261			
5	SPACE	1000-00-1261			
6	SPACE	1000-00-1261			
1	POST, 1/2" DIA FWD (1000-01-0001)	1000-01-0001			
2	WAFER	1000-01-0001			
1	DETENT, MOD FWD (1000-01-0001)	1000-01-0001			
WAVETEK PARTS LIST		ASSEMBLY NO 1202-00-0015		REV	
		PAGE 1			


NOTE: UNLESS OTHERWISE SPECIFIED

REMOVE ALL BURRS AND BREAK SHARP EDGES	DRAWN	DATE	WAVETEK SAN DIEGO, CALIFORNIA	
MATERIAL	PROVIDER	TITLE		
	RELEASE APPROV	TRIGGER SWITCH		
FINISH	TOLERANCE UNLESS OTHERWISE SPECIFIED X.XX .XX ANGLES 1		MODEL NO	REV
WAVETEK PROCESS	DO NOT SCALE DWG		146	1202-00-0015
	SCALE		23338	C
				SHEET 1 OF 1


REVISIONS		
REV	DESCRIPTION	DATE




FIXED STOP
ADJUSTABLE STOP RING




DETENT KEY LOCATION




SWI-A & B



SWI-C



SWI-D & E



8. SWITCH SHOWN IN FULL OPEN POSITION
1. SWITCH VIEWED FROM KNOB END OF BOARD
NOTES:

B	945	BA	10-2-74
A	BB4	130	1-1-74
TOLERANCES UNLESS OTHERWISE SPEC.		REV	BY DATE APP
XXX	1/16"	BY GARY DATE 10-2-74 APP 10-2-74	
XX	1/32"	WAVETEK SAN DIEGO, CALIFORNIA	
XX	1/64"	SCALE -	
MATERIAL		TITLE	
-		SWITCH ASSY FREQ HZ	
FINISH		MODEL NO. 146 1702-00-004	
-		RE 13	

THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION AND DESIGN RIGHTS BELONGING TO WAVETEK AND MAY NOT BE REPRODUCED FOR ANY REASON EXCEPT CALIBRATION, OPERATION, AND MAINTENANCE WITHOUT WRITTEN AUTHORIZATION.

THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION AND DESIGN RIGHTS BELONGING TO WAVETEK AND MAY NOT BE REPRODUCED FOR ANY REASON EXCEPT CALIBRATION OPERATION AND MAINTENANCE WITHOUT WRITTEN AUTHORIZATION

REV	ECN	BY	DATE	APP
-----	-----	----	------	-----

PREFERENCE DESIGNATORS	PART DESCRIPTION	UNIT-NUM-PART-NO	REF	WAVETEK NO.	UNIT/P1
0	SPACER	142-300	N/A	13400-00-2073	4
1	SPACER, 3/8"	1400-00-0013	N/A	13400-00-0013	4
2	POST, LUM, 10A	130-001A	N/A	1400-00-10305	1
3	WAFER	142-001-1	N/A	1310-00-0013	3
4	WAFER, 10P	142-33-000	LTS	1310-00-0000	1
5	WAFER, 10P	1310-00-0013	N/A	1310-00-0013	1

WAVETEK

PARTS LIST

TITLE

FREQ SW

ASSEMBLY NO.

1202-00-0016




REV

0


PAGE 1

NOTE: UNLESS OTHERWISE SPECIFIED

REMOVE ALL BURRS AND BREAK SHARP EDGES		DRAWN	DATE	WAVETEK SAN DIEGO, CA 92161	
MATERIAL		PROVIDER		TITLE	
FINISH WAVETEK PROCESS		RELEASE APPROV		FREQ SW	
TOLERANCE UNLESS OTHERWISE SPECIFIED: XX - .010 ANGLES 1:1 XX - .005		DO NOT SCALE DWG		MODEL NO	
SCALE		ECON		1202-00-0016	
ECON		23338		SHEET 1/1	



SW2-A



SW2-B



2. SWITCH SHOWN IN FULL CCW POSITION
1. SWITCH VIEWED FROM KNOB END OF BOARD

NOTES:

TOLERANCE UNLESS OTHERWISE SPECIFIED		BY		DATE		BY		DATE		BY	
X.XX ± .010		BY		DATE		BY		DATE		BY	
X.X ± .005		BY		DATE		BY		DATE		BY	
X.X ± .002		BY		DATE		BY		DATE		BY	
X.X ± .001		BY		DATE		BY		DATE		BY	
X.X ± .0005		BY		DATE		BY		DATE		BY	
X.X ± .0002		BY		DATE		BY		DATE		BY	
X.X ± .0001		BY		DATE		BY		DATE		BY	
X.X ± .00005		BY		DATE		BY		DATE		BY	
X.X ± .00002		BY		DATE		BY		DATE		BY	
X.X ± .00001		BY		DATE		BY		DATE		BY	
X.X ± .000005		BY		DATE		BY		DATE		BY	
X.X ± .000002		BY		DATE		BY		DATE		BY	
X.X ± .000001		BY		DATE		BY		DATE		BY	
X.X ± .0000005		BY		DATE		BY		DATE		BY	
X.X ± .0000002		BY		DATE		BY		DATE		BY	
X.X ± .0000001		BY		DATE		BY		DATE		BY	
X.X ± .00000005		BY		DATE		BY		DATE		BY	
X.X ± .00000002		BY		DATE		BY		DATE		BY	
X.X ± .00000001		BY		DATE		BY		DATE		BY	
X.X ± .000000005		BY		DATE		BY		DATE		BY	
X.X ± .000000002		BY		DATE		BY		DATE		BY	
X.X ± .000000001		BY		DATE		BY		DATE		BY	
X.X ± .0000000005		BY		DATE		BY		DATE		BY	
X.X ± .0000000002		BY		DATE		BY		DATE		BY	
X.X ± .0000000001		BY		DATE		BY		DATE		BY	
X.X ± .00000000005		BY		DATE		BY		DATE		BY	
X.X ± .00000000002		BY		DATE		BY		DATE		BY	
X.X ± .00000000001		BY		DATE		BY		DATE		BY	
X.X ± .000000000005		BY		DATE		BY		DATE		BY	
X.X ± .000000000002		BY		DATE		BY		DATE		BY	
X.X ± .000000000001		BY		DATE		BY		DATE		BY	
X.X ± .0000000000005		BY		DATE		BY		DATE		BY	
X.X ± .0000000000002		BY		DATE		BY		DATE		BY	
X.X ± .0000000000001		BY		DATE		BY		DATE		BY	
X.X ± .00000000000005		BY		DATE		BY		DATE		BY	
X.X ± .00000000000002		BY		DATE		BY		DATE		BY	
X.X ± .00000000000001		BY		DATE		BY		DATE		BY	
X.X ± .000000000000005		BY		DATE		BY		DATE		BY	
X.X ± .000000000000002		BY		DATE		BY		DATE		BY	
X.X ± .000000000000001		BY		DATE		BY		DATE		BY	
X.X ± .0000000000000005		BY		DATE		BY		DATE		BY	
X.X ± .0000000000000002		BY		DATE		BY		DATE		BY	
X.X ± .0000000000000001		BY		DATE		BY		DATE		BY	
X.X ± .00000000000000005		BY		DATE		BY		DATE		BY	
X.X ± .00000000000000002		BY		DATE		BY		DATE		BY	
X.X ± .00000000000000001		BY		DATE		BY		DATE		BY	
X.X ± .000000000000000005		BY		DATE		BY		DATE		BY	
X.X ± .000000000000000002		BY		DATE		BY		DATE		BY	
X.X ± .000000000000000001		BY		DATE		BY		DATE		BY	
X.X ± .0000000000000000005		BY		DATE		BY		DATE		BY	
X.X ± .0000000000000000002		BY		DATE		BY		DATE		BY	
X.X ± .0000000000000000001		BY		DATE		BY		DATE		BY	
X.X ± .00000000000000000005		BY		DATE		BY		DATE		BY	
X.X ± .00000000000000000002		BY		DATE		BY		DATE		BY	
X.X ± .00000000000000000001		BY		DATE		BY		DATE		BY	
X.X ± .000000000000000000005		BY		DATE		BY		DATE		BY	
X.X ± .000000000000000000002		BY		DATE		BY		DATE		BY	
X.X ± .000000000000000000001		BY		DATE		BY		DATE		BY	
X.X ± .0000000000000000000005		BY		DATE		BY		DATE		BY	
X.X ± .0000000000000000000002		BY		DATE		BY		DATE		BY	
X.X ± .0000000000000000000001		BY		DATE		BY		DATE		BY	
X.X ± .00000000000000000000005		BY		DATE		BY		DATE		BY	
X.X ± .00000000000000000000002		BY		DATE		BY		DATE		BY	
X.X ± .00000000000000000000001		BY		DATE		BY		DATE		BY	
X.X ± .000000000000000000000005		BY		DATE		BY		DATE		BY	
X.X ± .000000000000000000000002		BY		DATE		BY		DATE		BY	
X.X ± .000000000000000000000001		BY		DATE		BY		DATE		BY	
X.X ± .0000000000000000000000005		BY		DATE		BY		DATE		BY	
X.X ± .0000000000000000000000002		BY		DATE		BY		DATE		BY	
X.X ± .0000000000000000000000001		BY		DATE		BY		DATE		BY	
X.X ± .00000000000000000000000005		BY		DATE		BY		DATE		BY	
X.X ± .00000000000000000000000002		BY		DATE		BY		DATE		BY	
X.X ± .00000000000000000000000001		BY		DATE		BY		DATE		BY	
X.X ± .000000000000000000000000005		BY		DATE		BY		DATE		BY	
X.X ± .000000000000000000000000002		BY		DATE		BY		DATE		BY	
X.X ± .000000000000000000000000001		BY		DATE		BY		DATE		BY	
X.X ± .0000000000000000000000000005		BY		DATE		BY		DATE		BY	
X.X ± .0000000000000000000000000002		BY		DATE		BY		DATE		BY	
X.X ± .0000000000000000000000000001		BY		DATE		BY		DATE		BY	
X.X ± .00000000000000000000000000005		BY		DATE		BY		DATE		BY	
X.X ± .00000000000000000000000000002		BY		DATE		BY		DATE		BY	
X.X ± .00000000000000000000000000001		BY		DATE		BY		DATE		BY	
X.X ± .000000000000000000000000000005		BY		DATE		BY		DATE		BY	
X.X ± .000000000000000000000000000002		BY		DATE		BY		DATE		BY	
X.X ± .000000000000000000000000000001		BY		DATE		BY		DATE		BY	
X.X ± .0000000000000000000000000000005		BY		DATE		BY		DATE		BY	
X.X ± .0000000000000000000000000000002		BY		DATE		BY		DATE		BY	
X.X ± .0000000000000000000000000000001		BY		DATE		BY		DATE		BY	
X.X ± .00000000000000000000000000000005		BY		DATE		BY		DATE		BY	
X.X ± .00000000000000000000000000000002		BY		DATE		BY		DATE		BY	
X.X ± .00000000000000000000000000000001		BY		DATE		BY		DATE		BY	
X.X ± .000000000000000000000000000000005		BY		DATE		BY		DATE		BY	
X.X ± .000000000000000000000000000000002		BY		DATE		BY		DATE		BY	
X.X ± .000000000000000000000000000000001		BY		DATE		BY		DATE		BY	
X.X ± .0000000000000000000000000000000005		BY		DATE		BY		DATE		BY	
X.X ± .0000000000000000000000000000000002		BY		DATE		BY		DATE		BY	
X.X ± .0000000000000000000000000000000001		BY		DATE		BY		DATE		BY	
X.X ± .00000000000000000000000000000000005		BY		DATE		BY		DATE		BY	
X.X ± .00000000000000000000000000000000002		BY		DATE		BY		DATE		BY	
X.X ± .00000000000000000000000000000000001		BY		DATE		BY		DATE		BY	
X.X ± .000000000000000000000000000000000005		BY		DATE		BY		DATE		BY	
X.X ± .000000000000000000000000000000000002		BY		DATE		BY		DATE		BY	
X.X ± .000000000000000000000000000000000001		BY		DATE		BY		DATE		BY	
X.X ± .0000000000000000000000000000000000005		BY		DATE		BY		DATE		BY	
X.X ± .0000000000000000000000000000000000002		BY		DATE		BY		DATE		BY	
X.X ± .0000000000000000000000000000000000001		BY		DATE		BY		DATE		BY	
X.X ± .00000000000000000000000000000000000005		BY		DATE		BY		DATE		BY	
X.X ± .00000000000000000000000000000000000002		BY		DATE		BY		DATE		BY	
X.X ± .00000000000000000000000000000000000001		BY		DATE		BY		DATE		BY	
X.X ± .000000000000000000000000000000000000005		BY		DATE		BY		DATE		BY	
X.X ± .000000000000000000000000000000000000002		BY		DATE		BY		DATE		BY	
X.X ± .000000000000000000000000000000000000001		BY		DATE		BY		DATE		BY	
X.X ± .0000000000000000000000000000000000000005		BY		DATE		BY		DATE		BY	
X.X ± .0000000000000000000000000000000000000002		BY		DATE		BY		DATE		BY	
X.X ± .0000000000000000000000000000000000000001		BY		DATE		BY		DATE		BY	
X.X ± .00000000000000000000000000000000000000005		BY		DATE		BY		DATE		BY	
X.X ± .00000000000000000000000000000000000000002		BY		DATE		BY		DATE		BY	
X.X ± .00000000000000000000000000000000000000001		BY		DATE		BY		DATE		BY	
X.X ± .000000000000000000000000000000000000000005		BY		DATE		BY		DATE		BY	
X.X ± .000000000000000000000000000000000000000002		BY		DATE		BY		DATE		BY	
X.X ± .000000000000000000000000000000000000000001		BY		DATE		BY		DATE		BY	
X.X ± .0000000000000000000000000000000000000000005		BY		DATE		BY		DATE		BY	
X.X ± .0000000000000000000000000000000000000000002		BY		DATE		BY		DATE		BY	
X.X ± .000000											

THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION AND DESIGN RIGHTS BELONGING TO WAVETEK AND MAY NOT BE REPRODUCED FOR ANY REASON EXCEPT CALIBRATION, OPERATION, AND MAINTENANCE WITHOUT WRITTEN AUTHORIZATION





1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100

REFERENCE DESIGNATION	PART DESCRIPTION	ORIGINATOR PART NO	RDGN	WAVETEK NO.	WAVEPI
1	SPACER, 3/4"	1400-00-0013	W14	1400-00-0013	4
2	SPACER	0501	SPJ1H	1400-00-0003	4
3	W/1, LUN, 1/8"	130-0-10	W14	1400-00-0007	1
4	DEFINT	130-0-02	W14	1510-00-0003	1
5	WAFER	140-0-01-1	W14	1510-00-0013	4
6	BRIDGE PLUG	210-0-00-000	115	1510-00-0000	1
WAVETEK PARTS LIST TITLE ATTN SW ASST ASSEMBLY NO. 1400-00-0017 PAGE 1 REV A					

NOTE: UNLESS OTHERWISE SPECIFIED

REMOVE ALL BURRS AND BREAK SHARP EDGES		DRAWN		DATE	
MATERIAL		TOLERANCE		TITLE	
FINISH		RELEASE APPROV		ATTN SW	
WAVETEK PROCESS		TOLERANCE UNLESS OTHERWISE SPECIFIED XXX - 010 ANGLES - 1 XX - 000		MODEL NO 146	
DO NOT SCALE DWG		SCALE		DWG NO 1202-00-0017	
TOTAL		23338		REV A	

REVISIONS			
REV	DATE	BY	APPROVED



SW2

2. SWITCH SHOWN IN FULL CCW POSITION
1. SWITCH VIEWED FROM KNOB END OF BOARD
NOTES:

B 795	B 7074
A EC473	B 7074

TOLERANCE UNLESS OTHERWISE SPEC.		REV	PCN	BY	DATE	APP
XXX	1/2"					
AA	1/8"					
ANGLES	1/2"					
WAVETEK		SAR D-680 CALIFORNIA				
SCALE	1" = 1/2"	DATE	3-27-76	BY	WJL	
MATERIAL	TITLE SWITCH ASSY D/C OFFSET					
MODEL NO.	106	DATE	3-27-76	BY	WJL	
THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION AND SHOULD BE KEPT SECRET TO WAVETEK AND MAY NOT BE REPRODUCED FOR ANY REASON EXCEPT CALIBRATION, OPERATION, AND MAINTENANCE WITHOUT WRITTEN AUTHORIZATION.						

THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION AND DESIGN RIGHTS BELONGING TO WAVETEK AND MAY NOT BE REPRODUCED FOR ANY REASON EXCEPT CALIBRATION, OPERATION, AND MAINTENANCE WITHOUT WRITTEN AUTHORIZATION

REV	ECN	BY	DATE	APP
-----	-----	----	------	-----



REFERENCE DESIGNATORS	PART DESCRIPTION	UNIQUE PART NO.	QTY	WAVETEK NO.	QTY REQD
1	BLUEN-SUPPORT	130-328	1	1400-00-1000	1
1	DRILLH-ADPT MOUNT	130-000	1	1400-00-0011	1
1	DRILLH-ADPT	130-330-000	1	1400-00-0000	1

WAVETEK PARTS LIST	TITLE D/C OFFSET DR ADPT	ASSEMBLY NO. 1400-00-0010	REV 0
		PAGE 1	

NOTE: UNLESS OTHERWISE SPECIFIED

REMOVE ALL BURS AND BREAK SHARP EDGES		DRAWN	DATE	WAVETEK SAN DIEGO - CALIF. 92161	
MATERIAL	FINISH	RELEASE APPROV		TITLE D/C OFFSET SW	
FINISH WAVETEK PROCESS	TOLERANCE: UNLESS OTHERWISE SPECIFIED DIM - DIM ANGLES - DEG		MODEL NO. 1400-00-0010		
	DO NOT SCALE DIMS		DWG NO. 202-00-0010		
	SCALE		REV B		
DATE 2/23/88		SHEET 1		OF 1	

REVISION			
REV	DESCRIPTION	DATE	APPROVED



2. SWITCH SHOWN IN FULL CEN POSITION
 1. SWITCH VIEWED FROM KNOB END OF BOARD

NOTES:

TOLERANCE UNLESS OTHERWISE SPEC		REV		CON	BY	DATE	APP
XX ± .010		A		3	1	8-22-78	WAVE
XX ± .005		B		1	1	8-22-78	WAVE
ANGLES ± .5°		C		1	1	8-22-78	WAVE
SCALE -		BY GRAY		DATE 8-22-78		APP WAVE	
MATERIAL -		TITLE		SWITCH ASSY			
-		MODEL NO		100-12200-00-9			
FINISH -		DATE		8-22-78			
THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION AND DESIGN RIGHTS IN CONNECTION WITH THE DESIGN AND MAY NOT BE REPRODUCED FOR ANY REASON EXCEPT CALIBRATION OPERATOR AND MAINTENANCE WITHOUT WRITTEN AUTHORIZATION		REV		2			


THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION AND DESIGN RIGHTS BELONGING TO WAVETEK AND MAY NOT BE REPRODUCED FOR ANY REASON EXCEPT CALIBRATION, OPERATION, AND MAINTENANCE WITHOUT WRITTEN AUTHORIZATION

REV. C/N DT DATE APP

REFERENCE DESIGNATORS	PART DESCRIPTION	UNIG+MSGH+PART-NU	MGR	WAVETEK NO.	UTX/PT
2	NAFEM	133+3M1+1	RV1K	5104+02+0008	2
HUM6	SWITCH D10P	212+33+0006	CTB	5104+07+0002	1
1	DETECT,MOD +HUM5104+01+0003	5104+9V+0002	RV1K	5104+9V+0002	1
WAVETEK PARTS LIST		TITLE FREQ/PERIOD SW ASST		ASSEMBLY NO 1202+00+0019 PAGE: 1	REV R

NOTE: UNLESS OTHERWISE SPECIFIED



REMOVE ALL BURRS AND BREAK SHARP EDGES		DRAWN	DATE	WAVETEK SAN DIEGO • CA, FORM 14	
MATERIAL		PROTECTOR		TITLE	
RELEASE APPROV		FREQ/PERIOD SW			
TOLERANCE UNLESS OTHERWISE SPECIFIED BY: DIM ANGLES: 1 2X .25					
FINISH WAVETEK PROCESS		DO NOT SCALE DIMS		WORK NO 146	DWG NO 202-00-0019
G ALT				REV 3	REV 3
		23138		SHEET OF	



WAVETEK
 PATCH BLOCK (MODEL 154)
 1205-00-0489 A
 B 3-11-76 K.fo
 SHIT 2 of 2

REV	ECN	BY	DATE	APP
A	ECN NO. 1472	RO	12/28/94	
B	REDRAWN (NO CHANGES)	DC	12/27/94	
C	# 1444	BB	11/17/94	SC

TRIM PIN NO. 9, BEFORE
INSERTING IC1 INTO
DIP SOCKET



TRIM PIN NOS. 2, 3, 4, 5, 11, AND 12
AFTER INSERTING DIP SOCKET
INTO P.C. BD.

SPACER (EPOXY TO
UNDERSIDE OF P.C. BD.)

REFERENCE DESIGNATION	PART DESCRIPTION	UNIT QUANTITY	REF. NO.	QTY/PRT
1	SPACER	1000+00+000	101	1000+00+000
5	CHIP REPLACEMENT KIT	150+120	101	150+00+000
7	SKT, IC, 14PINS	C842270+1000	540	2100+00+000
H2	RESISTOR, 1/4W, 1K, 5%	W5550+0000	100	4700+00+000
H1	RESISTOR, 1/4W, 1K, 5%	W5550+0000	100	4700+00+000
Q1	TRIM PIN	25+00	101	4000+00+000
TC1	IC	700+00	101	4000+00+000

WAVETEK
PARTS LIST

TITLE
PATCH BLOCK

ASSEMBLY NO.
1205-00-0489
PAGE 1

REV
C

REMOVE ALL BURRS AND BREAK SHARP EDGES		DRAWN D. COOPER	DATE 12/27/94	WAVETEK SAN DIEGO • CALIFORNIA	
MATERIAL POTTER		TOLERANCE UNLESS OTHERWISE SPECIFIED XXX ± 0.10 ANGLES ± 1° XXX ± 0.05		TITLE PATCH BLOCK	
FINISH WAVETEK PROCESS		DO NOT SCALE DWG		MODEL NO. 144, H6	
SCALE		154		DWG NO. 1205-00-0489	
TITLED 23338		SHEET 2 OF 2		REV C	

www.manualsplus.com



1030093